

Service Manual

Inverter Pair Wall Mounted Type E-Series



[Applied Models]
● Inverter Pair : Heat Pump

Inverter Pair E-Series

●Heat Pump

Indoor Unit

ATXS25EV1B7

ATXS35EV1B7

ATXS50EV1B7

Outdoor Unit

ARXS25F3V1B

ARXS35F3V1B

ARXS50E3V1B

1. Introduction	V
1.1 Safety Cautions	V
1.2 Used Icons	ix
Part 1 List of Functions	1
1. List of Functions	2
Part 2 Specifications	3
1. Specifications	4
Part 3 Printed Circuit Board Connector Wiring Diagram	7
1. Printed Circuit Board Connector Wiring Diagram	8
1.1 Indoor Unit	8
1.2 Outdoor Unit	10
Part 4 Function and Control	15
1. Main Functions	16
1.1 Frequency Principle	16
1.2 Airflow Direction Control	18
1.3 Fan Speed Control for Indoor Units	19
1.4 Programme Dry Function	20
1.5 Automatic Operation	21
1.6 Thermostat Control	22
1.7 NIGHT SET Mode	23
1.8 ECONO Mode	24
1.9 INTELLIGENT EYE	25
1.10 Inverter POWERFUL Operation	27
1.11 Other Functions	28
2. Function of Thermistor	30
3. Control Specification	31
3.1 Mode Hierarchy	31
3.2 Frequency Control	32
3.3 Controls at Mode Changing / Start-up	34
3.4 Discharge Pipe Temperature Control	36
3.5 Input Current Control	37
3.6 Freeze-up Protection Control	38
3.7 Heating Peak-cut Control	38
3.8 Fan Control	39
3.9 Liquid Compression Protection Function 2	39
3.10 Defrost Control	40
3.11 Electronic Expansion Valve Control	41
3.12 Malfunctions	44
3.13 Forced Operation Mode	45
3.14 Additional Function	45
3.15 Facility Setting Jumper (cooling at low outdoor temperature)	46
Part 5 Operation Manual	47
1. System Configuration	48

2. Instruction.....	49
2.1 Safety precautions.....	49
2.2 Name of Parts	51
2.3 Preparation Before Operation	54
2.4 AUTO · DRY · COOL · HEAT · FAN Operation	57
2.5 Adjusting the Airflow Direction.....	59
2.6 POWERFUL Operation	61
2.7 OUTDOOR UNIT QUIET Operation.....	62
2.8 ECONO Operation	63
2.9 INTELLIGENT EYE Operation	64
2.10 TIMER Operation	66
2.11 Care and Cleaning	68
2.12 Troubleshooting.....	71

Part 6 Service Diagnosis..... 75








1. Caution for Diagnosis.....	76
2. Problem Symptoms and Measures	77
3. Service Check Function	78
4. Troubleshooting	81
4.1 Error Codes and Description	81
4.2 Indoor Unit PCB Abnormality	82
4.3 Freeze-up Protection Control or High Pressure Control.....	83
4.4 Fan Motor (DC Motor) or Related Abnormality.....	85
4.5 Thermistor or Related Abnormality (Indoor Unit).....	87
4.6 Signal Transmission Error (between Indoor and Outdoor Unit)	88
4.7 Unspecified Voltage (between Indoor and Outdoor Units)	90
4.8 Outdoor Unit PCB Abnormality.....	91
4.9 OL Activation (Compressor Overload)	93
4.10 Compressor Lock	94
4.11 DC Fan Lock	95
4.12 Input Over Current Detection	96
4.13 Four Way Valve Abnormality	99
4.14 Discharge Pipe Temperature Control.....	101
4.15 High Pressure Control in Cooling	103
4.16 Compressor System Sensor Abnormality	105
4.17 Position Sensor Abnormality	108
4.18 DC Voltage / Current Sensor Abnormality.....	109
4.19 CT or Related Abnormality	110
4.20 Thermistor or Related Abnormality (Outdoor Unit).....	112
4.21 Electrical Box Temperature Rise.....	114
4.22 Radiation Fin Temperature Rise	116
4.23 Output Over Current Detection.....	120
4.24 Insufficient Gas.....	122
4.25 Over-voltage Detection.....	126
4.26 Signal Transmission Error (on Outdoor Unit PCB).....	127
5. Check.....	128
5.1 How to Check	128

Part 7 Removal Procedure	137
1. Indoor Unit.....	138
1.1 Removal of Air Filter	138
1.2 Removal of Front Panel.....	140
1.3 Removal of Front Grille	142
1.4 Removal of Horizontal Blades and Vertical Blades	145
1.5 Removal of Electrical Box	148
1.6 Removal of PCB.....	151
1.7 Removal of Drain Pan Unit.....	157
1.8 Removal of Fan Motor.....	161
1.9 Removal of Heat Exchanger	163
1.10 Removal of Fan Rotor	166
2. Outdoor Unit.....	169
2.1 ARXS 25/35 F	169
2.2 ARXS 50 E	194
Part 8 Others	217
1. Others	218
1.1 Test Run from the Remote Controller	218
1.2 Jumper Settings	219
1.3 Application of Silicon Grease to a Power Transistor and a Diode Bridge.....	220
Part 9 Appendix.....	221
1. Piping Diagrams.....	222
1.1 Indoor Units	222
1.2 Outdoor Units	223
2. Wiring Diagrams.....	224
2.1 Indoor Units	224
2.2 Outdoor Units	225
Index	i
Drawings & Flow Charts	v








1. Introduction




1.1 Safety Cautions








Cautions and Warnings

- Be sure to read the following safety cautions before conducting repair work.
- The caution items are classified into “ **Warning**” and “ **Caution**”. The “ **Warning**” items are especially important since they can lead to death or serious injury if they are not followed closely. The “ **Caution**” items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.
- About the pictograms
 -  This symbol indicates the item for which caution must be exercised.
The pictogram shows the item to which attention must be paid.
 -  This symbol indicates the prohibited action.
The prohibited item or action is shown in the illustration or near the symbol.
 -  This symbol indicates the action that must be taken, or the instruction.
The instruction is shown in the illustration or near the symbol.
- After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer.












1.1.1 Cautions Regarding Safety of Workers






 Warning	
Be sure to disconnect the power cable plug from the plug socket before disassembling the equipment for repair. Working on the equipment that is connected to the power supply may cause an electrical shock. If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not touch any electrically charged sections of the equipment.	
If the refrigerant gas is discharged during the repair work, do not touch the discharged refrigerant gas. The refrigerant gas may cause frostbite.	
When disconnecting the suction or discharge pipe of the compressor at the welded section, evacuate the refrigerant gas completely at a well-ventilated place first. If there is a gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it may cause injury.	
If the refrigerant gas leaks during the repair work, ventilate the area. The refrigerant gas may generate toxic gases when it contacts flames.	
The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. Be sure to discharge the capacitor completely before conducting repair work. A charged capacitor may cause an electrical shock.	
Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug. Plugging or unplugging the power cable plug to operate the equipment may cause an electrical shock or fire.	







 Warning	
Be sure to wear a safety helmet, gloves, and a safety belt when working at a high place (more than 2m). Insufficient safety measures may cause a fall accident.	
In case of R410A refrigerant models, be sure to use pipes, flare nuts and tools for the exclusive use of the R410A refrigerant. The use of materials for R22 refrigerant models may cause a serious accident such as a damage of refrigerant cycle as well as an equipment failure.	






 Caution	
Do not repair the electrical components with wet hands. Working on the equipment with wet hands may cause an electrical shock.	
Do not clean the air conditioner by splashing water. Washing the unit with water may cause an electrical shock.	
Be sure to provide the grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.	
Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and cause injury.	
Be sure to conduct repair work with appropriate tools. The use of inappropriate tools may cause injury.	
Be sure to check that the refrigerating cycle section has cooled down enough before conducting repair work. Working on the unit when the refrigerating cycle section is hot may cause burns.	
Use the welder in a well-ventilated place. Using the welder in an enclosed room may cause oxygen deficiency.	

1.1.2 Cautions Regarding Safety of Users

 Warning	
<p>Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools may cause an electrical shock, excessive heat generation or fire.</p>	
<p>If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires may cause an electrical shock, excessive heat generation or fire.</p>	
<p>Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances, since it may cause an electrical shock, excessive heat generation or fire.</p>	
<p>Be sure to use an exclusive power circuit for the equipment, and follow the local technical standards related to the electrical equipment, the internal wiring regulations, and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work may cause an electrical shock or fire.</p>	
<p>Be sure to use the specified cable for wiring between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections may cause excessive heat generation or fire.</p>	
<p>When wiring between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section may cause an electrical shock, excessive heat generation or fire.</p>	
<p>Do not damage or modify the power cable. Damaged or modified power cable may cause an electrical shock or fire. Placing heavy items on the power cable, and heating or pulling the power cable may damage the cable.</p>	
<p>Do not mix air or gas other than the specified refrigerant (R410A / R22) in the refrigerant system. If air enters the refrigerating system, an excessively high pressure results, causing equipment damage and injury.</p>	
<p>If the refrigerant gas leaks, be sure to locate the leaking point and repair it before charging the refrigerant. After charging refrigerant, make sure that there is no refrigerant leak. If the leaking point cannot be located and the repair work must be stopped, be sure to perform pump-down and close the service valve, to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it may generate toxic gases when it contacts flames, such as fan and other heaters, stoves and ranges.</p>	
<p>When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength and if the installation work is not conducted securely, the equipment may fall and cause injury.</p>	





 Warning	
Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet securely. If the plug has dust or loose connection, it may cause an electrical shock or fire.	
Be sure to install the product correctly by using the provided standard installation frame. Incorrect use of the installation frame and improper installation may cause the equipment to fall, resulting in injury.	For unitary type only 
Be sure to install the product securely in the installation frame mounted on the window frame. If the unit is not securely mounted, it may fall and cause injury.	For unitary type only 
When replacing the coin battery in the remote controller, be sure to disposed of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.	

 Caution	
Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.	
Do not install the equipment in a place where there is a possibility of combustible gas leaks. If the combustible gas leaks and remains around the unit, it may cause a fire.	
Check to see if the parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections may cause excessive heat generation, fire or an electrical shock.	
If the installation platform or frame has corroded, replace it. Corroded installation platform or frame may cause the unit to fall, resulting in injury.	
Check the grounding, and repair it if the equipment is not properly grounded. Improper grounding may cause an electrical shock.	

 Caution	
Be sure to measure the insulation resistance after the repair, and make sure that the resistance is 1 MΩ or higher. Faulty insulation may cause an electrical shock.	
Be sure to check the drainage of the indoor unit after the repair. Faulty drainage may cause the water to enter the room and wet the furniture and floor.	
Do not tilt the unit when removing it. The water inside the unit may spill and wet the furniture and floor.	
Be sure to install the packing and seal on the installation frame properly. If the packing and seal are not installed properly, water may enter the room and wet the furniture and floor.	For unitary type only 

1.2 Used Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

Icon	Type of Information	Description
 Note:	Note	A “note” provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
 Caution	Caution	A “caution” is used when there is danger that the reader, through incorrect manipulation, may damage equipment, lose data, get an unexpected result or has to restart (part of) a procedure.
 Warning	Warning	A “warning” is used when there is danger of personal injury.
	Reference	A “reference” guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

Part 1

List of Functions

1. List of Functions	2
----------------------------	---

1. List of Functions

Category	Functions	ATXS25/35EV1B7 ARXS25/35F3V1B	ATXS50EV1B7 ARXS50E3V1B	Category	Functions	ATXS25/35EV1B7 ARXS25/35F3V1B	ATXS50EV1B7 ARXS50E3V1B
Basic Function	Inverter (with Inverter Power Control)	○	○	Health & Clean	Air Purifying Filter	—	—
	Operation Limit for Cooling (°CDB) ★	−10 ~46	−10 ~46		Photocatalytic Deodorizing Filter	—	—
	Operation Limit for Heating (°CWB)	−15 ~20	−15 ~18		Air Purifying Filter with Photocatalytic Deodorizing Function	—	—
	PAM Control	○	○		Titanium Apatite Photocatalytic Air-Purifying Filter	○	○
Compressor	Oval Scroll Compressor	—	—		Mold Proof Air Filter	○	○
	Swing Compressor	○	○		Wipe-clean Flat Panel	○	○
	Rotary Compressor	—	—		Washable Grille	—	—
	Reluctance DC Motor	○	○		Mold Proof Operation	—	—
Comfortable Airflow	Power-Airflow Flap	—	—	Timer	Heating Dry Operation	—	—
	Power-Airflow Dual Flaps	○	○		Good-Sleep Cooling Operation	—	—
	Power-Airflow Diffuser	—	—		24-Hour On/Off Timer	○	○
	Wide-Angle Louvers	○	○		Night Set Mode	○	○
	Vertical Auto-Swing (Up and Down)	○	○		Auto-Restart (after Power Failure)	○	○
	Horizontal Auto-Swing (Right and Left)	—	—		Self-Diagnosis (Digital, LED) Display	○	○
	3-D Airflow	—	—		Wiring Error Check	—	—
	Comfort Airflow Mode	○	○		Anticorrosion Treatment of Outdoor Heat Exchanger	○	○
Comfort Control	3-Step Airflow (H/P Only)	—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○
	Auto Fan Speed	○	○		Flexible Voltage Correspondence	—	—
	Indoor Unit Quiet Operation	○	○		High Ceiling Application	—	—
	Night Quiet Mode (Automatic)	—	—		Chargeless	10m	10m
	Outdoor Unit Quiet Operation	○	○		Either Side Drain (Right or Left)	○	○
	INTELLIGENT EYE	○	○		Power Selection	—	—
	Quick Warming Function	○	○		5-Rooms Centralized Controller (Option)	○	○
	Hot-Start Function	○	○		Remote Control Adaptor (Normal Open-Pulse Contact) (Option)	○	○
Operation	Automatic Defrosting	○	○	Remote Control	Remote Control Adaptor (Normal Open Contact) (Option)	○	○
	Automatic Operation	○	○		DIII-NET Compatible (Adaptor) (Option)	○	○
	Programme Dry Function	○	○		Wireless	○	○
Lifestyle Convenience	Fan Only	○	○	Remote Controller	Wired	—	—
	New POWERFUL Operation (Non-Inverter)	—	—				
	Inverter POWERFUL Operation	○	○				
	Priority-Room Setting	—	—				
	Cooling / Heating Mode Lock	—	—				
	HOME LEAVE Operation	—	—				
	ECONO Mode	○	○				
	Indoor Unit On/Off Switch	○	○				
	Signal Reception Indicator	○	○				
	Temperature Display	—	—				
	Another Room Operation	—	—				

Note: ○ : Holding Functions
— : No Functions

★ : Lower limit can be extended to −15°C by cutting jumper. (facility use only)

Part 2

Specifications

1. Specifications	4
-------------------------	---

1. Specifications

50Hz 220-230-240V

Model	Indoor Units		ATXS25EV1B7		ATXS35EV1B7	
	Outdoor Units		ARXS25F3V1B		ARXS35F3V1B	
			Cooling	Heating	Cooling	Heating
Capacity Rated (Min.~Max.)	kW	Btu/h	2.5 (1.2~3.0)	3.4 (1.2~4.5)	3.4 (1.2~3.8)	4.0 (1.2~5.0)
			8,500 (4,100~10,200)	11,600 (4,100~15,400)	11,600 (4,100~13,000)	13,600 (4,100~17,100)
			2,150 (1,030~2,580)	2,920 (1,030~3,870)	2,920 (1,030~3,270)	3,440 (1,030~4,300)
Moisture Removal	L/h		1.2	—	1.9	—
Running Current (Rated)	A		3.50-3.30-3.20	4.30-4.10-3.90	4.80-4.60-4.40	5.10-4.90-4.60
Power Consumption Rated (Min.~Max.)	W		600 (300~800)	830 (290~1,340)	1,000 (300~1,220)	1,080 (290~1,550)
Power Factor	%		77.9-79.1-78.1	87.7-88.0-88.7	94.7-94.5-94.7	96.3-95.8-97.8
COP Rated (Min.~Max.)	W/W		4.17 (4.00-3.75)	4.10 (4.14-3.36)	3.40 (4.00~3.11)	3.70 (4.14~3.23)
Piping Connections	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ 18.0		φ 18.0	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Max. Interunit Piping Length	m		20		20	
Max. Interunit Height Difference	m		15		15	
Chargeless	m		10		10	
Amount of Additional Charge of Refrigerant	g/m		20		20	
Indoor Unit			ATXS25EV1B7		ATXS35EV1B7	
Front Panel Color			White		White	
Airflow Rate	m³/min (cfm)	H	8.7 (307)	9.4 (332)	8.9 (314)	9.7 (342)
		M	6.7 (237)	7.6 (268)	6.9 (244)	7.9 (279)
		L	4.7 (166)	5.8 (205)	4.8 (169)	6.0 (212)
		SL	3.9 (138)	5.0 (177)	4.0 (141)	5.2 (184)
Fan	Type		Cross Flow Fan		Cross Flow Fan	
	Motor Output	W	40		40	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)	A		0.17-0.16-0.15	0.17-0.16-0.15	0.19-0.18-0.17	0.19-0.18-0.17
Power Consumption (Rated)	W		35	35	40	40
Power Factor	%		93.6-95.1-97.2	93.6-95.1-97.2	95.7-96.6-98.0	95.7-96.6-98.0
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)	mm		283x800x195		283x800x195	
Packaged Dimensions (HxWxD)	mm		265x855x340		265x855x340	
Weight	kg		9		9	
Gross Weight	kg		12		12	
Operation Sound	H/M/L/SL	dBA	38 / 32 / 25 / 22	38 / 33 / 28 / 25	39 / 33 / 26 / 23	39 / 34 / 29 / 26
Sound Power	H	dBA	56	56	57	57
Outdoor Unit			ARXS25F3V1B		ARXS35F3V1B	
Casing Color			Ivory White		Ivory White	
Compressor	Type		Hermetically Sealed Swing Type		Hermetically Sealed Swing Type	
	Model		1YC23NXD		1YC23NXD	
Refrigerant Oil	Motor Output	W	600		600	
	Model		FVC50K		FVC50K	
Refrigerant	Charge	L	0.375		0.375	
	Model		R-410A		R-410A	
Airflow Rate (H/L)	Charge	kg	1.0		1.00	
	m³/min		33.5 / 23.4	30.2 / 28.3	33.5 / 23.4	30.2 / 28.3
Fan	cfm		1,183 / 826	1,066 / 999	1,183 / 826	1,066 / 999
	Type		Propeller		Propeller	
Running Current (Rated)	Motor Output	W	23		23	
	A		3.33-3.14-3.05	4.13-3.94-3.75	4.61-4.42-4.23	4.91-4.72-4.43
Power Consumption (Rated)	W		565	795	960	1,040
Power Factor	%		77.1-78.2-77.2	87.5-87.7-88.3	94.7-94.4-94.6	96.3-95.8-97.8
Starting Current	A		4.3		5.1	
Dimensions (HxWxD)	mm		550x765x285		550x765x285	
Packaged Dimensions (HxWxD)	mm		612x906x364		612x906x364	
Weight	kg		34		34	
Gross Weight	kg		40		40	
Operation Sound	H/L	dBA	46 / 43	47 / 44	47 / 44	48 / 45
Sound Power	H	dBA	61	62	62	63
Drawing No.			3D059566		3D059569	

Note: ■ The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

50Hz 230V

Model	Indoor Units		ATXS50EV1B7	
	Outdoor Units		ARXS50E3V1B	
			Cooling	Heating
Capacity Rated (Min.~Max.)		kW	5.0 (2.0~5.2)	5.8 (2.0~6.0)
		Btu/h	17,100 (6,800~17,700)	19,800 (6,800~20,500)
		kcal/h	4,300 (1,720~4,470)	4,990 (1,720~5,160)
Moisture Removal		L/h	2.6	—
Running Current (Rated)		A	7.3	9.1
Power Consumption Rated (Min.~Max.)		W	1,650 (500~1,820)	2,060 (520~2,190)
Power Factor		%	98.3	98.4
COP Rated (Min.~Max.)		W/W	3.03 (4.00~2.86)	2.82 (3.85~2.74)
Piping Connections	Liquid	mm	φ 6.4	
	Gas	mm	φ12.7	
	Drain	mm	φ18.0	
Heat Insulation			Both Liquid and Gas Pipes	
Max. Interunit Piping Length		m	30	
Max. Interunit Height Difference		m	20	
Chargeless		m	10	
Amount of Additional Charge of Refrigerant		g/m	20	
Indoor Unit			ATXS50EV1B7	
Front Panel Color			White	
Airflow Rate	m³/min (cfm)	H	11.4 (402)	11.4 (402)
		M	9.3 (328)	9.4 (332)
		L	7.1 (251)	7.4 (261)
		SL	6.2 (219)	6.3 (222)
Fan	Type		Cross Flow Fan	
	Motor Output	W	40	
	Speed	Steps	5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.21	0.21
Power Consumption (Rated)		W	48	48
Power Factor		%	99.4	99.4
Temperature Control			Microcomputer Control	
Dimensions (HxWxD)		mm	283x800x195	
Packaged Dimensions (HxWxD)		mm	265x855x340	
Weight		kg	9	
Gross Weight		kg	12	
Operation Sound	H/M/L/SL	dBA	46/41/35/32	46/40/34/31
Sound Power	H	dBA	62	62
Outdoor Unit			ARXS50E3V1B	
Casing Color			Ivory White	
Compressor	Type		Hermetically Sealed Swing Type	
	Model		2YC36BXD	
Refrigerant Oil	Motor Output	W	1,100	
	Model		FVC50K	
Refrigerant	Charge	L	0.65	
	Model		R-410A	
Airflow Rate (HH/H/L)	Charge	kg	1.5	
	m³/min		50.9/48.9/41.7	—/45.0/45.0
Fan	cfm		1,798/1,727/1,473	—/1,589/1,589
	Type		Propeller	
Running Current (Rated)	Motor Output	W	53	
	A		7.09	
Power Consumption (Rated)		W	1,602	2,012
Power Factor		%	98.2	98.4
Starting Current		A	9.1	
Dimensions (HxWxD)		mm	735x825x300	
Packaged Dimensions (HxWxD)		mm	797x960x390	
Weight		kg	48	
Gross Weight		kg	53	
Operation Sound	H/L	dBA	47/44	48/45
Sound Power	H	dBA	61	62
Drawing No.			3D059571	

Note: ■ The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae
kcal/h=kW×860 Btu/h=kW×3414 cfm=m³/min×35.3

Part 3

Printed Circuit Board

Connector Wiring Diagram

1. Printed Circuit Board Connector Wiring Diagram.....	8
1.1 Indoor Unit.....	8
1.2 Outdoor Unit.....	10

1. Printed Circuit Board Connector Wiring Diagram

1.1 Indoor Unit

Connectors

PCB(1) (Control PCB)

- 1) **S1** Connector for DC fan motor
- 2) **S6** Connector for swing motor (horizontal blades)
- 3) **S21** Connector for [centralized control \(HA\)](#)
- 4) **S26** Connector for display PCB
- 5) **S28** Connector for signal receiver PCB
- 6) **S32** Connector for heat exchanger thermistor
- 7) **S35** Connector for INTELLIGENT EYE sensor PCB

PCB(2) (Signal Receiver PCB)

- 1) **S29** Connector for control PCB

PCB(3) (Display PCB)

- 1) **S27** Connector for control PCB

PCB(4) (INTELLIGENT EYE sensor PCB)

- 1) **S36** Connector for control PCB



Note:

Other designations

PCB(1) (Control PCB)


- 1) **V1** [Varistor](#)
- 2) **JA** [Address setting jumper](#)
- JB** [Fan speed setting](#) when compressor is OFF on thermostat
- JC** [Power failure recovery function \(auto-restart\)](#)
- * Refer to page 219 for detail.
- 3) **LED A** LED for service monitor (green)
- 4) **FU1** [Fuse](#) (3.15A)

PCB(3) (Display PCB)

- 1) **SW1 (S1W)** [Forced operation ON / OFF switch](#)
- 2) **LED1** LED for operation (green)
- 3) **LED2** LED for timer (yellow)
- 4) **LED3** LED for INTELLIGENT EYE (green)
- 5) **RTH1 (R1T)** Room temperature thermistor


PCB Detail

PCB(1): Control PCB




(R6039)

PCB(2): Signal Receiver PCB




(R5183)

PCB(3): Display PCB



(R4290)

PCB(4): INTELLIGENT EYE sensor PCB



(R4291)

1.2 Outdoor Unit

1.2.1 ARXS 25/35 F

Connectors

PCB (1) (Filter PCB)

- | | |
|---------------|---------------------------|
| 1) S11 | Connector for control PCB |
|---------------|---------------------------|

PCB (2) (Control PCB)

- | | |
|------------------------------|--|
| 1) S10 | Connector for filter PCB |
| 2) S20 | Connector for electronic expansion valve coil |
| 3) S30 | Connector for compressor motor |
| 4) S40 | Connector for overload protector |
| 5) S70 | Connector for fan motor |
| 6) S80 | Connector for four way valve coil |
| 7) S90 | Connector for thermistors
(outdoor air, heat exchanger, discharge pipe) |
| 8) HC3, HC4, HL3, HN3 | Connector for filter PCB |



Note:

Other designations

PCB (1) (Filter PCB)


- | | |
|------------------|------------|
| 1) FU3 | Fuse (20A) |
| 2) V2, V3 | Varistor |

PCB (2) (Control PCB)


- | | |
|--------------------|-----------------------------|
| 1) FU1, FU2 | Fuse (3.15A) |
| 2) LED A | Service monitor LED (green) |
| 3) V1 | Varistor |
| 4) J8 | Facility setting jumper |
- *Refer to page 46 for detail.

PCB Detail

PCB(1): Filter PCB



PCB(2): Control PCB (outdoor unit)



1.2.2 ARXS 50 E

Connectors

PCB(1)(Main PCB)

- | | |
|--------------|--|
| 1) S10 | Connector for terminal strip (indoor-outdoor transmission) |
| 2) S20 | Connector for electronic expansion valve coil |
| 3) S40 | Connector for overload protector |
| 4) S51, S101 | Connector for service monitor PCB |
| 5) S70 | Connector for fan motor |
| 6) S80 | Connector for four way valve coil |
| 7) S90 | Connector for thermistors
(outdoor air, heat exchanger, and discharge pipe) |
| 8) AC1, AC2 | Connector for terminal strip (power supply) |
| 9) HR1, HR2 | Connector for reactor |

PCB(2)(Service Monitor PCB)

- | | |
|--------------|---------------------------|
| 1) S52, S102 | Connector for control PCB |
|--------------|---------------------------|



Note:

Other Designations

PCB(1)(Main PCB)


- | | |
|------------------------|--------------|
| 1) FU1 | Fuse (30A) |
| 2) FU2, FU3 | Fuse (3.15A) |
| 3) V2, V3, V5, V6, V11 | Varistor |

PCB(2)(Service Monitor PCB)

- | | |
|----------|--------------------------------|
| 1) LED A | Service monitor LED (green) |
| 2) SW1 | Forced operation ON/OFF switch |
| 3) SW4 | Field setting switch |
- *Switch A: No function
- *Switch B: For the changeover of the lower limit for cooling.
(OFF: -10°C, ON: -15°C)
Refer to page 46 for detail.
- *Switch C: Powerful defrost operation (ON)


PCB Detail

PCB(1): iMain PCB



(R5201)

PCB(2): Service Monitor PCB



(R5203)

Part 4

Function and Control

1. Main Functions.....	16
1.1 Frequency Principle.....	16
1.2 Airflow Direction Control.....	18
1.3 Fan Speed Control for Indoor Units.....	19
1.4 Programme Dry Function	20
1.5 Automatic Operation.....	21
1.6 Thermostat Control.....	22
1.7 NIGHT SET Mode	23
1.8 ECONO Mode	24
1.9 INTELLIGENT EYE	25
1.10 Inverter POWERFUL Operation	27
1.11 Other Functions.....	28
2. Function of Thermistor	30
3. Control Specification	31
3.1 Mode Hierarchy	31
3.2 Frequency Control.....	32
3.3 Controls at Mode Changing / Start-up.....	34
3.4 Discharge Pipe Temperature Control.....	36
3.5 Input Current Control.....	37
3.6 Freeze-up Protection Control	38
3.7 Heating Peak-cut Control	38
3.8 Fan Control.....	39
3.9 Liquid Compression Protection Function 2.....	39
3.10 Defrost Control	40
3.11 Electronic Expansion Valve Control	41
3.12 Malfunctions	44
3.13 Forced Operation Mode	45
3.14 Additional Function.....	45
3.15 Facility Setting Jumper (cooling at low outdoor temperature)	46

1. Main Functions



Note: See the list of functions for the functions applicable to different models.

1.1 Frequency Principle

Main Control Parameters

The compressor is frequency-controlled during normal operation. The target frequency is set by the following 2 parameters coming from the operating indoor unit:

- The load condition of the operating indoor unit
- The difference between the room temperature and the set temperature

Additional Control Parameters

The target frequency is adapted by additional parameters in the following cases:

- Frequency restrictions
- Initial settings
- Forced cooling operation


Inverter Principle

To regulate the capacity, a frequency control is needed. The inverter makes it possible to vary the rotation speed of the compressor. The following table explains the conversion principle:

Phase	Description
1	The supplied AC power source is converted into the DC power source for the present.
2	<p>The DC power source is reconverted into the three phase AC power source with variable frequency.</p> <ul style="list-style-type: none"> ■ When the frequency increases, the rotation speed of the compressor increases resulting in an increased refrigerant circulation. This leads to a higher amount of the heat exchange per unit. ■ When the frequency decreases, the rotation speed of the compressor decreases resulting in a decreased refrigerant circulation. This leads to a lower amount of the heat exchange per unit.

Drawing of Inverter


The following drawing shows a schematic view of the inverter principle:



Inverter Features

The inverter provides the following features:

- The regulating capacity can be changed according to the changes in the outdoor air temperature and cooling / heating load.
- Quick heating and quick cooling
The compressor rotational speed is increased when starting the heating (or cooling). This enables a quick set temperature.



- Even during extreme cold weather, the high capacity is achieved. It is maintained even when the outdoor air temperature is 2°C.
- Comfortable air conditioning
A detailed adjustment is integrated to ensure a fixed room temperature. It is possible to air condition with a small room temperature variation.
- Energy saving heating and cooling
Once the set temperature is reached, the energy saving operation enables to maintain the room temperature at low power.

Frequency Limits

The following table shows the functions that define the minimum and maximum frequency:

Frequency limits	Limited during the activation of following functions
Low	<ul style="list-style-type: none"> ■ Four way valve operation compensation. Refer to page 35.
High	<ul style="list-style-type: none"> ■ Input current control. Refer to page 37. ■ Compressor protection function. Refer to page 35. ■ Heating peak-cut control. Refer to page 38. ■ Freeze-up protection control. Refer to page 38. ■ Defrost control. Refer to page 40.

Forced Cooling Operation

For more information, refer to "Forced operation mode" on page 45.

1.2 Airflow Direction Control

Power-Airflow Dual Flaps

The large flaps send a large volume of air downwards to the floor. The flap provides an optimum control area in cooling, heating and dry mode.

Heating Mode

During heating mode, the large flap enables direct warm air straight downwards. The flap presses the warm air above the floor to reach the entire room.

Cooling Mode





During cooling mode, the flap retracts into the indoor unit. Then, cool air can be blown far and pervaded all over the room.

Wide-Angle Louvres

The louvres, made of elastic synthetic resin, provide a wide range of airflow that guarantees a comfortable air distribution.

Auto-Swing



The following table explains the auto swing process for heating, cooling, dry and fan :

Vertical Swing (up and down)			Horizontal Swing (right and left: manual)
Cooling / Dry	Heating	Fan	
 (R4281)	 (R4282)	 (R4283)	 (R4284)

COMFORT AIRFLOW Mode

The vertical swing flap is controlled not to blow the air directly on the person in the room.

- The airflow rate is controlled automatically within the following steps.
Cooling: L tap – MH tap (same as AUTOMATIC)
Heating: ML tap – M tap
- The latest command has the priority between POWERFUL and COMFORT AIRFLOW.

Heating	Cooling
 (R4303)	 (R4302)

1.3 Fan Speed Control for Indoor Units

Control Mode



The airflow rate can be automatically controlled depending on the difference between the set temperature and the room temperature. This is done through phase control and Hall IC control.




For more information about Hall IC, refer to trouble shooting for fan motor on page 85.

Phase Steps

Phase control and fan speed control contains 9 steps: LLL, LL, SL, L, ML, M, MH, H and HH. In Automatic operation, the step "SL" is not available.

Step	Cooling	Heating	Dry mode
LLL	 (R5310)	 (R8356)	25 / 35 class : 670 - 880 rpm (During POWERFUL operation : 720 - 930 rpm) 50 class: 980 - 1090 rpm
LL			
L			
ML			
M			
MH			
H			
HH (POWERFUL)			

 = Within this range the airflow rate is automatically controlled when the FAN setting button is set to automatic.



Note:


1. During POWERFUL operation, fan rotates at H tap + 50 - 90 rpm.
2. Fan stops during defrost operation.
3. In time of thermostat OFF, the fan rotates at the following speed.
Cooling: The fan keeps rotating at the set tap.
Heating: 25/35 class: The fan stops.
50 class: The fan rotates at LLL tap.

Automatic Airflow control for heating

On heating mode, the indoor fan speed will be regulated according to the indoor heat exchanger temperature and the difference between the room temperature and the required set point.

Automatic Airflow control for cooling

The following drawing explains the principle of fan speed control for cooling:



1.4 Programme Dry Function


Programme dry function removes humidity while preventing the room temperature from lowering.

Since the microcomputer controls both the temperature and airflow volume, the temperature adjustment and fan adjustment buttons are inoperable in this mode.

In Case of Inverter Units

The microcomputer automatically sets the temperature and fan settings. The difference between the room temperature at startup and the temperature set by the microcomputer is divided into two zones. Then, the unit operates in the dry mode with an appropriate capacity for each zone to maintain the temperature and humidity at a comfortable level.

Room temperature at startup	Set temperature X	Thermostat OFF point Y	Thermostat ON point Z
24°C or more	Room temperature at startup	$X - 2.5^{\circ}\text{C}$	$X - 0.5^{\circ}\text{C}$ or $Y + 0.5^{\circ}\text{C}$ (zone B) continues for 10 min.
23.5°C ⋮ 18°C		$X - 2.0^{\circ}\text{C}$	$X - 0.5^{\circ}\text{C}$ or $Y + 0.5^{\circ}\text{C}$ (zone B) continues for 10 min.
17.5°C ⋮	18°C	$X - 2.0^{\circ}\text{C}$	$X - 0.5^{\circ}\text{C} = 17.5^{\circ}\text{C}$ or $Y + 0.5^{\circ}\text{C}$ (zone B) continues for 10 min.



(R6841)

1.5 Automatic Operation

Automatic Cooling / Heating Function (Heat Pump Only)

When the AUTO mode is selected with the remote controller, the microcomputer automatically determines the operation mode from cooling and heating according to the room temperature and setting temperature at the time of the operation startup, and automatically operates in that mode.

The unit automatically switches the operation mode to cooling or heating to maintain the room temperature at the main unit setting temperature.


Detailed Explanation of the Function

1. Remote controller setting temperature is set as automatic cooling / heating setting temperature (18 to 30°C).
2. Main unit setting temperature equals remote controller setting temperature.
3. Operation ON / OFF point and mode switching point are as follows.
 - ① Heating → Cooling switching point:
Room temperature \geq Main unit setting temperature +2.5 deg.
 - ② Cooling → Heating switching point:
Room temperature $<$ Main unit setting temperature -2.5 deg.
 - ③ Thermostat ON / OFF point is the same as the ON / OFF point of cooling or heating operation.

During initial operation

Room temperature \geq Remote controller setting temperature: Cooling operation

Room temperature $<$ Remote controller setting temperature: Heating operation



(R6842)

Ex: When the set point is 25°C

Cooling Operation → 23°C: Thermostat OFF → 22°C: Switch to Heating Operation

Heating Operation → 26.5°C: Thermostat OFF → 27.5°C: Switch to Cooling Operation

1.6 Thermostat Control

Thermostat control is based on the difference between the room temperature and the setpoint.


Thermostat OFF Condition

- ♦ The temperature difference is in the zone A.


Thermostat ON Condition

- ♦ The temperature difference is above the zone C after being in the zone A.
- ♦ The system resumes from defrost control in any zones except A.
- ♦ The operation turns on in any zones except A.
- ♦ The monitoring time has passed while the temperature difference is in the zone B.
(Cooling / Dry : 10 minutes, Heating : 10 seconds)

Cooling / Dry



Heating




1.7 NIGHT SET Mode

When the OFF timer is set, the NIGHT SET circuit automatically activates. The NIGHT SET circuit maintains the airflow setting made by users.


The NIGHT SET Circuit

The NIGHT SET circuit continues heating or cooling the room at the set temperature for the first one hour, then automatically raises the temperature setting slightly in the case of cooling, or lowers it slightly in the case of heating, for economical operations. This prevents excessive heating in winter and excessive cooling in summer to ensure comfortable sleeping conditions, and also conserves electricity.

Cooling Operation



Heating Operation



1.8 ECONO Mode


Outline

The "ECONO mode" reduces the maximum operating current and power consumption by approx. 30% during start up etc..

This mode is particularly convenient for energy-saving-oriented users. It is also a major bonus for those whose breaker capacities do not allow the use of multiple electrical devices and air conditioners.

It is easily activated from the wireless remote controller by pushing the ECONO button.

- When this function is ON, the maximum capacity is also down. (Approx. 20%)
- This function can only be set when the unit is running. Pressing the operation stop button causes the settings to be cancelled.
- This function and POWERFUL operation cannot be used at the same time. The latest command has the priority.



Details


- ECONO mode can be activated while the unit is running. The remote controller can send the ECONO command when the unit is in COOL, HEAT, DRY, or AUTO operation.
- When the ECONO command is valid, the input current is under reducing control. (Refer to "Input current control" on page 37.) Also, the upper limit of frequency is restricted.

1.9 INTELLIGENT EYE

This is the function that detects existence of humans in the room by a human motion sensor (INTELLIGENT EYE) and reduces the capacity when there is no human in the room in order to save electricity.


Processing

1. Detection method by INTELLIGENT EYE



- This sensor detects human motion by receiving infrared rays and displays the pulse wave output.
- A microcomputer in an indoor unit carries out a sampling every 20 msec. and if it detects 10 cycles of the wave in one second in total (corresponding to $20\text{msec.} \times 10 = 200\text{msec.}$), it judges human is in the room as the motion signal is ON.

2. The motions (for example: in cooling)



- When a microcomputer doesn't have a signal from the sensor in 20 minutes, it judges that nobody is in the room and operates the unit in temperature shifted 2°C from the set temperature. (Cooling / Dry : 2°C higher, Heating : 2°C lower and Auto : according to the operation mode at that time.)
- ★1 In case of FAN mode, the fan speed reduces by 50 rpm.

- Since the set temperature is shifted by 2°C higher for 40 minutes, compressor speed becomes low and can realize energy saving operation. But as thermostat is prone to be off by the fact that the set temperature has been shifted, the thermostat-off action is prohibited in 40 minutes so as to prevent this phenomena.
After this 40 minutes, the prohibition of the thermostat-off is cancelled and it can realize the conditions to conduct thermostat-off depending on the room temperature. In or after this 40 minutes, if the sensor detects human motion detection signal, it let the set temperature and the fan speed return to the original set point, keeping a normal operation.

Others

- The dry operation can't command the setting temperature with a remote controller, but internally the set temperature is shifted by 1°C.

1.10 Inverter POWERFUL Operation

Outline


In order to exploit the cooling and heating capacity to full extent, operate the air conditioner by increasing the indoor fan rotating speed and the compressor frequency.

Details of the Control

When POWERFUL button is pushed in each operation mode, the fan speed / setting temperature will be converted to the following states in a period of twenty minutes.

Operation mode	Fan speed		Target set temperature
	25/35 class	50class	
COOL	H tap + 50 rpm	H tap + 90 rpm	18°C
DRY	Dry rotating speed + 50 rpm	Dry rotating speed + 50 rpm	Normally targeted temperature in dry operation; Approx. -2°C
HEAT	H tap + 50 rpm	H tap + 90 rpm	30°C
FAN	H tap + 50 rpm	H tap + 90 rpm	—
AUTO	Same as cooling / heating in POWERFUL operation	Same as cooling / heating in POWERFUL operation	The target is kept unchanged

Ex.) : POWERFUL operation in cooling mode (25/35 class).



(R4606)

1.11 Other Functions

1.11.1 Hot-Start Function

Heat Pump Only

In order to prevent the cold air blast that normally comes when heating is started, the temperature of the heat exchanger of the indoor unit is detected, and either the airflow is stopped or is made very weak thereby carrying out comfortable heating of the room.

*The cold air blast is also prevented using a similar control when the defrosting operation is started or when the thermostat gets turned ON.


1.11.2 Signal Receiving Sign

When the indoor unit receives a signal from the remote controller, the unit emits a signal receiving sound.

1.11.3 ON/OFF Button on Indoor Unit

An ON/OFF button is provided on the front panel of the unit. Use this button when the remote controller is missing or if its battery has run out.

Every press of the button switches from ON to OFF or from OFF to ON.



- Push this button once to start operation. Push once again to stop it.
- This button is useful when the remote controller is missing.
- The operation mode refers to the following table.

	Mode	Temperature setting	Airflow rate
Heat Pump	AUTO	25°C	AUTO

- In the case of multi system operation, there are times when the unit does not activate with this button.

<Forced operation mode>

Forced operation mode will be set by pressing the ON/OFF button for between 5 to 9 sec. while the unit is not operating.



Note: When the ON/OFF button is pressed for 10 sec. or more, the operation will be stopped.

- See page 45 for the detail of "Forced Operation Mode".

1.11.4 Titanium Apatite Photocatalytic Air-Purifying Filter

This filter combines the Air Purifying Filter and Titanium Apatite Photocatalytic Deodorizing Filter in a single highly effective unit. The filter traps microscopic particles, decompose odours and even deactivates bacteria and viruses. It lasts for three years without replacement if washed about once every six months.

1.11.5 Mold Proof Air Filter

The air filter net is impregnated with a safe, odourless mould preventative to make the filter virtually immune to mould.


1.11.6 Self-Diagnosis Digital Display

The microcomputer continuously monitors main operating conditions of the indoor unit, outdoor unit and the entire system. When an abnormality occur, the LCD remote controller displays error code. These indications allow prompt maintenance operations.

1.11.7 Auto-restart Function

Even if a power failure (including one for just a moment) occurs during the operation, the operation restarts in the condition before power failure automatically when power is restored.
(Note) It takes 3 minutes to restart the operation because the 3-minute standby function is activated.

2. Function of Thermistor



A Outdoor Heat Exchanger Thermistor

1. The outdoor heat exchanger thermistor is used for controlling target discharge temperature. The system sets a target discharge temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The outdoor heat exchanger thermistor is used for detecting disconnection of the discharge thermistor when cooling.
When the discharge pipe temperature becomes lower than the outdoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.
3. The outdoor heat exchanger thermistor is used for high pressure protection during cooling operation.

B Discharge Pipe Thermistor

1. The discharge pipe thermistor is used for controlling temperature of the discharge pipe. If the temperature of discharge pipe (used in place of the inner temperature of the compressor) rises abnormally, the operating frequency drops or the operation halts.
2. The discharge pipe thermistor is used for detecting disconnection of the discharge thermistor.

C Indoor Heat Exchanger Thermistor

1. The indoor heat exchanger thermistor is used for controlling target discharge temperature. The system sets a target discharge temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The indoor heat exchanger thermistor is used for preventing freezing.
During the cooling operation, if the temperature drops abnormally, the operating frequency becomes lower, then the operation halts.
3. During heating, the indoor heat exchanger thermistor is used for detecting disconnection of the discharge pipe thermistor.
When the discharge pipe temperature becomes lower than the indoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.
The indoor heat exchanger thermistor is also used for preventing abnormal high pressure.

3. Control Specification

3.1 Mode Hierarchy


Outline

There are two modes; the mode selected in user's place (normal air conditioning mode) and forced operation mode for installation and providing service.

Detail

1. For heat pump model

There are following modes; stop, cooling (includes drying), heating (include defrosting)



(R2829)



Note:


Unless specified otherwise, an indoor dry operation command must be regarded as cooling operation.

3.2 Frequency Control

Outline

Frequency will be determined according to the difference between room and set temperature. The function is explained as follows.

1. How to determine frequency.
2. Frequency command from an indoor unit. (The difference between a room temperature and the temperature set by the remote controller.)
3. Frequency command from an indoor unit.
4. Frequency initial setting.
5. PI control.



(R2831)

Detail

How to Determine Frequency

The compressor's frequency will finally be determined by taking the following steps.

For Heat Pump Model

1. Determine command frequency

- ◆ Command frequency will be determined in the following order of priority.
 - 1.1 Limiting frequency by drooping function
 - ◆ Input current, discharge pipes, peak cutting, freeze-up protection, dew prevention, fin thermistor temperature.
 - 1.2 Limiting defrost control time
 - 1.3 Forced cooling
 - 1.4 Indoor frequency command

2. Determine upper limit frequency

- ◆ Set a minimum value as an upper limit frequency among the frequency upper limits of the following functions:
Compressor protection, input current, discharge pipes, peak cutting, freeze-up protection, defrost.

3. Determine lower limit frequency

- ◆ Set a maximum value as a lower limit frequency among the frequency lower limits of the following functions:
Four way valve operating compensation, draft prevention, pressure difference upkeep.

4. Determine prohibited frequency

- ◆ There is a certain prohibited frequency such as a power supply frequency.

Indoor Frequency Command (ΔD signal)

The difference between a room temperature and the temperature set by the remote controller will be taken as the " ΔD signal" and is used for frequency command.

Temperature difference	ΔD signal	Temperature difference	ΔD signal	Temperature difference	ΔD signal	Temperature difference	ΔD signal
0	*Th OFF	2.0	4	4.0	8	6.0	C
0.5	1	2.5	5	4.5	9	6.5	D
1.0	2	3.0	6	5.0	A	7.0	E
1.5	3	3.5	7	5.5	B	7.5	F

*Th OFF = Thermostat OFF

Frequency Initial Setting**<Outline>**

When starting the compressor, or when conditions are varied due to the change of the room, the frequency must be initialized according to the ΔD value of the indoor unit and the Q value of the indoor unit.

Q value: Indoor unit output determined from indoor unit volume, airflow rate and other factors.

PI Control (Determine Frequency Up / Down by ΔD Signal)**1. P control**

Calculate ΔD value in each sampling time (20 seconds), and adjust the frequency according to its difference from the frequency previously calculated.

2. I control

If the operating frequency is not change more than a certain fixed time, adjust the frequency up and down according to the ΔD value, obtaining the fixed ΔD value.

When the ΔD value is small...lower the frequency.

When the ΔD value is large...increase the frequency.

3. Frequency management when other controls are functioning

- ♦ When frequency is drooping;
Frequency management is carried out only when the frequency droops.
- ♦ For limiting lower limit
Frequency management is carried out only when the frequency rises.

4. Upper and lower limit of frequency by PI control

The frequency upper and lower limits are set depending on indoor unit.

When low noise commands come from the indoor unit or when outdoor unit low noise or quiet commands come from indoor unit, the upper limit frequency must be lowered than the usual setting.

5. Limit of frequency variation width (50 class only)

When the difference between input current and input current drooping value is less than 1.5 A, the frequency increase width must be limited.

3.3 Controls at Mode Changing / Start-up

3.3.1 Preheating Operation

Outline

■ 25/35 class

Operate the inverter in the open phase operation with the conditions including the preheating command from the discharge pipe temperature.

■ 50 class

Operate the inverter in the open phase operation with the conditions including the outdoor air temperature, discharge pipe temperature, and fin temperature (internal temperature of PM1).

Detail

■ 25/35 class

Preheating ON Condition

- ◆ When the discharge pipe temperature is below 10°C, inverter in open phase operation starts. (The power consumption of compressor during preheat operation is 35 W.)

OFF Condition

- ◆ When the discharge pipe temperature is higher than 12°C, inverter in open phase operation stops.

■ 50 class

Outside temperature $\geq 10^{\circ}\text{C}$ → Control A (preheating for normal state)

Outside temperature $< 10^{\circ}\text{C}$ → Control B (preheating of increased capacity)

Control A

- ◆ ON condition
 - Discharge pipe temperature $< 6^{\circ}\text{C}$
 - Fin temperature $< 85^{\circ}\text{C}$
- ◆ OFF condition
 - Discharge pipe temperature $> 8^{\circ}\text{C}$
 - Fin temperature $\geq 90^{\circ}\text{C}$

Control B

- ◆ ON condition
 - Discharge pipe temperature $< 10.5^{\circ}\text{C}$
 - Fin temperature $< 85^{\circ}\text{C}$
- ◆ OFF condition
 - Discharge pipe temperature $> 12^{\circ}\text{C}$
 - Fin temperature $\geq 90^{\circ}\text{C}$

3.3.2 Four Way Valve Switching

Outline

Heat Pump Only

During the heating operation current must be conducted and during cooling and defrosting current must not be conducted. In order to eliminate the switching sound (as the four way valve coil switches from ON to OFF) when the heating is stopped, the delay switch of the four way valve must be carried out after the operation stopped.

Detail

The OFF delay of four way valve

Energize the coil for about 160 sec after unit operation is stopped.

3.3.3 Four Way Valve Operation Compensation

Outline

Heat Pump Only

At the beginning of the operation as the four way valve is switched, acquire the differential pressure required for activating the four way valve by having output the operating frequency, which is more than a certain fixed frequency, for a certain fixed time.

Detail

Starting Conditions

■ 25/35 class

1. When starting compressor for heating.
2. When the operating mode changes to cooling from heating.
3. When starting compressor for rushing defrosting or resetting.
4. When starting compressor for the first time after the reset with the power is ON.
5. When starting compressor for heating next to the suspension of defrosting.
6. When starting compressor next to the fault of switching over cooling / heating.

Set the lower limit frequency (cooling : 68Hz, heating : 66Hz) for 45 seconds with any conditions 1 through 6 above.

■ 50 class

1. The MRC/W turns ON when the compressor starts for heating after the MRC/W has been OFF with compressor halted.
2. The MRC/W turns OFF when the compressor starts for cooling after the MRC/W has been ON with compressor running.
3. The compressor starts for the first time after reset.
4. The compressor starts after suspension caused by the trouble of cooling/heating changeover.

Set the lower limit frequency to 48 Hz for 70 seconds with any conditions 1 through 4 above.


3.3.4 3-minute Standby

Prohibit to turn ON the compressor for 3 minutes after turning it off.
(Except when defrosting. (Only for Heat Pump Model).)

3.3.5 Compressor Protection Function

When turning the compressor from OFF to ON, the upper limit of frequency must be set as follows. (The function must not be used when defrosting (only for heat pump model).)

	25/35 class	50 class
FCG 3	88	85
FCG 2	64	70
FCG 1	48	55
TCG 1	240	120
TCG 2	360	200
TCG 3	180	470




3.4 Discharge Pipe Temperature Control

Outline

The discharge pipe temperature is used as the compressor's internal temperature. If the discharge pipe temperature rises above a certain level, the operating frequency upper limit is set to keep this temperature from going up further.

Detail

Divide the Zone



	25/35 class	50 class
A	110	110
B	105	103
C	101	102
D	99	101
E	97	95

(R8340)

Management within the Zones

Zone	Control contents
Stop zone	When the temperature reaches the stop zone, stop the compressor and correct abnormality.
Drooping zone	Start the timer, and the frequency will be drooping.
Keep zone	Keep the upper limit of frequency.
Return / Reset zone	Cancel the upper limit of frequency.


3.5 Input Current Control

Outline

The microcomputer calculates the input current during the compressor is running, and set the frequency upper limit from such input current.

In case of heat pump model, this control is the upper limit control function of the frequency which takes priority of the lower limit of four way valve activating compensation.

Detail



Frequency control in each zone

Drooping zone

- ♦ The maximum limit of the compressor frequency in this control is defined as operation frequency – 2Hz.
- ♦ After this, the output frequency is pulled down by 2Hz every second until it reaches the steady zone.

Keep zone

- ♦ The present maximum frequency goes on.

Reset zone

- ♦ Limit of the frequency is cancelled.

Stop zone

- ♦ After 2.5 s in this zone, the compressor is stopped.

Cooling					Heating		
		25 class	35 class	50 class	25 class	35 class	50 class
I4 (A)		9.25		20.0	9.25		20.0
I3 (A)	Normal mode	6.0	7.25	10.0	7.5	8.25	15.0
	ECONO mode	4.25	5.0	7.0	5.25	5.75	10.5
I3-Iα (A)	Normal mode	5.25	6.5	9.0	6.75	7.5	14.0
	ECONO mode	3.5	4.25	6.0	4.5	5.0	9.5

Limitation of current drooping and stop value according to the outdoor air temperature

- In case the operation mode is cooling
 - ♦ The current droops when outdoor air temperature becomes higher than a certain level (model by model).
- In case the operation mode is heating (only for heat pump model)
 - ♦ The current droops when outdoor air temperature becomes higher than a certain level (model by model).

3.6 Freeze-up Protection Control

Outline


During cooling operation, the signals being sent from the indoor unit allow the operating frequency limitation and then prevent freezing of the indoor heat exchanger. (The signal from the indoor unit must be divided into the zones as the followings.

Detail

Conditions for Start Controlling

Judge the controlling start with the indoor heat exchanger temperature after 2 sec from operation start.

Control in Each Zone



3.7 Heating Peak-cut Control

Outline

Heat Pump Only

During heating operation, the signals being sent from the indoor unit allow the operating frequency limitation and prevent abnormal high pressure. (The signal from the indoor unit must be divided as follows.)

Detail


Conditions for Start Controlling

Judge the controlling start with the indoor heat exchanger temperature.


Control in Each Zone

The heat exchange intermediate temperature of indoor unit controls the following.

■ 25/35 class



■ 50 class



3.8 Fan Control

Outline

Fan control is carried out with following conditions.

■ 25/35 class

1. Fan control when defrosting
2. Fan OFF delay when stopped
3. ON/OFF control when cooling operation
4. Fan control when forced operation
5. Fan control in low noise mode
6. Fan control during heating operation
7. Fan control in the quiet mode
8. Fan control in the POWERFUL mode
9. Fan control for pressure difference upkeep

■ 50 class

1. Fan ON control for electric component cooling fan
2. Fan control when defrosting
3. Fan OFF delay when stopped
4. Fan control for maintaining pressure difference
5. Fan control when the compressor starts for heating
6. Fan control in forced operation
7. Fan control in POWERFUL mode
8. Fan control in low noise operation
9. Fan control in quiet mode

Detail

Fan OFF Control when Stopped

- Fan OFF delay for 60 seconds must be made when the compressor is stopped.

3.9 Liquid Compression Protection Function 2

Outline

In order to obtain the dependability of the compressor, the compressor must be stopped according to the conditions of the temperature of the outdoor air and outdoor heat exchanger.

Detail

- Operation stop depending on the outdoor air temperature
Compressor operation turns OFF under the conditions that the system is in cooling operation and outdoor air temperature is below -10°C .

3.10 Defrost Control

Outline

Heat Pump Only

Defrosting is carried out by the cooling cycle (reverse cycle). The defrosting time or outdoor heat exchanger temperature must be more than its fixed value when finishing.

Detail


Conditions for Starting Defrost

The starting conditions must be made with the outdoor air temperature and heat exchanger temperature. Under the conditions that the system is in heating operation, 6 minutes after the compressor is started and more than 28 minutes of accumulated time pass since the start of the operation or ending the defrosting.


Conditions for Cancelling Defrost

The judgment must be made with heat exchanger temperature. (25/35 class: 4°C-22°C, 50 class: 4°C-12°C)

■ 25/35 class



■ 50 class



3.11 Electronic Expansion Valve Control

Outline

The following items are included in the electronic expansion valve control.

Electronic expansion valve is fully closed

1. Electronic expansion valve is fully closed when turning on the power.
2. Pressure equalizing control

Open Control

1. Electronic expansion valve control when starting operation
2. Control when frequency changed
3. Control for defrosting (only for heat pump model)
4. Control when a discharge pipe temperature is abnormally high
5. Control when the discharge pipe thermistor is disconnected

Feedback Control

1. Discharge pipe temperature control

Detail

The followings are the examples of control which function in each mode by the electronic expansion valve control.

Operation pattern		Control when frequency changed	Control for abnormally high discharge pipe temperature
When power is turned ON ↓ Cooling operation ↓ Stop ↓ Heating operation (only for heat pump model) ↓ Stop ↓ Heating operation (only for heat pump model) ↓ Control of discharge pipe thermistor disconnection ↓ Stop			
		○ : function × : not function	
Fully closed when power is turned ON		×	×
Open control when starting		×	○
(Control of target discharge pipe temperature)		○	○
Pressure equalizing control		×	×
Open control when starting		×	○
(Control of target discharge pipe temperature)		○	○
(Defrost control FD=1) (only for heat pump model)		×	×
Pressure equalizing control		×	×
Open control when starting		×	○
Continue		×	×
Pressure equalizing control		×	×

(R2833)

3.11.1 Fully Closing with Power ON

Initialize the electronic expansion valve when turning on the power, set the opening position and develop pressure equalizing.

3.11.2 Pressure Equalization Control

When the compressor is stopped, open and close the electronic expansion valve and develop pressure equalization.

3.11.3 Opening Limit

Outline

Limit a maximum and minimum opening of the electronic expansion valve.

Detail

- ♦ A maximum electronic expansion valve opening : 480 pulses
 - ♦ A minimum electronic expansion valve opening : 52 pulses (25/35 class), 54 pulses (50 class)
- The electronic expansion valve is fully closed in the room where cooling is stopped and is opened with fixed opening during defrosting.

3.11.4 Starting Operation Control

Control the electronic expansion valve opening when the system is starting, and prevent the system to be super heated or moistened.

3.11.5 High Temperature of the Discharge Pipe

When the compressor is operating, if the discharge pipe temperature exceeds a certain value, open the electronic expansion valve and remove the refrigerant to the low pressure side and lower discharge temperature.

3.11.6 Disconnection of the Discharge Pipe Thermistor

Outline

Disconnection of the discharge pipe thermistor is detected by comparing the discharge pipe temperature with the heat exchanger temperature. If any is disconnected, open the electronic expansion valve according to the outdoor air temperature and the operating frequency, and operate for 9 minutes, and then stop.

After 3 minutes of waiting, the compressor restarts and the same process is carried out again. If the disconnection is detected 5 times (25/35 class) or 4 times (50 class) in succession, then the system will be down.

When the compressor runs for 60 minutes without any error, the error counter will reset itself.

Detail

Detect Disconnection

When the timer for open control (25/35 class : 810 sec., 50 class : 630 sec.) is over, and the 9-minute timer for the compressor operation continuation is not counting time, the following adjustment must be made.


1. When the operation mode is cooling
When the following condition is fulfilled, the discharge pipe thermistor disconnection is ascertained.
Discharge pipe temperature $+6^{\circ}\text{C} < \text{outdoor heat exchanger temperature}$
2. When the operation mode is heating
When the following condition is fulfilled, the discharge pipe thermistor disconnection is ascertained.
Discharge pipe temperature $+6^{\circ}\text{C} < \text{indoor heat exchanger temperature}$

3.11.7 Control when frequency is changed

When the target discharge pipe temperature control is active, if the target frequency is changed for a specified value in a certain time period, cancel the target discharge pipe temperature control and change the target opening of the electronic expansion valve according to the shift.

3.11.8 Target Discharge Pipe Temperature Control

Obtain the target discharge pipe temperature from the indoor and outdoor heat exchanger temperature, and adjust the electronic expansion valve opening so that the actual discharge pipe temperature become close to that temperature. (Indirect SH control using the discharge pipe temperature)



(R1389)

Determine a correction value of the electronic expansion valve compensation and drive it according to the deflection of the target discharge temperature and actual discharge temperature, and the discharge temperature variation by the 20 sec.

3.12 Malfunctions

3.12.1 Sensor Malfunction Detection

Sensor malfunction may occur in the thermistor.

Relating to Thermistor Malfunction

1. Outdoor heat exchanger thermistor
2. Discharge pipe thermistor
3. Fin thermistor
4. Outdoor air thermistor

3.12.2 Detection of Overload and Over Current

Outline

In order to protect the inverter, detect an excessive output current, and for protecting compressor, monitor the OL operation.

Detail

- ♦ If the OL (compressor head) temperature exceeds 120~130°C (depending on the model), the compressor gets interrupted.
- ♦ If the inverter current exceeds 22 A (25/35 class) or 30 A (50 class), the compressor gets interrupted too.

3.12.3 Insufficient Gas Control


Outline

There are three ways of control to detect insufficient gas.

I Detecting by power consumption


If the power consumption is below the specified value and the frequency is higher than the 55 Hz (depending on the model), it is regarded as insufficient gas.

The power consumption is weak comparing with that in the normal operation when gas is insufficient, and gas insufficiency is detected by checking a power consumption.



II Detecting by discharge pipe temperature

If the discharge temperature is higher than the target discharge pipe temperature, and the electronic expansion valve is fully open more than the specified time, it is regarded as insufficient gas.



III Detecting by the difference of temperature

If the difference between inhale and exhale temperature is smaller than the specified value, it is regarded as insufficient gas.



Refer to "Insufficient Gas" on page 122 for details.

3.13 Forced Operation Mode

Outline Forced operating mode includes only forced cooling.

Detail

Forced Cooling

Item	Forced Cooling
Forced operation allowing conditions	1) The outdoor unit is not abnormal and not in the 3-minute stand-by mode.
	2) The operating mode of the outdoor unit is the stop mode.
	3) The forced operation is ON. The forced operation is allowed when the above "and" conditions are met.
Starting/adjustment	If the forced operation switch is pressed as the above conditions are met.
1) Command frequency	25/35 class: 68 Hz 50 class: 66 Hz
2) Electronic expansion valve opening	It depends on the capacity of the indoor unit.
3) Outdoor unit adjustment	Compressor is in operation.
4) Indoor unit adjustment	The command of forced operation is transmitted to the indoor unit.
End	1) When the forced operation switch is pressed again.
	2) The operation is to end automatically after 15 min.
Others	The protect functions are prior to all others in the forced operation.

3.14 Additional Function

3.14.1 POWERFUL Operation Mode

Compressor operating frequency is increased to PI Max. (Max. Hz of operating room) and outdoor unit airflow rate is increased.

3.14.2 Voltage Detection Function

Power supply voltage is detected each time equipment operation starts.

3.15 Facility Setting Jumper (cooling at low outdoor temperature)


Outline

This function is limited only for facilities (the target of air conditioning is equipment (such as computer)). Never use it in a residence or office (the space where there is a human).

Detail


■ 25/35 class

You can expand the operation range to -15°C by cutting jumper 8 (J8) on the PCB. If the outdoor temperature falls to -20°C or lower, the operation will stop. If the outdoor temperature rises, the operation will start again.



■ 50 class

You can expand the operation range to -15°C by turning on switch B (SW4) on the PCB. If the outdoor temperature falls to -20°C or lower, the operation will stop. If the outdoor temperature rises, the operation will start again.



(R5209)



Caution

1. If the outdoor unit is installed where the heat exchanger of the unit is exposed to direct wind, provide a windbreak wall.
2. Intermittent noises may be produced by the indoor unit due to the outdoor fan turning on and off when using facility settings.
3. Do not place humidifiers or other items which might raise the humidity in rooms where facility settings are being used.
A humidifier might cause dew jumping from the indoor unit outlet vent.
4. Cutting jumper 8 (J8) sets the indoor fan tap to the highest position. Notify the user about this. (25/35 class)
5. Use the indoor unit at the highest level of airflow rate. (50 class)

Part 5

Operation Manual

1. System Configuration.....	48
2. Instruction.....	49
2.1 Safety precautions.....	49
2.2 Name of Parts	51
2.3 Preparation Before Operation	54
2.4 AUTO · DRY · COOL · HEAT · FAN Operation	57
2.5 Adjusting the Airflow Direction.....	59
2.6 POWERFUL Operation	61
2.7 OUTDOOR UNIT QUIET Operation.....	62
2.8 ECONO Operation	63
2.9 INTELLIGENT EYE Operation	64
2.10 TIMER Operation	66
2.11 Care and Cleaning	68
2.12 Troubleshooting.....	71

1. System Configuration

After the installation and test operation of the room air conditioner have been completed, it should be operated and handled as described below. Every user would like to know the correct method of operation of the room air conditioner, to check if it is capable of cooling (or heating) well, and to know a clever method of using it.

In order to meet this expectation of the users, giving sufficient explanations taking enough time can be said to reduce about 80% of the requests for servicing. However good the installation work is and however good the functions are, the customer may blame either the room air conditioner or its installation work because of improper handling. The installation work and handing over of the unit can only be considered to have been completed when its handling has been explained to the user without using technical terms but giving full knowledge of the equipment.

2. Instruction

2.1 Safety precautions

Safety precautions

- Keep this manual where the operator can easily find them.
- Read this manual attentively before starting up the unit.
- For safety reason the operator must read the following cautions carefully.
- This manual classifies precautions into WARNING and CAUTION. Be sure to follow all precautions below: they are all important for ensuring safety.



WARNING

If you do not follow these instructions exactly, the unit may cause property damage, personal injury or loss of life.



CAUTION

If you do not follow these instructions exactly, the unit may cause minor or moderate property damage or personal injury.



Never do.



Be sure to earth the air conditioner.



Never touch the air conditioner (including the remote controller) with a wet hand.



Be sure to follow the instructions.



Never cause the air conditioner (including the remote controller) to get wet.



WARNING

- In order to avoid fire, explosion or injury, do not operate the unit when harmful, among which flammable or corrosive gases, are detected near the unit.
- It is not good for health to expose your body to the air flow for a long time.
- Do not put a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury.
- Do not attempt to repair, relocate, modify or reinstall the air conditioner by yourself. Incorrect work will cause electric shocks, fire etc.
For repairs and reinstallation, consult your Daikin dealer for advice and information.



- The refrigerant used in the air conditioner is safe. Although leaks should not occur, if for some reason any refrigerant happens to leak into the room, make sure it does not come in contact with any flame as of gas heaters, kerosene heaters or gas range.
- If the air conditioner is not cooling (heating) properly, the refrigerant may be leaking, so call your dealer. When carrying out repairs accompanying adding refrigerant, check the content of the repairs with our service staff.
- Do not attempt to install the air conditioner by your self. Incorrect work will result in water leakage, electric shocks or fire. For installation, consult the dealer or a qualified technician.
- In order to avoid electric shock, fire or injury, if you detect any abnormally such as smell of fire, stop the operation and turn off the breaker. And call your dealer for instructions.
- Depending on the environment, an earth leakage breaker must be installed. Lack of an earth leakage breaker may result in electric shocks or fire.



- The air conditioner must be earthed. Incomplete earthing may result in electric shocks. Do not connect the earth line to a gas pipe, water pipe, lightning rod, or a telephone earth line.



CAUTION

- In order to avoid any quality deterioration, do not use the unit for cooling precision instruments, food, plants, animals or works of art.
- Never expose little children, plants or animals directly to the air flow.
- Do not place appliances which produce open fire in places exposed to the air flow from the unit or under the indoor unit. It may cause incomplete combustion or deformation of the unit due to the heat.



- Do not block air inlets nor outlets. Impaired air flow may result in insufficient performance or trouble.
- Do not stand or sit on the outdoor unit. Do not place any object on the unit to avoid injury, do not remove the fan guard.
- Do not place anything under the indoor or outdoor unit that must be kept away from moisture. In certain conditions, moisture in the air may condense and drip.
- After a long use, check the unit stand and fittings for damage.
- Do not touch the air inlet and aluminum fins of outdoor unit. It may cause injury.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the appliance.

- To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the air conditioner.
- Before cleaning, be sure to stop the operation, turn the breaker off or pull out the supply cord.
- Do not connect the air conditioner to a power supply different from the one as specified. It may cause trouble or fire.
- Arrange the drain hose to ensure smooth drainage. Incomplete draining may cause wetting of the building, furniture etc.
- Do not place objects in direct proximity of the outdoor unit and do not let leaves and other debris accumulate around the unit.
Leaves are a hotbed for small animals which can enter the unit. Once in the unit, such animals can cause malfunctions, smoke or fire when making contact with electrical parts.



- Do not operate the air conditioner with wet hands.



- Do not wash the indoor unit with excessive water, only use a slightly wet cloth.
- Do not place things such as vessels containing water or anything else on top of the unit. Water may penetrate into the unit and degrade electrical insulations, resulting in an electric shock.



Installation site.

- To install the air conditioner in the following types of environments, consult the dealer.
 - Places with an oily ambient or where steam or soot occurs.
 - Salty environment such as coastal areas.
 - Places where sulfide gas occurs such as hot springs.
 - Places where snow may block the outdoor unit.

The drain from the outdoor unit must be discharged to a place of good drainage.

Consider nuisance to your neighbours from noises.

- For installation, choose a place as described below.
 - A place solid enough to bear the weight of the unit which does not amplify the operation noise or vibration.
 - A place from where the air discharged from the outdoor unit or the operation noise will not annoy your neighbours.

Electrical work.

- For power supply, be sure to use a separate power circuit dedicated to the air conditioner.


System relocation.

- Relocating the air conditioner requires specialized knowledge and skills. Please consult the dealer if relocation is necessary for moving or remodeling.


2.2 Name of Parts

Names of parts

■ Indoor Unit



■ Outdoor Unit



■ Indoor Unit

1. Air filter

2. Titanium Apatite Photocatalytic Air-Purifying Filter:

- These filters are attached to the inside of the air filters.

3. Air inlet

4. Front panel

5. Panel tab

6. Room temperature sensor:

- It senses the air temperature around the unit.

7. INTELLIGENT EYE sensor:

- It detects the movements of people and automatically switches between normal operation and energy saving operation. (page 17.)

8. Display

9. Air outlet

10. Flaps (horizontal blades): (page 12.)

11. Louvers (vertical blades):

- The louvers are inside of the air outlet. (page 12.)

12. Indoor Unit ON/OFF switch: (page 10.)

- Push this switch once to start operation. Push once again to stop it.
- The operation mode refers to the following table.

	Mode	Temperature setting	Airflow rate
ATKS	COOL	22°C	AUTO
ATXS	AUTO	25°C	AUTO

- This switch is useful when the remote controller is missing.

13. Operation lamp (green)

14. TIMER lamp (yellow): (page 19.)

15. INTELLIGENT EYE lamp (green): (page 17.)

16. Signal receiver:

- It receives signals from the remote controller.
- When the unit receives a signal, you will hear a short beep.
 - Operation startbeep-beep
 - Settings changed.....beep
 - Operation stopbeeeeee

■ Outdoor Unit

17. Air inlet: (Back and side)

18. Air outlet

19. Refrigerant piping and inter-unit cable

20. Drain hose

21. Earth terminal:


- It is inside of this cover.

22. Outside air temperature sensor: (Back side)

- It senses the ambient temperature around the unit.

Appearance of the outdoor unit may differ from some models. (The illustration shows a 20-35 class unit.)

■ Remote Controller



<ARC433B61, 62>


- 1. Signal transmitter:**
 - It sends signals to the indoor unit.
- 2. Display:**
 - It displays the current settings.
(In this illustration, each section is shown with all its displays ON for the purpose of explanation.)
- 3. ECONO button:**
ECONO operation (page 16.)
- 4. POWERFUL button:**
POWERFUL operation (page 14.)
- 5. TEMPERATURE adjustment buttons:**
 - It changes the temperature setting.
- 6. ON/OFF button:**
 - Press this button once to start operation.
Press once again to stop it.
- 7. MODE selector button:**
 - It selects the operation mode.
(AUTO/DRY/COOL/HEAT/FAN) (page 10.)
- 8. QUIET button:** OUTDOOR UNIT QUIET operation (page 15.)
- 9. FAN setting button:**
 - It selects the airflow rate setting.
- 10. SWING button:**
 - Adjusting the Airflow Direction. (page 12.)
- 11. COMFORT AIRFLOW button:** COMFORT AIRFLOW operation (page 13.)
- 12. SENSOR button:** INTELLIGENT EYE operation (page 17.)
- 13. ON TIMER button:** (page 20.)
- 14. OFF TIMER button:** (page 19.)
- 15. TIMER Setting button:**
 - It changes the time setting.
- 16. TIMER CANCEL button:**
 - It cancels the timer setting.
- 17. CLOCK button:** (page 9.)
- 18. RESET button:**
 - Restart the unit if it freezes.
 - Use a thin object to push.

2.3 Preparation Before Operation

Preparation Before Operation

■ To set the batteries

1. Slide the front cover to take it off.
2. Set two dry batteries (LR03-AAA).
3. Set the front cover as before.



ATTENTION


■ About batteries

- When replacing the batteries, use batteries of the same type, and replace the two old batteries together.
- When the system is not used for a long time, take the batteries out.
- The batteries will last for approximately one year. If the remote controller display begins to fade and the degradation of reception performance occurs within a year, however, replace both two batteries with new size AAA alkaline batteries.
- The attached batteries are provided for the initial use of the system.
The usable period of the batteries may be short depending on the manufactured date of the air conditioner.

Preparation Before Operation


■ To operate the remote controller

- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- Do not drop the remote controller. Do not get it wet.
- The maximum distance for communication is about 7m.



■ To fix the remote controller holder on the wall

1. Choose a place from where the signals reach the unit.
2. Fix the holder to a wall, a pillar, or similar location with the screws procured locally.
3. Place the remote controller in the remote controller holder.



- To remove, pull it upwards.

ATTENTION

■ About remote controller

- Never expose the remote controller to direct sunlight.
- Dust on the signal transmitter or receiver will reduce the sensitivity. Wipe off dust with soft cloth.
- Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
- If the remote controller signals happen to operate another appliance, move that appliance to somewhere else, or consult the shop.

■ To set the clock

1. Press “**CLOCK** button”.

0:00 is displayed.

⌚ blinks.

2. Press “**TIMER** setting button” to set the clock to the present time.


Holding down “▲” or “▼” button rapidly increases or decreases the time display.

3. Press “**CLOCK** button”.

⌚ blinks.

■ Turn the breaker ON

- Turning ON the breaker opens the flap, then closes it again. (This is a normal procedure.)



NOTE

■ Tips for saving energy

- Be careful not to cool (heat) the room too much. Keeping the temperature setting at a moderate level helps save energy.
- Cover windows with a blind or a curtain. Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every two weeks.

Recommended temperature setting

For cooling: 26°C – 28°C
For heating: 20°C – 24°C

■ Please note

- The air conditioner always consumes 15-35 watts of electricity even while it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker OFF.
- Use the air conditioner in the following conditions.

Mode	Operating conditions	If operation is continued out of this range
COOL	Outdoor temperature: (2AMK(X)40/50) 10 to 46°C (2AMK(X)S40) 10 to 46°C (2AMX52) –10 to 46°C (3AMX) –10 to 46°C (ARK(X)S) –10 to 46°C Indoor temperature: 18 to 32°C Indoor humidity: 80% max.	<ul style="list-style-type: none"> • A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the outdoor unit only.) • Condensation may occur on the indoor unit and drip.
HEAT	Outdoor temperature: (2AMX(S)40) –10 to 15.5°C (2AMX52) –15 to 15.5°C (3AMX) –15 to 15.5°C (ARXS20/25/35) –15 to 20°C (ARXS50) –15 to 18°C Indoor temperature: 10 to 30°C	<ul style="list-style-type: none"> • A safety device may work to stop the operation.
DRY	Outdoor temperature: (2AMK(X)40/50) 10 to 46°C (2AMK(X)S40) 10 to 46°C (2AMX52) –10 to 46°C (3AMX) –10 to 46°C (ARK(X)S) –10 to 46°C Indoor temperature: 18 to 32°C Indoor humidity: 80% max.	<ul style="list-style-type: none"> • A safety device may work to stop the operation. • Condensation may occur on the indoor unit and drip.

- Operation outside this humidity or temperature range may cause a safety device to disable the system.

2.4 AUTO · DRY · COOL · HEAT · FAN Operation

AUTO · DRY · COOL · HEAT · FAN Operation

The air conditioner operates with the operation mode of your choice.

From the next time on, the air conditioner will operate with the same operation mode.

■ To start operation


1. Press “MODE selector button” and select a operation mode.

- Each pressing of the button advances the mode setting in sequence.



 : AUTO

 : DRY

 : COOL


 : HEAT

 : FAN



2. Press “ON/OFF button” .

- The OPERATION lamp lights up.




■ To stop operation

3. Press “ON/OFF button” again.

- Then OPERATION lamp goes off.






■ To change the temperature setting

4. Press “TEMPERATURE adjustment button”.


DRY or FAN mode	AUTO or COOL or HEAT mode
The temperature setting is not variable.	Press “▲” to raise the temperature and press “▼” to lower the temperature.
	Set to the temperature you like. 

■ To change the airflow rate setting

5. Press “FAN setting button”.

DRY mode	AUTO or COOL or HEAT or FAN mode
The airflow rate setting is not variable.	<p>Five levels of airflow rate setting from “” to “” plus “” “” are available.</p> 

- Indoor unit quiet operation

When the airflow is set to “”, the noise from the indoor unit will become quieter.
Use this when making the noise quieter.

NOTE

■ Note on HEAT operation

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.
- The heat pump system heats the room by circulating hot air around all parts of the room. After the start of heating operation, it takes some time before the room gets warmer.
- In heating operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.

■ Note on COOL operation

- This air conditioner cools the room by blowing the hot air in the room outside, so if the outside temperature is high, the performance of the air conditioner drops.

■ Note on DRY operation

- The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and airflow rate, so manual adjustment of these functions is unavailable.

■ Note on AUTO operation

- In AUTO operation, the system selects an appropriate operation mode (COOL or HEAT) based on the room temperature at the start of the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.
- If you do not like AUTO operation, manually change the set temperature.

■ Note on airflow rate setting

- At smaller airflow rates, the cooling (heating) effect is also smaller.


2.5 Adjusting the Airflow Direction

Adjusting the Airflow Direction


You can adjust the airflow direction to increase your comfort.


■ To adjust the horizontal blades (flaps)

1. Press “SWING button”.

- “” is displayed on the LCD and the flaps will begin to swing.

2. When the flaps have reached the desired position, press “SWING button” once more.

- The flaps will stop moving.
- “” disappears from the LCD.




■ To adjust the vertical blades (louvers)

Hold the knob and move the louvers.

(You will find a knob on the left-side and the right-side blades.)


- When the unit is installed in the corner of a room, the direction of the louvers should be facing away from the wall.

If they face the wall, the wall will block off the wind, causing the cooling (or heating) efficiency to drop.




■ To start COMFORT AIRFLOW operation

3. Press “COMFORT AIRFLOW button”.

- The flap position will change, preventing air from blowing directly on the occupants of the room.
 - “” is displayed on the LCD.
- 〈COOL/DRY〉 The flap will go up.
- 〈HEAT〉 The flap will go down.

■ To cancel COMFORT AIRFLOW operation

4. Press “COMFORT AIRFLOW button” again.

- The flaps will return to the memory position from before COMFORT AIRFLOW mode.
- “” disappears from the LCD.

Notes on COMFORT AIRFLOW operation


- POWERFUL operation and COMFORT AIRFLOW operation cannot be used at the same time. Priority is given to POWERFUL operation.

Notes on flaps and louvers angles

- When “SWING button” is selected, the flaps swinging range depends on the operation mode. (See the figure.)

■ ATTENTION

- Always use a remote controller to adjust the flaps angle. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Be careful when adjusting the louvers. Inside the air outlet, a fan is rotating at a high speed.




2.6 POWERFUL Operation

POWERFUL Operation

POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity .

■ To start POWERFUL operation


1. Press “POWERFUL button”.

- POWERFUL operation ends in 20minutes. Then the system automatically operates again with the previous settings which were used before POWERFUL operation.
- “” is displayed on the LCD.
- When using POWERFUL operation, there are some functions which are not available.

■ To cancel POWERFUL operation


2. Press “POWERFUL button” again.

- “” disappears from the LCD.



NOTE

■ Notes on POWERFUL operation

- POWERFUL Operation cannot be used together with ECONO, QUIET, or COMFORT Operation. Priority is given to the function of whichever button is pressed last.
- POWERFUL Operation can only be set when the unit is running. Pressing the operation stop button causes the settings to be canceled, and the “” disappears from the LCD.
- **In COOL and HEAT mode**
To maximize the cooling (heating) effect, the capacity of outdoor unit must be increased and the airflow rate be fixed to the maximum setting.
The temperature and airflow settings are not variable.
- **In DRY mode**
The temperature setting is lowered by 2.5°C and the airflow rate is slightly increased.
- **In FAN mode**
The airflow rate is fixed to the maximum setting.

2.7 OUTDOOR UNIT QUIET Operation

OUTDOOR UNIT QUIET Operation

OUTDOOR UNIT QUIET operation lowers the noise level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during night.

■ To start OUTDOOR UNIT QUIET operation


1. Press “QUIET button”.

- “” is displayed on the LCD.

■ To cancel OUTDOOR UNIT QUIET operation

2. Press “QUIET button” again.

- “” disappears from the LCD.



NOTE

■ Note on OUTDOOR UNIT QUIET operation

- This function is available in COOL, HEAT, and AUTO modes.
(This is not available in FAN and DRY mode.)
- POWERFUL operation and OUTDOOR UNIT QUIET operation cannot be used at the same time.
Priority is given to the function of whichever button is pressed last.

2.8 ECONO Operation

ECONO Operation

ECONO operation is a function which enables efficient operation by lowering the maximum power consumption value.

■ To start ECONO operation


1. Press “ECONO button” .

- “” is displayed on the LCD.


■ To cancel ECONO operation

2. Press “ECONO button” again.

- “” disappears from the LCD.



NOTE

- ECONO Operation can only be set when the unit is running. Pressing the operation stop button causes the settings to be canceled, and the “” disappears from the LCD.
- ECONO operation is a function which enables efficient operation by limiting the power consumption of the outdoor unit (operating frequency).
- ECONO operation functions in AUTO, COOL, DRY, and HEAT modes.
- POWERFUL operation and ECONO operation cannot be used at the same time. Priority is given to the function of whichever button is pressed last.
- Power consumption may not drop even if ECONO operation is used, when the level of power consumption is already low.

2.9 INTELLIGENT EYE Operation

INTELLIGENT EYE Operation

“INTELLIGENT EYE” is the infrared sensor which detects the human movement.



■ To start INTELLIGENT EYE operation

1. Press “SENSOR button”.
 - “” is displayed on the LCD.

■ To cancel the INTELLIGENT EYE operation

2. Press “SENSOR button” again.
 - “” disappears from the LCD.

[EX.]



INTELLIGENT EYE Operation


“INTELLIGENT EYE” is useful for Energy Saving

■ Energy saving operation

- Change the temperature -2°C in heating / $+2^{\circ}\text{C}$ in cooling / $+2^{\circ}\text{C}$ in dry mode from set temperature.
- Decrease the airflow rate slightly in fan operation. (In FAN mode only)

Notes on “INTELLIGENT EYE”

- Application range is as follows.



- Sensor may not detect moving objects further than 7m away. (Check the application range)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during powerful operation.
- Night set mode (page 19.) will not go on during you use INTELLIGENT EYE operation.

⚠ CAUTION

- Do not place large objects near the sensor.
Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect objects it shouldn't as well as not detect objects it should.
- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

2.10 TIMER Operation

TIMER Operation

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

■ To use OFF TIMER operation

- Check that the clock is correct.
If not, set the clock to the present time.
(page 9.)

1. Press “OFF TIMER button”.

0:00 is displayed.



⊕-○ blinks.

2. Press “TIMER Setting button” until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by 10 minutes.
Holding down either button changes the setting rapidly.

3. Press “OFF TIMER button” again.

- The TIMER lamp lights up.



■ To cancel the OFF TIMER operation

4. Press “CANCEL button”.

- The TIMER lamp goes off.

NOTE

- When TIMER is set, the present time is not displayed.
- Once you set ON, OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote controller batteries are replaced.)
- When operating the unit via the ON/OFF Timer, the actual length of operation may vary from the time entered by the user.

■ NIGHT SET MODE

When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

TIMER Operation

■ To use ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time.
(page 9.)

1. Press “ON TIMER button”.

6:00 is displayed.



⊕·| blinks.

2. Press “TIMER Setting button” until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

3. Press “ON TIMER button” again.

- The TIMER lamp lights up.




■ To cancel ON TIMER operation

4. Press “CANCEL button”.

- The TIMER lamp goes off.

■ To combine ON TIMER and OFF TIMER

- A sample setting for combining the two timers is shown below.



ATTENTION

■ In the following cases, set the timer again.

- After a breaker has turned OFF.
- After a power failure.
- After replacing batteries in the remote controller.

2.11 Care and Cleaning

Care and Cleaning



CAUTION Before cleaning, be sure to stop the operation and turn the breaker OFF.

Units


■ Indoor unit, Outdoor unit and Remote controller

1. Wipe them with dry soft cloth.

■ Front panel


1. Open the front panel.

- Hold the panel by the tabs on the two sides and lift it until it stops with a click.



2. Remove the front panel.

- Lift the front panel up, slide it slightly to the right, and remove it from the horizontal axle.




3. Clean the front panel.

- Wipe it with a soft cloth soaked in water.
- Only neutral detergent may be used.
- In case of washing the panel with water, dry it with cloth, dry it up in the shade after washing.

4. Attach the front panel.

- Set the 2 keys of the front panel into the slots and push them in all the way.
- Close the front panel slowly and push the panel at the 3 points.
(1 on each side and 1 in the middle.)



CAUTION


- Don't touch the metal parts of the indoor unit. If you touch those parts, this may cause an injury.
- When removing or attaching the front panel, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front panel, support the panel securely with hand to prevent it from falling.
- For cleaning, do not use hot water above 40°C, benzene, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.
- After cleaning, make sure that the front panel is securely fixed.

Filters

1. Open the front panel. (page 23.)


2. Pull out the air filters.

- Push a little upwards the tab at the center of each air filter, then pull it down.




3. Take off the Titanium Apatite Photocatalytic Air-Purifying Filter.

- Hold the recessed parts of the frame and unhook the four claws.



5. Set the air filter and Titanium Apatite Photocatalytic Air-Purifying Filter as they were and close the front panel.


- Insert claws of the filters into slots of the front panel. Close the front panel slowly and push the panel at the 3 points. (1 on each side and 1 in the middle.)



■ Air Filter


1. Wash the air filters with water or clean them with vacuum cleaner.

- If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.
- It is recommended to clean the air filters every two weeks.



■ Titanium Apatite Photocatalytic Air-Purifying Filter.

The Titanium Apatite Photocatalytic Air-Purifying Filter can be renewed by washing it with water once every 6 months. We recommend replacing it once every 3 years.



[Maintenance]

1. Remove dust with a vacuum cleaner and wash lightly with water.
2. If it is very dirty, soak it for 10 to 15 minutes in water mixed with a neutral cleaning agent.
3. Do not remove filter from frame when washing with water.
4. After washing, shake off remaining water and dry in the shade.
5. Since the material is made out of polyester, do not wring out the filter when removing water from it.

[Replacement]

1. Remove the tabs on the filter frame and replace with a new filter.
 - Dispose of the old filter as non-flammable waste.

NOTE

- Operation with dirty filters:
 (1) cannot deodorize the air. (2) cannot clean the air.
 (3) results in poor heating or cooling. (4) may cause odour.
- To order Titanium Apatite Photocatalytic Air-Purifying Filter contact to the service shop there you bought the air conditioner.
- Dispose of the old filter as non-flammable waste.

Item	Part No.
Titanium Apatite Photocatalytic Air-Purifying Filter (without frame) 1 set	KAF970A46

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.
Check that the drain comes smoothly out of the drain hose during COOL or DRY operation. • If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

■ Before a long idle period

1. Operate the “FAN only” for several hours on a fine day to dry out the inside.
 - Press “MODE selector button” and select “FAN” operation.
 - Press “ON/OFF button” and start operation.
2. After operation stops, turn off the breaker for the room air conditioner.
3. Clean the air filters and set them again.
4. Take out batteries from the remote controller.

2.12 Troubleshooting

Trouble Shooting

These cases are not troubles.

The following cases are not air conditioner troubles but have some reasons. You may just continue using it.

Case	Explanation
Operation does not start soon. <ul style="list-style-type: none"> When ON/OFF button was pressed soon after operation was stopped. When the mode was reselected. 	<ul style="list-style-type: none"> This is to protect the air conditioner. You should wait for about 3 minutes.
Hot air does not flow out soon after the start of heating operation.	<ul style="list-style-type: none"> The air conditioner is warming up. You should wait for 1 to 4 minutes. (The system is designed to start discharging air only after it has reached a certain temperature.)
The heating operation stops suddenly and a flowing sound is heard.	<ul style="list-style-type: none"> The system is taking away the frost on the outdoor unit. You should wait for about 3 to 8 minutes.
The outdoor unit emits water or steam.	<ul style="list-style-type: none"> ■ In HEAT mode <ul style="list-style-type: none"> The frost on the outdoor unit melts into water or steam when the air conditioner is in defrost operation. ■ In COOL or DRY mode <ul style="list-style-type: none"> Moisture in the air condenses into water on the cool surface of outdoor unit piping and drips.
Mist comes out of the indoor unit.	<ul style="list-style-type: none"> ■ This happens when the air in the room is cooled into mist by the cold airflow during cooling operation.
The indoor unit gives out odour.	<ul style="list-style-type: none"> ■ This happens when smells of the room, furniture, or cigarettes are absorbed into the unit and discharged with the airflow. (If this happens, we recommend you to have the indoor unit washed by a technician. Consult the service shop where you bought the air conditioner.)
The outdoor fan rotates while the air conditioner is not in operation.	<ul style="list-style-type: none"> ■ After operation is stopped: <ul style="list-style-type: none"> The outdoor fan continues rotating for another 60 seconds for system protection. ■ While the air conditioner is not in operation: <ul style="list-style-type: none"> When the outdoor temperature is very high, the outdoor fan starts rotating for system protection.
The operation stopped suddenly. (OPERATION lamp is on.)	<ul style="list-style-type: none"> ■ For system protection, the air conditioner may stop operating on a sudden large voltage fluctuation. It automatically resumes operation in about 3 minutes.
No remote controller signals are displayed. The remote controller sensitivity is low. The display is low in contrast or blacked out. The display runs out of control.	<ul style="list-style-type: none"> The batteries are dying and the remote controller is malfunctioning. Replace all the batteries with new size AAA alkaline batteries. For details, refer to "To set the batteries" of this manual. (page7.) * If the reset button is provided, press the reset button after the batteries are replaced.

Check again.

Please check again before calling a repair person.

Case	Check
The air conditioner does not operate. (OPERATION lamp is off.)	<ul style="list-style-type: none"> • Hasn't a breaker turned OFF or a fuse blown? • Isn't it a power failure? • Are batteries set in the remote controller? • Is the timer setting correct?
Cooling (Heating) effect is poor.	<ul style="list-style-type: none"> • Are the air filters clean? • Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? • Is the temperature setting appropriate? • Are the windows and doors closed? • Are the airflow rate and the air direction set appropriately? • Is the unit set to the INTELLIGENT EYE mode? (page 17.)
Operation stops suddenly. (OPERATION lamp flashes.)	<ul style="list-style-type: none"> • Are the air filters clean? • Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? <p>Clean the air filters or take all obstacles away and turn the breaker OFF. Then turn it ON again and try operating the air conditioner with the remote controller. If the lamp still flashes, call the service shop where you bought the air conditioner.</p>
An abnormal functioning happens during operation.	<ul style="list-style-type: none"> • The air conditioner may malfunction with lightning or radio waves. Turn the breaker OFF, turn it ON again and try operating the air conditioner with the remote controller.

Call the service shop immediately.



WARNING

- When an abnormality (such as a burning smell) occurs, stop operation and turn the breaker OFF.
Continued operation in an abnormal condition may result in troubles, electric shocks or fire.
Consult the service shop where you bought the air conditioner.
- Do not attempt to repair or modify the air conditioner by yourself.
Incorrect work may result in electric shocks or fire.
Consult the service shop where you bought the air conditioner.

If one of the following symptoms takes place, call the service shop immediately.

- **The power cord is abnormally hot or damaged.**
- **An abnormal sound is heard during operation.**
- **The safety breaker, a fuse, or the earth leakage breaker cuts off the operation frequently.**
- **A switch or a button often fails to work properly.**
- **There is a burning smell.**
- **Water leaks from the indoor unit.**



Turn the breaker OFF and call the service shop.

■ After a power failure

The air conditioner automatically resumes operation in about 3 minutes. You should just wait for a while.

■ Lightning

If lightning may strike the neighbouring area, stop operation and turn the breaker OFF for system protection.

Disposal requirements



Your air conditioning product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the air conditioning system, treatment of the refrigerant, of oil and of other parts must be done by a qualified installer in accordance with relevant local and national legislation.

Air conditioners must be treated at a specialized treatment facility for re-use, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. Please contact the installer or local authority for more information.

Batteries must be removed from the remote controller and disposed of separately in accordance with relevant local and national legislation.

We recommend periodical maintenance.

In certain operating conditions, the inside of the air conditioner may get foul after several seasons of use, resulting in poor performance. It is recommended to have periodical maintenance by a specialist aside from regular cleaning by the user. For specialist maintenance, contact the service shop where you bought the air conditioner. The maintenance cost must be born by the user.

Important information regarding the refrigerant used.

This product contains fluorinated greenhouse gases covered by the Kyoto Protocol.

Refrigerant type: **R410A**

GWP⁽¹⁾ value: **1975**

⁽¹⁾ GWP = global warming potential

Periodical inspections for refrigerant leaks may be required depending on European or local legislation. Please contact your local dealer for more information.

Part 6

Service Diagnosis


1. Caution for Diagnosis	76
2. Problem Symptoms and Measures	77
3. Service Check Function	78
4. Troubleshooting	81
4.1 Error Codes and Description	81
4.2 Indoor Unit PCB Abnormality	82
4.3 Freeze-up Protection Control or High Pressure Control.....	83
4.4 Fan Motor (DC Motor) or Related Abnormality.....	85
4.5 Thermistor or Related Abnormality (Indoor Unit).....	87
4.6 Signal Transmission Error (between Indoor and Outdoor Unit)	88
4.7 Unspecified Voltage (between Indoor and Outdoor Units)	90
4.8 Outdoor Unit PCB Abnormality.....	91
4.9 OL Activation (Compressor Overload)	93
4.10 Compressor Lock	94
4.11 DC Fan Lock	95
4.12 Input Over Current Detection	96
4.13 Four Way Valve Abnormality	99
4.14 Discharge Pipe Temperature Control.....	101
4.15 High Pressure Control in Cooling	103
4.16 Compressor System Sensor Abnormality	105
4.17 Position Sensor Abnormality	108
4.18 DC Voltage / Current Sensor Abnormality.....	109
4.19 CT or Related Abnormality	110
4.20 Thermistor or Related Abnormality (Outdoor Unit).....	112
4.21 Electrical Box Temperature Rise.....	114
4.22 Radiation Fin Temperature Rise	116
4.23 Output Over Current Detection.....	120
4.24 Insufficient Gas.....	122
4.25 Over-voltage Detection.....	126
4.26 Signal Transmission Error (on Outdoor Unit PCB).....	127
5. Check	128
5.1 How to Check.....	128

1. Caution for Diagnosis

The operation lamp flashes when any of the following errors is detected.

1. When a protection device of the indoor or outdoor unit is activated or when the thermistor malfunctions, disabling equipment operation.
 2. When a signal transmission error occurs between the indoor and outdoor units.
- In either case, conduct the diagnostic procedure described in the following pages.

Location of Operation Lamp



(R5191)

Troubleshooting with LED Indication

The outdoor unit has one green LED (LEDA) on the PCB. The flashing green LED indicates normal condition of microcomputer operation.

2. Problem Symptoms and Measures


Symptom	Check Item	Details of Measure	Reference Page
None of the Units Operates.	Check the power supply.	Check to make sure that the rated voltage is supplied.	—
	Check the type of the indoor units.	Check to make sure that the indoor unit type is compatible with the outdoor unit.	—
	Check the outdoor air temperature.	Heating operation cannot be used when the outdoor air temperature is 20°C or higher (only for heat pump model), and cooling operation cannot be used when the outdoor air temperature is below -10°C.	—
	Diagnosis with remote controller indication	—	81
	Check the remote controller addresses.	Check to make sure that address settings for the remote controller and indoor unit are correct.	—
Operation Sometimes Stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation. (Operation lamp OFF)	—
	Check the outdoor air temperature.	Heating operation cannot be used when the outdoor air temperature is 20°C or higher (only for heat pump model), and cooling operation cannot be used when the outdoor air temperature is below -10°C.	—
	Diagnosis with remote controller indication	—	81
Equipment operates but does not cool, or does not heat (only for heat pump model).	Check for wiring and piping errors in the indoor and outdoor units connection wires and pipes.	Conduct the wiring/piping error check described on the product diagnosis nameplate.	—
	Check for thermistor detection errors.	Check to make sure that the main unit's thermistor has not dismantled from the pipe holder.	—
	Check for faulty operation of the electronic expansion valve.	Set the units to cooling operation, and compare the temperatures of the liquid side connection pipes of the connection section among rooms to check the opening and closing operation of the electronic expansion valves of the individual units.	—
	Diagnosis with remote controller indication	—	81
	Diagnosis by service port pressure and operating current	Check for insufficient gas.	132
Large Operating Noise and Vibrations	Check the output voltage of the power transistor.	—	133
	Check the power transistor.	—	—
	Check the installation condition.	Check to make sure that the required spaces for installation (specified in the Engineering data book, etc.) are provided.	—

3. Service Check Function

In the ARC433 series remote controller, the temperature display sections on the main unit indicate corresponding codes.

Check Method 1

1. When the timer cancel button is held down for 5 seconds, a "00" indication flashes on the temperature display section.



(R8258)

2. Press the timer cancel button repeatedly until a continuous beep is produced.
 ■ The code indication changes in the sequence shown below, and notifies with a long beep.

No.	Code	No.	Code	No.	Code
1	00	12	F6	23	R1
2	U4	13	C7	24	E1
3	L5	14	R3	25	U8
4	E6	15	H8	26	U4
5	H6	16	H9	27	P4
6	H0	17	C9	28	L3
7	R6	18	C4	29	L4
8	E7	19	C5	30	H7
9	U0	20	J3	31	U2
10	F3	21	J6	32	E8
11	R5	22	E5	33	R4




Note:

1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.


Check Method 2

1. Enter the diagnosis mode.
Press the 3 buttons (TEMP▲, TEMP▼, MODE) simultaneously.




The digit of the number of tens blinks.

★Try again from the start when the digit does not blink.




2. Press the TEMP button.
Press TEMP▲ or TEMP▼ and change the digit until you hear the sound of “beep” or “pi pi”.




3. Diagnose by the sound.
 - ★“pi” : The number of tens does not accord with the error code.
 - ★“pi pi” : The number of tens accords with the error code.
 - ★“beep” : The both numbers of tens and units accord with the error code. (→See 7.)


4. Enter the diagnosis mode again.
Press the MODE button.



The digit of the number of units blinks.




5. Press the TEMP button.
Press TEMP▲ or TEMP▼ and change the digit until you hear the sound of “beep”.



(R4277)

6. Diagnose by the sound.
 - ★“pi” : The both numbers of tens and units do not accord with the error code.
 - ★“pi pi” : The number of tens accords with the error code.
 - ★“beep” : The both numbers of tens and units accord with the error code.
7. Determine the error code.
The digits indicated when you hear the “beep” sound are error code.
(Error codes and description → Refer to page 81.)
8. Exit from the diagnosis mode.
Press the MODE button.



(R4278)

4. Troubleshooting

4.1 Error Codes and Description

	Code Indication	Description	Reference Page
System	00	Normal	—
	U0★	Insufficient gas	122
	U2	Over-voltage detection	126
	U4	Signal transmission error (between indoor and outdoor unit)	88
	U8	Unspecified voltage (between indoor and outdoor unit)	90
Indoor Unit	R1	Indoor unit PCB abnormality	82
	R5	Freeze-up protection control or high pressure control	83
	R6	Fan motor or related abnormality	85
	C4	Heat exchanger temperature thermistor abnormality	87
	C9	Room temperature thermistor abnormality	87
Outdoor Unit	E1	Outdoor unit PCB abnormality	91
	E5★	OL activation (compressor overload)	93
	E6★	Compressor lock	94
	E7	DC fan lock	95
	E8	Input over current detection	96
	E9	Four way valve abnormality	99
	F3	Discharge pipe temperature control	101
	F6	High pressure control in cooling	103
	H0	Compressor system sensor abnormality	105
	H6	Position sensor abnormality	108
	H8	DC voltage/current sensor abnormality	109
		CT or related abnormality	110
	H9	Outdoor air thermistor or related abnormality	112
	J3	Discharge pipe temperature thermistor or related abnormality	112
	J6	Heat exchanger temperature thermistor or related abnormality	112
	L3	Electrical box temperature rise	114
	L4	Radiation fin temperature rise	116
	L5	Output over current detection	120
	P4	Heat radiation fin thermistor or related abnormality	112
	U7	Signal transmission error on outdoor unit PCB	127

★: Displayed only when system-down occurs.

4.2 Indoor Unit PCB Abnormality

Remote
Controller
Display

81

Method of
Malfunction
Detection

Evaluation of zero-cross detection of power supply by indoor unit.


Malfunction
Decision
Conditions

When there is no zero-cross detection in approximately 10 continuous seconds.

Supposed
Causes

- Faulty indoor unit PCB
- Faulty connector connection

Troubleshooting



(R7130)



Note: Connector Nos. vary depending on models.

Model Type	Connector No.
Wall Mounted Type 25 / 35 / 50 class	Terminal strip~Control PCB

4.3 Freeze-up Protection Control or High Pressure Control

Remote
Controller
Display

85

Method of
Malfunction
Detection

- High pressure control (heat pump model only)
During heating operations, the temperature detected by the indoor heat exchanger thermistor is used for the high pressure control (stop, outdoor fan stop, etc.)
- Freeze-up protection control (operation halt) is activated during cooling operation according to the temperature detected by the indoor unit heat exchanger thermistor.

Malfunction
Decision
Conditions

- High pressure control
During heating operations, the temperature detected by the indoor heat exchanger thermistor is above 65°C
- Freeze-up protection
When the indoor unit heat exchanger temperature is below 0°C during cooling operation.

Supposed
Causes

- Operation halt due to clogged air filter of the indoor unit.
- Operation halt due to dust accumulation on the indoor unit heat exchanger.
- Operation halt due to short-circuit.
- Detection error due to faulty indoor unit heat exchanger thermistor.
- Detection error due to faulty indoor unit PCB.


Troubleshooting



Check No.06
Refer to P.130

**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R7131)

4.4 Fan Motor (DC Motor) or Related Abnormality

Remote Controller Display



Method of Malfunction Detection

The rotation speed detected by the [Hall IC](#) during fan motor operation is used to determine abnormal fan motor operation.

Malfunction Decision Conditions

When the detected rotation speed does not reach the demanded rotation speed of the target tap, and is less than 50% of the maximum fan motor rotation speed.

Supposed Causes

- Operation halt due to short circuit inside the fan motor winding.
- Operation halt due to breaking of wire inside the fan motor.
- Operation halt due to breaking of the fan motor lead wires.
- Operation halt due to faulty capacitor of the fan motor.
- Detection error due to faulty indoor unit PCB.

Troubleshooting




Check No.01
Refer to P.128



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R7133)

4.5 Thermistor or Related Abnormality (Indoor Unit)

Remote
Controller
Display

℃4,℃9

Method of
Malfunction
Detection

The temperatures detected by the thermistors are used to determine thermistor errors.

Malfunction
Decision
Conditions

When the thermistor input is more than 4.96 V or less than 0.04 V during compressor operation*.

* (reference)

When above about 212°C (less than 120 ohms) or below about -50°C (more than 1,860 kohms).



Note: The values vary slightly in some models.

Supposed
Causes

- Faulty connector connection
- Faulty thermistor
- Faulty PCB

Troubleshooting



Check No.06
Refer to P.130



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Check the connector connection.

Is it normal?

NO

Correct the connection.

YES

Check No. 06
Check the thermistor resistance value.

Is it normal?

NO

Replace the thermistor.
(Replace the indoor unit PCB.)

YES

Replace the indoor unit PCB.

(R7134)

℃4 : Heat exchanger thermistor

℃9 : Room temperature thermistor

4.6 Signal Transmission Error (between Indoor and Outdoor Unit)

Remote
Controller
Display

U4

Method of
Malfunction
Detection

The data received from the outdoor unit in indoor unit-outdoor unit signal transmission is checked whether it is normal.

Malfunction
Decision
Conditions

When the data sent from the outdoor unit cannot be received normally, or when the content of the data is abnormal.

Supposed
Causes

- Faulty outdoor unit PCB.
- Faulty indoor unit PCB.
- Indoor unit-outdoor unit signal transmission error due to wiring error.
- Indoor unit-outdoor unit signal transmission error due to disturbed power supply waveform.
- Indoor unit-outdoor unit signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units (wire No. 3).
- Short circuit inside the fan motor winding


Troubleshooting



Check No.10
Refer to P.132

**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R8266)

4.7 Unspecified Voltage (between Indoor and Outdoor Units)

Remote
Controller
Display



Method of
Malfunction
Detection

The supply power is detected for its requirements (different from pair type and multi type) by the indoor / outdoor transmission signal.


Malfunction
Decision
Conditions

The pair type and multi type are interconnected.

Supposed
Causes

- Wrong models interconnected
- Wrong indoor unit PCB mounted
- Indoor unit PCB defective
- Wrong outdoor unit PCB mounted or defective

Troubleshooting



(R7342)

4.8 Outdoor Unit PCB Abnormality

4.8.1 25/35 Class

Remote
Controller
Display

E1

Method of
Malfunction
Detection

- The system follows the microprocessor program to make sure it runs normally.
- The system checks to see if the zero-cross signal comes in properly.


Malfunction
Decision
Conditions

- The microprocessor program runs out of control.
- The zero-cross signal is not detected.

Supposed
Causes

- The microcomputer is out of control due to external factors.
 - ◆ Noise
 - ◆ Momentary voltage drop
 - ◆ Momentary power failure, etc.
- Outdoor unit PCB defective
- Broken harness between PCBs

Troubleshooting



4.8.2 50 Class

Remote
Controller
Display

E1

Method of
Malfunction
Detection

- Detect within the programme of the microcomputer that the programme is in normal running order.

Malfunction
Decision
Conditions

- When the programme of the microcomputer is in abnormal running order.

Supposed
Causes


- Out of control of microcomputer caused by external factors
 - Noise
 - Momentary fall of voltage
 - Momentary power loss
- Defective outdoor unit PCB

Troubleshooting



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R5142)

4.9 OL Activation (Compressor Overload)

Remote
Controller
Display

ES

Method of
Malfunction
Detection

A compressor overload is detected through compressor OL.

Malfunction
Decision
Conditions

- If the compressor OL is activated twice, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).
- * The operating temperature condition is not specified.

Supposed
Causes

- Refrigerant shortage
- Four way valve malfunctioning
- Outdoor unit PCB defective
- Water mixed in the local piping
- Electronic expansion valve defective
- Stop valve defective

Troubleshooting



Check No.04
Refer to P.128



Check No.05
Refer to P.129



Check No.06
Refer to P.130




Check No.11
Refer to P.132



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R7137)

4.10 Compressor Lock

Remote
Controller
Display



Method of
Malfunction
Detection

A compressor lock is detected by checking the compressor running condition through the position detection circuit.

Malfunction
Decision
Conditions

25/35 class

- The system judges the compressor lock, and stops due to over current.
- The system judges the compressor lock, and cannot operation with position detection within 15 seconds after start up.
- The system will be shut down if the error occurs 16 times.
- Clearing condition: Continuous run for about 10 minutes (normal)

50 class

- Judging from current waveform generated when applying high-frequency voltage to the motor.
- The system will be shut down if the error occurs 16 times.
- Clearing condition: Continuous run for about 5 minutes (normal)

Supposed
Causes


- Compressor locked
- Compressor harness disconnected

Troubleshooting



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.
(Precaution before turning on the power again)
Make sure the power has been off for at least 30 seconds.



(R8357)

4.11 DC Fan Lock

Remote
Controller
Display

E7

Method of
Malfunction
Detection

A fan motor or related error is detected by checking the high-voltage fan motor rpm being detected by the Hall IC.

Malfunction
Decision
Conditions


- The fan does not start in 30 seconds even when the fan motor is running.
- The system will be shut down if the error occurs 16 times.
- Clearing condition: Continuous run for about 10 minutes (normal)

Supposed
Causes

- Fan motor breakdown
- Harness or connector disconnected between fan motor and PCB or in poor contact
- Foreign matters stuck in the fan

Troubleshooting


Check No.15
Refer to P.135



4.12 Input Over Current Detection

4.12.1 25/35 Class

Remote
Controller
Display



Method of
Malfunction
Detection

An input over-current is detected by checking the input current value with the compressor running.

Malfunction
Decision
Conditions

- The following current with the compressor running continues for 2.5 seconds.
Cooling / Heating: Above 9.25A

Supposed
Causes

- Over-current due to compressor failure
- Over-current due to defective power transistor
- Over-current due to defective outdoor unit PCB
- Error detection due to outdoor unit PCB
- Over-current due to short-circuit

Troubleshooting

Check No.07
Refer to P.131


Check No.08
Refer to P.131



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

* An input over-current may result from wrong internal wiring. If the wires have been disconnected and reconnected for part replacement, for example, and the system is interrupted by an input over-current, take the following procedure.



(R8256)

4.12.2 50 Class

Remote Controller Display



Method of Malfunction Detection

An input over-current is detected by checking the input current value being detected by CT with the compressor running.

Malfunction Decision Conditions

- The following CT input with the compressor running continues for 2.5 seconds.
CT input : Above 20 A
- The system will be shut down if the error occurs 16 times.
- Clearing condition : Continuous run for about 5 minutes (normal)

Supposed Causes

- Over-current due to compressor failure
- Over-current due to defective power transistor
- Over-current due to defective inverter main circuit electrolytic capacitor
- Over-current due to defective outdoor unit PCB
- Error detection due to outdoor unit PCB
- Over-current due to short-circuit

Troubleshooting



Check No.07
Refer to P.131



Check No.08
Refer to P.131




Check No.14
Refer to P.135



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

* An input over-current may result from wrong internal wiring. If the wires have been disconnected and reconnected for part replacement, for example, and the system is interrupted by an input over-current, check the wires again.



(R8343)

4.13 Four Way Valve Abnormality

Remote
Controller
Display

E8

Method of
Malfunction
Detection

The indoor air temperature thermistor, the indoor unit heat exchanger thermistor, the outdoor temperature thermistor and the outdoor unit heat exchanger thermistor are checked to see if they function within their normal ranges in the operating mode.

Malfunction
Decision
Conditions

A following condition continues over **A** minutes after operating **B** minutes.

	25/35 class	50 class
A	10	1
B	5	10

- Cooling / dry operation
(room temp. – indoor heat exchanger temp.) < –5°C
- Heating
(indoor unit heat exchanger temp. – room temp.) < –5°C

Supposed
Causes


- Connector in poor contact
- Thermistor defective
- Outdoor unit PCB defective
- Four way valve coil or harness defective
- Four way valve defective
- Foreign substance mixed in refrigerant
- Insufficient gas

Troubleshooting

 **Check No.05**
Refer to P.129

 **Check No.06**
Refer to P.130

 **Check No.11**
Refer to P.132



(R8344)

4.14 Discharge Pipe Temperature Control

Remote Controller Display



Method of Malfunction Detection

The discharge pipe temperature control (stop, frequency drooping, etc.) is checked with the temperature being detected by the discharge pipe thermistor.

Malfunction Decision Conditions

25/35 class

- If a stop takes place 4 times successively due to abnormal discharge pipe temperature, the system will be shut down.
- If the temperature being detected by the discharge pipe thermistor rises above A°C , the compressor will stop. (The error is cleared when the temperature has dropped below B°C .)

Stop temperatures	A	B
(1) above 45Hz (rising), above 40Hz (dropping)	110	97
(2) 30~45Hz (rising), 25~40Hz (dropping)	105	92
(3) below 30Hz (rising), below 25Hz (dropping)	99	86

- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

50 class

- If a stop takes place 6 times successively due to abnormal discharge pipe temperature, the system will be shut down.
- If the temperature being detected by the discharge pipe thermistor rises above A°C , the compressor will stop. (The error is cleared when the temperature has dropped below B°C .)

50 class	
A	110
B	95

- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed Causes


- Refrigerant shortage
- Four way valve malfunctioning
- Discharge pipe thermistor defective
(heat exchanger or outdoor air temperature thermistor defective)
- Outdoor unit PCB defective
- Water mixed in the local piping
- Electronic expansion valve defective
- Stop valve defective

Troubleshooting


Check No.04
Refer to P.128


Check No.06
Refer to P.130


Check No.11
Refer to P.132



4.15 High Pressure Control in Cooling

Remote Controller Display



Method of Malfunction Detection

High-pressure control (stop, frequency drop, etc.) is activated in the cooling mode if the temperature being sensed by the heat exchanger thermistor exceeds the limit.

Malfunction Decision Conditions

- Activated when the temperature being sensed by the heat exchanger thermistor rises above 65°C.
- The error is cleared when the temperature drops below 54°C (25/35 class) or 51°C (50 class).

Supposed Causes

- The installation space is not large enough.
- Faulty outdoor unit fan
- Faulty electronic expansion valve
- Faulty defrost thermistor
- Faulty outdoor unit PCB
- Faulty stop valve
- Dirty heat exchanger

Troubleshooting

 **Check No.04**
Refer to P.128

 **Check No.06**
Refer to P.130


 **Check No.07**
Refer to P.131

 **Check No.09**
Refer to P.132



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R7142)

4.16 Compressor System Sensor Abnormality

4.16.1 25/35 Class

Remote
Controller
Display

HC

Method of
Malfunction
Detection

- The system checks the DC current before the compressor starts.


Malfunction
Decision
Conditions

- If the DC current before compressor start-up is out of the range 0.5-4.5 V (sensor output converted to voltage value) or if the DC voltage before compressor start-up is below 50 V.

Supposed
Causes

- PCB defective
- Broken or poorly connected harness

Troubleshooting



(R7348)

4.16.2 50 Class

Remote Controller Display

H0

Method of Malfunction Detection

- Fault condition is identified by the supply voltage and the DC voltage which is detected before the compressor startup.
- Fault condition is identified by compressor current which is detected right after the compressor startup.


Malfunction Decision Conditions

- The detected value of the supply voltage and the DC voltage is obviously low or high.
- The compressor current doesn't run when the compressor is started.

Supposed Causes

- Reactor disconnection
- Compressor disconnection
- Outdoor unit PCB defective
- Compressor defective

Troubleshooting



(R7174)

4.17 Position Sensor Abnormality

Remote
Controller
Display



Method of
Malfunction
Detection

A compressor startup failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction
Decision
Conditions


- The compressor fails to start in about 15 seconds after the compressor run command signal is sent.
- Clearing condition: Continuous run for about 10 minutes (25/35 class) or 5 minutes (50 class).
- The system will be shut down if the error occurs 16 times (25/35 class) or 8 times (50 class).

Supposed
Causes

- Compressor relay cable disconnected
- Compressor itself defective
- Outdoor unit PCB defective
- Stop valve closed
- Input voltage out of specification

Troubleshooting


Check No.13
Refer to P.133



(R7175)

4.18 DC Voltage / Current Sensor Abnormality

Remote
Controller
Display



Method of
Malfunction
Detection

Detecting abnormality of the DC sensor by the running frequency of compressor and by the input current multiplied DC voltage and current.

Malfunction
Decision
Conditions

The compressor running frequency is below 52 Hz.
(The input current is also below 0.1 A.)

- If this error repeats 4 times, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed
Causes

- Outdoor unit PCB defective

Troubleshooting



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Replace the outdoor unit PCB.

4.19 CT or Related Abnormality

Remote Controller Display



Method of Malfunction Detection

A CT or related error is detected by checking the compressor running frequency and CT-detected input current.

Malfunction Decision Conditions

The compressor running frequency is below 55 Hz and the CT input is below 0.1 V.
(The input current is also below 0.5 A.)

- If this error repeats 4 times, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).


Supposed Causes

- Power transistor defective
- Internal wiring broken or in poor contact
- Reactor defective
- Outdoor unit PCB defective

Troubleshooting


Check No.12
Refer to P.133
**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R7184)

4.20 Thermistor or Related Abnormality (Outdoor Unit)

Remote Controller Display

P4, U3, U6, H9

Method of Malfunction Detection

This type of error is detected by checking the thermistor input voltage to the microcomputer.
[A thermistor error is detected by checking the temperature.]

Malfunction Decision Conditions

The thermistor input is above 4.96 V or below 0.04 V with the power on.
Error U3 is judged if the discharge pipe thermistor temperature is smaller than the condenser thermistor temperature.

Supposed Causes

- Connector in poor contact
- Thermistor defective
- Outdoor unit PCB defective
- Indoor unit PCB defective
- Condenser thermistor defective in the case of U3 error (outdoor unit heat exchanger thermistor in the cooling mode, or indoor unit heat exchanger thermistor in the heating mode)


Troubleshooting



Check No.06
Refer to P.130

**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R7346)

- P4 : Radiation fin thermistor
 J3 : Discharge pipe thermistor
 J5 : Outdoor heat exchanger thermistor
 H3 : Outdoor air temperature thermistor

4.21 Electrical Box Temperature Rise

Remote Controller Display



Method of Malfunction Detection

An electrical box temperature rise is detected by checking the radiation fin thermistor with the compressor off.

Malfunction Decision Conditions

With the compressor off, the radiation fin temperature is above 80°C (95°C★). (Reset is made when the temperature drops below 70°C (80°C★).)

★: value for 50 class

Supposed Causes


- Fin temperature rise due to defective outdoor unit fan
- Fin temperature rise due to short-circuit
- Fin thermistor defective
- Connector in poor contact
- Outdoor unit PCB defective

Troubleshooting


Check No.06
 Refer to P.130


Check No.07
 Refer to P.131


Check No.09
 Refer to P.132



(R8345)

★: Value for 50 class

4.22 Radiation Fin Temperature Rise

4.22.1 25/35 Class


Remote Controller Display	L4
Method of Malfunction Detection	A radiation fin temperature rise is detected by checking the radiation fin thermistor with the compressor on.
Malfunction Decision Conditions	<ul style="list-style-type: none"> ■ If the radiation fin temperature with the compressor on is above 90°C. ■ Clearing condition : when the temperature drops below 85°C. ■ If a radiation fin temperature rise takes place 4 times successively, the system will be shut down. ■ The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).
Supposed Causes	<ul style="list-style-type: none"> ■ Fin temperature rise due to defective outdoor unit fan ■ Fin temperature rise due to short-circuit ■ Fin thermistor defective ■ Connector in poor contact ■ Outdoor unit PCB defective ■ Silicon grease is not applied properly on the heat radiation fin after replacing outdoor unit PCB

Troubleshooting


Check No.06
 Refer to P.130


Check No.07
 Refer to P.131


Check No.09
 Refer to P.132



(R7147)



Note: Refer to “1.3 Application of Silicon grease to a power transistor and a diode bridge” on P 220.

4.22.2 50 Class

Remote Controller Display

L4

Method of Malfunction Detection

A radiation fin temperature rise is detected by checking the radiation fin thermistor with the compressor on.

Malfunction Decision Conditions

- If the radiation fin temperature with the compressor on is above 105°C,
- The error is cleared when the temperature drops below 99°C.
- If a radiation fin temperature rise takes place 4 times successively, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed Causes

- Fin temperature rise due to defective outdoor unit fan
- Fin temperature rise due to short-circuit
- Fin thermistor defective
- Connector in poor contact
- Outdoor unit PCB defective
- Silicon grease is not applied properly on the heat radiation fin after replacing outdoor unit PCB

Troubleshooting




Check No.07
Refer to P.131



Check No.09
Refer to P.132

**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R7178)



Note: Refer to “1.3 Application of Silicon grease to a power transistor and a diode bridge” on P 220.

4.23 Output Over Current Detection

Remote
Controller
Display

LS

Method of
Malfunction
Detection

An output over-current is detected by checking the current that flows in the inverter DC section.

Malfunction
Decision
Conditions

- A position signal error occurs while the compressor is running.
- A speed error occurs while the compressor is running.
- An output over-current input is fed from the output over-current detection circuit to the microcomputer.
- The system will be shut down if the error occurs 255 times (25/35 class) or 16 times (50 class).
- Clearing condition: Continuous run for about 10 minutes (25/35 class) or 5 minutes (50 class) (normal)

Supposed
Causes

- Over-current due to defective power transistor
- Over-current due to wrong internal wiring
- Over-current due to abnormal supply voltage
- Over-current due to defective PCB
- Error detection due to defective PCB
- Over-current due to closed stop valve
- Over-current due to compressor failure
- Over-current due to poor installation condition

Troubleshooting



Check No.07
Refer to P.131



Check No.08
Refer to P.131




Check No.13
Refer to P.133

**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

* An output over-current may result from wrong internal wiring. If the wires have been disconnected and reconnected for part replacement, for example, and the system is interrupted by an output over-current, take the following procedure.



(R8346)

4.24 Insufficient Gas

4.24.1 25/35 Class

Remote
Controller
Display



Method of
Malfunction
Detection

Gas shortage detection I:

Gas shortage is detected by checking the input current value and the compressor running frequency. If the gas is short, the input current is smaller than the normal value.

Gas shortage detection II:

Gas shortage is detected by checking the discharge temperature and the opening of the electronic expansion valve. If the gas is short, the discharge temperature tends to rise.

Gas shortage detection III:

A gas shortage is detected by checking the difference between inhale and exhale temperature.

Malfunction
Decision
Conditions

Gas shortage detection I:

The following conditions continue for 7 minutes.

- ◆ Input current × input voltage ≤ 640 / 256 × output frequency
- ◆ Output frequency > 55 (Hz)

Gas shortage detection II:

The following conditions continue for 80 seconds.

- ◆ Target opening of the electronic expansion valve ≥ 480 (pulse)
- ◆ Discharge temperature > 255 / 256 × target discharge temperature +30 (°C)

Gas shortage detection III:

When the difference of the temperature is smaller than Δ , it is regarded as insufficient gas.

		Δ
Cooling	room temperature – indoor heat exchanger temperature	4.0°C
	outdoor heat exchanger temperature – outdoor temperature	4.0°C
Heating	indoor heat exchanger temperature – room temperature	3.0°C
	outdoor temperature – outdoor heat exchanger temperature	3.0°C

If a gas shortage error takes place 4 times straight, the system will be shut down. The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed
Causes

- Refrigerant shortage (refrigerant leakage)
- Poor compression performance of compressor
- Discharge pipe thermistor disconnected, or indoor unit or outdoor unit heat exchanger thermistor disconnected, room or outdoor air temperature thermistor disconnected
- Stop valve closed
- Electronic expansion valve defective

Troubleshooting




Check No.04
Refer to P.128



Check No.06
Refer to P.130

**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R7149)

4.24.2 50 Class

Remote Controller Display



Method of Malfunction Detection

Gas shortage detection I :

A gas shortage is detected by checking the CT-detected input current value and the compressor running frequency.

Gas shortage detection II :

A gas shortage is detected by checking the difference between indoor unit heat exchanger temperature and room temperature as well as the difference between outdoor unit heat exchanger temperature and room temperature.

Malfunction Decision Conditions

Gas shortage detection I :

$DC\ current \leq A\ (A/Hz) \times Output\ frequency + B$

However, when the status of running frequency > 55 (Hz) is kept on for a certain time.

Note : The values are different from model to model.

	A	B
50 class	18 / 1000	0.7

Gas shortage detection II :

If a gas shortage error takes place 4 times successively, the system will be shut down. The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed Causes

- Refrigerant shortage (refrigerant leakage)
- Poor compression performance of compressor
- Discharge pipe thermistor disconnected, or indoor unit or outdoor unit heat exchanger thermistor disconnected, room or outside air temperature thermistor disconnected
- Stop valve closed
- Electronic expansion valve defective

Troubleshooting




Check No.04
Refer to P.128



Check No.06
Refer to P.130

**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



4.25 Over-voltage Detection

Remote
Controller
Display

U2

Method of
Malfunction
Detection

An abnormal voltage rise is detected by checking the specified over-voltage detection circuit.

Malfunction
Decision
Conditions

25/35 class

- An over-voltage signal is fed from the over-voltage detection circuit to the microcomputer (The voltage is over 400V).
- The system will be shut down if the error occurs 255 times.
- Clearing condition: Continuous run for about 10 minutes (normal)


50 class

- An over-voltage signal is fed from the over-voltage detection circuit to the microcomputer, or the voltage being detected by the DC voltage detection circuit is judged to be below 150 V for 0.1 second.
- The system will be shut down if the error occurs 16 times.
- Clearing condition: Continuous run for about 60 minutes (normal)

Supposed
Causes

- Supply voltage not as specified
- Over-voltage detection circuit defective
- PAM control part(s) defective
- Short circuit inside the fan motor winding.

Troubleshooting



(R8347)

4.26 Signal Transmission Error (on Outdoor Unit PCB)

Remote
Controller
Display



Method of
Malfunction
Detection

Communication error between microcomputer mounted on the main PCB and PM1.

Malfunction
Decision
Conditions

- When the data sent from the PM1 can not be received successively for 9 sec.
- The abnormality is determined if the above fault conditions occurs once
- Fault counter is reset when the data from the PM1 can be successfully received.

Supposed
Causes


- Defective outdoor unit PCB

Troubleshooting



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R7185)


5. Check

5.1 How to Check

5.1.1 Fan Motor Connector Output Check

Check No.01

1. Check connector connection.
2. Check motor power supply voltage output (pins 4-7).
3. Check motor control voltage (pins 4-3).
4. Check rotation command voltage output (pins 4-2).
5. Check rotation pulse input (pins 4-1).




5.1.2 Electronic Expansion Valve Check

Check No.04

Conduct the followings to check the electronic expansion valve (EV).

1. Check to see if the EV connector is correctly inserted in the PCB. Compare the EV unit and the connector number.
2. Turn the power off and back on again, and check to see if all the EVs generate latching sound.
3. If any of the EVs does not generate latching noise in the above step 2, disconnect that connector and check the conductivity using a tester.
Check the conductivity between pins 1, 3 and 6, and between pins 2, 4 and 5. If there is no conductivity between the pins, the EV coil is faulty.




4. If no EV generates latching sound in the above step 2, the outdoor unit PCB is faulty.
5. If the conductivity is confirmed in the above step 2, mount a good coil (which generated latching sound) in the EV unit that did not generate latching sound, and check to see if that EV generates latching sound.
*If latching sound is generated, the outdoor unit PCB is faulty.
*If latching sound is not generated, the EV unit is faulty.




Note: Please note that the latching sound varies depending on the valve type.

5.1.3 Four Way Valve Performance Check

Check No.05



(Fig. 1)



(R8348)


5.1.4 Thermistor Resistance Check

Check No.06


Remove the connectors of the thermistors on the PCB, and measure the resistance of each thermistor using tester.

The relationship between normal temperature and resistance is shown in the graph and the table below.

Thermistor Temperature (°C)	R25°C=20kΩ B=3950
-20	211.0 (kΩ)
-15	150
-10	116.5
-5	88
0	67.2
5	51.9
10	40
15	31.8
20	25
25	20
30	16
35	13
40	10.6
45	8.7
50	7.2




(R25=20kΩ 、 B=3950)



(R1437)

5.1.5 Installation Condition Check


Check No.07



(R7452)

5.1.6 Discharge Pressure Check

Check No.08




(R7158)

5.1.7 Outdoor Unit Fan System Check

Check No.09

DC motor




5.1.8 Power Supply Waveforms Check

Check No.10

Measure the power supply waveform between pins 1 and 2 on the terminal board, and check the waveform disturbance.


- Check to see if the power supply waveform is a sine wave (Fig.1).
- Check to see if there is waveform disturbance near the zero cross (sections circled in Fig.2)

[Fig.1]



(R1736)


[Fig.2]



(R1444)

5.1.9 Inverter Units Refrigerant System Check

Check No.11




(R8349)

5.1.10 Capacitor Voltage Check

Check No.12

Before this checking, be sure to check the main circuit for short-circuit.

- Checking the capacitor voltage
- With the circuit breaker still on, measure the voltage according to the drawing of the model in question. Be careful never to touch any live parts.



(R5222)

5.1.11 Power Transistor Check

Check No.13



Note:

25/35 class

Check to make sure that the voltage between the terminal of Power transistor (+) and (-) is approx. 0 volt before checking power transistor.

< Measuring method >

Disconnect the compressor harness connector from the outdoor unit PCB. To disengage the connector, press the protrusion on the connector.

Then, follow the procedure below to measure resistance between power transistor (+) and (-) and the U, V and W terminals of the compressor connector with a multi-tester. Evaluate the measurement results for a pass/fail judgment.


<Power transistor check>

Negative (-) terminal of tester (positive terminal (+) for digital tester)	Power transistor (+)	UVW	Power transistor (-)	UVW
Positive (+) terminal of tester (negative terminal (-) for digital tester)	UVW	Power transistor (+)	UVW	Power transistor (-)
Normal resistance	Several kΩ to several MΩ (*)			
Unacceptable resistance	Short (0 Ω) or open			

50 class

- Checking the power transistor
- Never touch any live parts for at least 10 minutes after turning off the circuit breaker.
- If unavoidably necessary to touch a live part, make sure the power transistor's supply voltage is below 50 V using the tester.
- For the UVW, make measurements at the Faston terminal on the board or the relay connector.

Tester's negative terminal	Power transistor (+)	UVW	Power transistor (-)	UVW
Tester's positive terminal	UVW	Power transistor (+)	UVW	Power transistor (-)
Normal resistance	Several kΩ to several MΩ			
Abnormal resistance	0 or ∞			




(R5237)

5.1.12 Main Circuit Electrolytic Capacitor Check

Check No.14

- Checking the main circuit electrolytic capacitor
- Never touch any live parts for at least 10 minutes after turning off the circuit breaker.
- If unavoidably necessary to touch a live part, make sure there is no DC voltage using the tester.
- Check the continuity with the tester. Reverse the pins and make sure there is continuity.



5.1.13 Turning Speed Pulse Input on the Outdoor Unit PCB Check

Check No.15

<Propeller fan motor>


Make sure the voltage of $320 \pm 30V$ is being applied.

- (1) Stop the operation first and then the power off, and disconnect the connector S70.
- (2) Make sure there is about DC 320 V between pins 4 and 7.
- (3) With the system and the power still off, reconnect the connector S70.
- (4) Make a turn of the fan motor with a hand, and make sure the pulse (0-15 V) appears twice at pins 1 and 4.

If the fuse for fan motor protection is blown out, the outdoor-unit fan may also be in trouble. Check the fan too.

If the voltage in Step (2) is not applied, it means the PCB is defective. Replace the PCB.

If the pulse in Step (4) is not available, it means the Hall IC is defective. Replace the DC fan motor. If there are both the voltage (2) and the pulse (4), replace the PCB.



* Propeller fan motor : S70

Part 7

Removal Procedure

1. Indoor Unit.....	138
1.1 Removal of Air Filter.....	138
1.2 Removal of Front Panel.....	140
1.3 Removal of Front Grille	142
1.4 Removal of Horizontal Blades and Vertical Blades	145
1.5 Removal of Electrical Box	148
1.6 Removal of PCB.....	151
1.7 Removal of Drain Pan Unit.....	157
1.8 Removal of Fan Motor.....	161
1.9 Removal of Heat Exchanger	163
1.10 Removal of Fan Rotor	166
2. Outdoor Unit.....	169
2.1 ARXS 25/35 F	169
2.2 ARXS 50 E	194

1. Indoor Unit




1.1 Removal of Air Filter




Procedure



Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Appearance feature		<p>Warning Dangerous: High voltage A high voltage is applied to all the electric circuits of this product including thermistors.</p> <ul style="list-style-type: none"> ■ The panel designs are different according to the models. ■ When a signal from the remote controller is received, the receiving tone sounds and the operation lamp flickers immediately to confirm the signal reception. ■ When the ON/OFF switch is kept pressed for 5 seconds, the forced cooling operation is performed for about 15 minutes.
2. Removing the air filter	<p>1 Put your fingers on the right and left projections of the front panel, and open the panel to the position where it will stop.</p> <p>2 Slightly push up the knob at the center of the air filter and release the hook.</p> <p>3 Pull out the air filter downwards and remove it.</p>  	<ul style="list-style-type: none"> ■ The air filter is not marked for difference between the right and left sides. ■ The air filter can be set easily by inserting it along the guides. ■ Insert the air filter with the "FRONT"-marked face up. ■ Be sure to insert the hooks (at 2 lower positions) when mounting the air filter.

Step	Procedure	Points
3. Removing the titanium apatite photocatalytic air-purifying filter		
1	<p>The titanium apatite photocatalytic air-purifying filter is attached to the back of the air filter.</p> 	<p>■ The titanium apatite photocatalytic air-purifying filter is not marked for difference between the right and left sides.</p>
2	<p>Remove the titanium apatite photocatalytic air-purifying filter frame by bending the air filter and unfastening the projections from the air filter frame.</p> 	
3	<p>Remove the titanium apatite photocatalytic air-purifying filter from its frame (at 5 positions) by bending it.</p> 	





1.2 Removal of Front Panel


Procedure



Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Removing the front panel		
1	Put your fingers on the right and left projections of the front panel, and open the panel over the position where it will stop.	 <p>(R4312)</p>
2	Slide the left rotary shaft to the right and release it.	 <p>(R4313)</p>
3	When mounting the front panel, make sure that the projection is fitted in the guide before closing the panel.	 <p>(R4314)</p>
4	Slide the right rotary shaft to the left and release it.	 <p>(R4315)</p>

Step		Procedure	Points
5	Remove the front panel.	 (R4316)	Caution on Mounting ■ When mounting the front panel, fit the right and left rotary shafts one by one into the grooves and fully push them in position.

1.3 Removal of Front Grille





Procedure












Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Removing the service cover		Preparation <ul style="list-style-type: none"> Remove the front panel according to the "Removal of Front Panel." <ul style="list-style-type: none"> There are no switches to be set in the field.
1	Remove the screw of the service cover.	
2	Pull out the service cover diagonally down in the direction of the arrow.	
3	The figure shows the appearance of the inside.	
2. Removing the front grille		
1	Open the horizontal blades.	



Step		Procedure	Points
2	Remove the screw covers (one each at the right and left).	 <p>(R4321)</p>	
3	Remove the screws (one each at the right and left).	 <p>(R4322)</p>	<p>■ When installing the indoor unit, drive the screws with the horizontal blades open or removed.</p>
4	Release the 3 hooks at the top.	 <p>(R4323)</p>	
5	Put your fingers into the front grille to the depth and lift the grille up to unhook.	 <p>(R4324)</p>	

Step		Procedure	Points
6	Put your fingers into the front grille and lift the grille up to unfasten the centre hook.	 <p>(R4325)</p>	
7	Unfasten the right hook also by putting your fingers into the grille and lifting it.	 <p>(R4326)</p>	
8	Remove the front grille by tilting the upper part to the front (a) and lifting and pulling the lower part toward yourself (b).	 <p>(R4327)</p>  <p>(R4565)</p>	<p>Caution on Mounting</p> <ul style="list-style-type: none"> ■ When mounting the front grille, make sure that the hooks are fastened as they were. ■ When mounting the front grille, be sure not to get it stuck on the spacer of the drain pan.  <p>(R4590)</p>

1.4 Removal of Horizontal Blades and Vertical Blades


Procedure





Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.


Step	Procedure	Points
1. Removing the horizontal blade (large)		
1	Open the horizontal blade (large).	Cautions on Mounting <ul style="list-style-type: none"> ■ Mount the large horizontal blade to the upper side and the small horizontal blade to the lower side. Do not put them in the wrong place. ■ There is a key alignment mark at the right side. Insert the key first while turning. ■ After key alignment at the right side, mount the flap first to the centre fixing shaft and then to the left fixing shaft.
2	Unfasten the centre fixing shaft while bending the horizontal blade slightly.	
3	Unfasten the left fixing shaft of the horizontal blade (large).	
4	Unfasten the right fixing shaft of the horizontal blade (large).	






(R4329)






(R4330)



(R4331)

Step	Procedure	Points
2. Removing the horizontal blade (small)		
1	<p data-bbox="204 327 464 454">Remove the horizontal blade (small) while bending the fixed part at the centre slightly.</p>  <p data-bbox="1007 629 1066 651">(R4332)</p>	
2	<p data-bbox="204 790 448 813">Unfasten the left side.</p>  <p data-bbox="1007 1122 1066 1144">(R4333)</p>	
3	<p data-bbox="204 1290 456 1384">Unfasten the key type fixing shaft at the right side.</p>  <p data-bbox="1007 1597 1066 1619">(R4334)</p>	

Step	Procedure	Points
3. Removing the vertical blade		
1	Unfasten the hooks at the shaft mounting part by pressing them with a flat screwdriver.	
2	Unfasten the hooks at the upper 2 positions.	
3	Remove the vertical blade toward yourself.	<ul style="list-style-type: none"> ■ Six vertical blades are united as a set. (It is impossible to replace only one blade.) ■ The set of blades is not marked for difference between right and left.












1.5 Removal of Electrical Box




Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	<p>The figure shows the connections of wire harnesses.</p>  <p>(R4338)</p>	<p>Preparation</p> <ul style="list-style-type: none">■ Remove the front grille according to the “Removal of Front Grille.”
2	<p>Remove the screw of the electric wire retaining plate.</p>  <p>(R4339)</p>	
3	<p>Loosen the screws of the terminal board and disconnect the connecting wires.</p>  <p>(R4340)</p>	
4	<p>Remove the connector of the swing motor [S6].</p>  <p>(R4341)</p>	

Step		Procedure	Points
5	Remove the drip proof plate by removing the screw.	 <p>(R4343)</p>	<ul style="list-style-type: none"> Put any excess wires behind the power supply lead wire.
6	Replace the heat exchanger thermistor .	 <p>(R4344)</p>	<ul style="list-style-type: none"> Use care not to lose the retainer of thermistor. 
7	Disconnect the earth wire by removing the screw.	 <p>(R4345)</p>	
8	Remove the screw of the electrical box.	 <p>(R4346)</p>	



Step		Procedure	Points
9	Release the hook at the upper far side by pressing it from above and pulling the box toward yourself.	 <p>(R4347)</p>	
10	Lift up the electrical box and pull it toward yourself.	 <p>(R4348)</p>	<p>■ There is a hook also at the lower part of the back. When mounting the box, make sure that it is securely fastened.</p>
11	When the connector of the fan motor [S1] is removed, the electrical box can be dismantled.	 <p>(R4349)</p>	





1.6 Removal of PCB





Procedure










Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.



Step	Procedure	Points
1. Removing the shelter		
1	The figure shows the appearance of the electrical box.	Preparation ■ Remove the electrical box according to the “Removal of Electrical Box.”
2	Open the shelter (at the back).	
3	Push the upper centre of the shelter and unfasten the hooks at the upper 2 positions of the shelter.	
		
2. Removing the heat exchanger thermistor		
1	Remove the heat exchanger thermistor and disconnect the earth wire.	

Step	Procedure	Points
3. Removing the terminal strip board	 <p>(R4354)</p>	
1 Dismount the terminal board by removing the screw.		
4. Removing the signal receiver unit	 <p>(R4355)</p>  <p>(R4356)</p>  <p>(R4357)</p>	
1 Remove the signal receiver unit by unfastening the hooks (one each at the right and left).		
2 Remove the electrical box (cover) by unfastening the hooks at 2 positions.		

Step		Procedure	Points
3	Remove the electrical box by sliding it to the left.	 <p>(R4358)</p>	
4	Disconnect the wire harness.	 <p>(R4359)</p>	
5. Removing the signal receiver PCB			
1	Remove the signal receiver PCB by opening the hooks at 3 positions.	 <p>(R4361)</p>	
2	Disconnect the connector from the signal receiver PCB.	 <p>(R4362)</p>	

Step	Procedure	Points
6. Removing the INTELLIGENT EYE PCB		
1	<p>Remove the INTELLIGENT EYE fixing plate by twisting it clockwise.</p>  <p>(R4363)</p>	
2	<p>Remove the INTELLIGENT EYE PCB by unfastening the hook.</p>  <p>(R4364)</p>	
3	<p>Disconnect the connector from the INTELLIGENT EYE PCB.</p>  <p>(R4365)</p>	

Step	Procedure	Points
7. Removing the display PCB		
<p>1 The figure shows the connection of wire harness for the display PCB.</p> <p>2 Remove the display PCB by unfastening the 2 hooks.</p> <p>3 Disconnect the connector from the display PCB.</p>	 <p>Display PCB (R4366)</p>  <p>Hook (R4367)</p>  <p>Green LED 1 Yellow LED 2 Green LED 3 (R5233)</p>	
8. Removing the control PCB		
<p>1 Dismount the control PCB by removing the 2 hooks.</p>	 <p>Hook (R4369)</p>	

Step		Procedure	Points
2	Lift up the bottom of the control PCB and pull it out.		<ul style="list-style-type: none"> When mounting the control PCB, make sure that it is fixed by upper hooks.
3	The figures show the names of the PCB component parts.		<ul style="list-style-type: none"> Lead-free solder (PbF) is used for the PCB. When replacing the PCB, use the specific solder and soldering iron. <p>[S1] To DC fan motor [S6] To swing motor [S21] HA connector [S26] To display PCB [S28] To signal receiver PCB [S32] To heat exchanger thermistor [S35] To INTELLIGENT EYE PCB</p>

1.7 Removal of Drain Pan Unit





Procedure











Warning





Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1. Removing the drain pan unit		Preparation <ul style="list-style-type: none"> ■ Remove the electrical box according to the "Removal of Electrical Box." ■ Inserting of the wooden base facilitates the removing work. ■ Place a plastic bag under the drain pan to prevent from wetting the floor with remaining drain.
1	Lift up the indoor unit body slightly and pull out the drain hose. (In the case of left piping)	
2	Remove the screw at the left side of the drain pan.	
3	Remove the drain pan from the heat exchanger by pressing its right side and twisting its left side.	



Step		Procedure	Points
4	Remove the drain pan toward yourself from the indoor unit body.	 <p>(R4378)</p>  <p>Hook</p> <p>(R4379)</p>	Caution on Mounting <ul style="list-style-type: none"> ■ Make sure that the hook at the left side is fitted in the groove.
2. Removing the swing motor			
1	Remove the screw of the swing motor.	 <p>Swing motor</p> <p>(R4380)</p>	
2	Pull out the swing motor.	 <p>(R4381)</p>	

Step	Procedure	Points
3. Removing the crank assembly		
1	Remove the screw of the crank assembly.	 <p>Crank assembly</p> <p>(R4382)</p>
2	Remove the crank assembly by unfastening the hook.	 <p>Hook</p> <p>(R4383)</p>
3	The figure shows the position of the hook when the crank assembly has been removed.	 <p>Hook inserting part</p> <p>(R4384)</p>
4. How to connect the drain hose in right piping		
1	Pull out the drain hose from its right side connection.	 <p>Drain hose</p> <p>(R4385)</p>

Step		Procedure	Points
2	Remove the drain cap located at the left side of the drain pan unit.		
3	Insert the drain hose to the left side.		
4	Press the removed drain plug into the right side with an Allen wrench (4mm).		<p>■ Use a 4mm Allen wrench.</p> <p>Caution  Do not thrust in the drain plug with a sharp-pointed tool like a screwdriver. (The drain plug may be broken, resulting in water leakage.)</p>




1.8 Removal of Fan Motor

Procedure







Warning

Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1	Undo the fan motor lead wires from the hooks.	Preparation <ul style="list-style-type: none"> ■ Remove the drain pan unit according to the "Removal of Drain Pan Unit." ■ You can remove the fan motor with the heat exchanger left. It is easy to clean up the heat exchanger.
	 <p>(R4389)</p>	
2	Loosen and remove the fan rotor lock screw.	
	 <p>(R4390)</p>	
3	Remove the 2 screws of the fan motor fixing plate.	
	 <p>(R4391)</p>	

Step	Procedure	Points
4	Unfasten the hook (a) of the fan motor fixing plate with your thumb.	
5	Unfasten the hook (c).	
6	Remove the fan motor.	



1.9 Removal of Heat Exchanger

Procedure







Warning



Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1. Disconnecting the refrigerant pipe		Preparation
1	Remove the screws which fix the heat exchanger to the installation plate.	<ul style="list-style-type: none"> Remove the drain pan unit according to the "Removal of Drain Pan Unit."
2	Lift the indoor unit by a wooden base.	<p>Caution</p> <p>In pump-down work, be sure to stop the compressor before disconnecting the refrigerant pipe. If the refrigerant pipe is disconnected with the compressor being operated and the stop valve being open, air may be sucked in to generate an over-pressure in refrigeration cycle, thus resulting in pipe rupture or accidental injury.</p>
3	Lift up the indoor unit body slightly and pull out the drain hose. (In the case of left piping)	<ul style="list-style-type: none"> Place a plastic bag under the drain pan to prevent from wetting the floor with remaining drain. If the drain hose is embedded in the wall, disconnect the drain hose beforehand.
4	Disconnect the pipe connection with 2 pair of spanners.	<ul style="list-style-type: none"> Carry out the removal works with 2 pair of spanners. When the pipes are disconnected, protect the both openings of pipe side and unit side from entering of moisture.



Caution
From the point of view of environmental protection, be sure to use a vacuum pump for air purging.

Step	Procedure	Points
2. Removing the indoor unit		
1	Remove the indoor unit from the installation plate.  (R4400)	
3. Removing the heat exchanger		
1	Unfasten the hook of the pipe fixing plate at the back of the unit and pull out the pipe.  (R4401)	
2	Widen the auxiliary pipe by about 10-20 degrees.  (R4402)	
3	Unfasten the lower hook with a flat screwdriver.  (R4403)	<div data-bbox="1109 1500 1173 1556">!</div> Caution When dismantling or mounting the heat exchanger, be sure to wear gloves or wrap it with cloth before proceeding to the work. (You may be injured by the fins.)

Step		Procedure	Points
4	After unfastening the lower hooks, hold up the heat exchanger by its left side and lift it up toward yourself.	 <p>(R4404)</p>	<ul style="list-style-type: none"> ■ When mounting the heat exchanger, make sure that the hook (left) is fastened.
5	When the left side is lifted, the hook at the right side comes off position.	 <p>(R4405)</p>	
6	Remove the heat exchanger.		





1.10 Removal of Fan Rotor




Procedure






Warning

Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1. Removing the drip proof plate		Preparation <ul style="list-style-type: none"> Remove the heat exchanger according to the "Removal of Heat Exchanger."
1	Dismount the drip proof plate (right) by removing the 2 screws.  	
2	Unhook the fan motor wire harness. 	
3	Remove the 2 screws of the fan motor fixing plate. 	

Step		Procedure	Points
4	Unfasten the hook (a) of the fan motor fixing plate with your thumb and unfasten the hook (b).	 <p>(R4410)</p>	
5	The fan motor fixing plate can be removed from the unit when the hook (c) is unfastened.	<p>(R4411)</p>	
2. Removing the fan rotor			
1	Dislocate the fan rotor by sliding it to the right.	 <p>(R4412)</p>	
2	Remove the fan rotor by loosening the lock screw.	 <p>(R4413)</p>	

Step	Procedure	Points
3. Removing the bearing		
1	<p>Remove the screw of the drip proof plate (left).</p>  <p>(R4414)</p>	
2	<p>The drip proof plate can be removed when the hooks at 2 positions are unfastened.</p>  <p>Hook</p> <p>Hook</p> <p>(R4415)</p>	
3	<p>Press the rubber-made bearing with force from outside.</p>	
4	<p>Remove the bearing.</p>  <p>3</p> <p>4</p> <p>(R4416)</p>	

2. Outdoor Unit





2.1 ARXS 25/35 F

2.1.1 Removal of Panels and Fan Motor


Procedure




Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Features	 <p>(R7186)</p>  <p>(R3236)</p>  <p>(R7188)</p>  <p>(R7189)</p>	<ul style="list-style-type: none">■ Take care not to cut your finger by the fins of the heat exchanger.■ The stop valve cover is united with the shelter.■ When reassembling, make sure to fit the 5 hooks.


Step	Procedure	Points
2. Remove the panels.		
1	Loosen the 2 screws (right, left) and lift the top panel.	
2	Remove the drip proof plate.	
3	Loosen the 4 screws of the discharge grille.	




(R7190)



(R7191)








(R7192)











(R7193)

■ The discharge grille has 4 hooks.


Step	Procedure	Points
4	<p>Loosen the 8 screws of the front panel.</p> 	
5	<p>Undo the hooks. Pull and remove the front panel.</p> 	<ul style="list-style-type: none"> ■ The front panel has 4 hooks. ■ The fan motor is united with the front panel.

Step	Procedure	Points
3. Remove the fan motor.		
1	<p>Unscrew the washer-fitted nut (M10) of the propeller fan with a spanner.</p>  <p>Propeller fan (R7196)</p>	<p>■ The screw has clockwise winding.</p>
2	<p>Remove the propeller fan.</p>  <p>D-cut (R7197)</p>	<p>■ Align ▼ mark of the propeller fan with D-cut section of the motor shaft when reassembling.</p>
3	<p>Cut the clamp.</p>  <p>(R7198)</p>	


Step	Procedure	Points
4	Disconnect the fan motor connector (S70). 	
5	The illustration shows arrangement of the fan motor lead wire. 	
6	Loosen the fixing hooks and release the lead wire. 	■ Put the lead wire through the back of the motor when reassembling. (so as not to be entangled with the propeller fan) 
7	Loosen the 4 screws to remove the fan motor. 	■ DC fan motor

Step	Procedure	Points
8	<div>Loosen the screw to remove the fan motor fixing frame.</div> <div><p>Fan motor fixing frame</p><p>(R7204)</p><p>(R7205)</p><p>(R7206)</p></div>	<div></div> <div>■ When reassembling, fit the lower hook into the bottom frame.</div>


Step	Procedure	Points
4. Remove the right side panel.		
1	Loosen the 2 screws on the rear side.	
2	Unhook the outdoor air thermistor.	
3	Lift up the guard net to remove.	





(R7207)




(R7208)



(R7209)

Step	Procedure		Points
4	Loosen the 4 screws on the right side.	<div><p>(R7210)</p></div>	
5	Loosen the screw and lift the connection port to remove.	<div><p>(R7211)</p></div>	

Step	Procedure	Points
6	<p data-bbox="201 707 424 768">Lift up the right side panel to remove.</p>  <p data-bbox="1018 667 1078 689">(R7212)</p> <p data-bbox="914 1059 967 1081">Hook</p> <p data-bbox="1010 1227 1070 1249">(R7213)</p>	<ul style="list-style-type: none">■ When reassembling, make sure to fit the hook.


2.1.2 Removal of Electrical Box

Procedure




Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.


Step	Procedure	Points
<ul style="list-style-type: none"> Remove the top panel. Disconnect the connector for fan motor. 		
1. Remove the electrical box.		
1	Disconnect the 2 reactor harnesses.	<ul style="list-style-type: none"> When reassembling, coil the excessive lead wire and hang the loop on the hook.
2	Cut the clamp.	
3	Disconnect the connector for compressor motor (S30).	






(R7214)









(R7215)



(R7216)

Step	Procedure	Points
4	<p>Disconnect the connector for overload protector (S40).</p>  <p>(R7217)</p>	
5	<p>Disconnect the connector for electronic expansion valve coil (S20).</p>  <p>(R7218)</p>	
6	<p>Disconnect the connector for four way valve coil (S80).</p>  <p>(R7219)</p>	

Step	Procedure		Points
7	Release the discharge pipe thermistor.	 <p>Discharge pipe thermistor (R7220)</p>	<ul style="list-style-type: none">■ Pay attention so as not to lose the clip for thermistor.  <p>Thermistor Piping Clip (R3262)</p>
8	Cut the clamp.	 <p>(R7221)</p>	
9	Pull out the heat exchanger thermistor.	 <p>Heat exchanger thermistor (R7222)</p>	<ul style="list-style-type: none">■ Pay attention so as not to lose the clip.  <p>Clip (R3264)</p>




Step	Procedure	Points
10	<p data-bbox="201 219 421 275">Lift and remove the electrical box.</p>  <p data-bbox="1011 712 1070 730">(R7223)</p>	



2.1.3 Removal of Reactor and Partition Plate

Procedure




Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.




Step	Procedure	Points
<div>■ Remove the outer panels.</div> <div>■ Remove the electrical box.</div> <div>1. Remove the reactor.</div>		
1	<div>Loosen the screw.</div> <div>Lift and remove the reactor.</div> <div> (R7224)</div> <div> (R7225)</div>	
2. Remove the partition plate.		
1	<div>Loosen the 2 screws.</div> <div> (R7226)</div>	


Step	Procedure	Points
2	<p>The partition plate has a hook on the lower side. Lift and pull the partition plate to remove.</p>  <p>(R7227)</p>  <p>(R7228)</p>	<ul style="list-style-type: none">■ When reassembling, fit the lower hook into the bottom frame.

2.1.4 Removal of Sound Blanket

Procedure

 **Warning** Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
■ Remove the outer panels. ■ Remove the electrical box.		
1. Remove the sound blanket.		
1	Untie the strings and open the sound blanket.  (R7229)	
2	Lift and remove the sound blanket (body) as it is opened.  (R7230)	■ Since the piping ports on the sound blanket are torn easily, remove the blanket carefully.
3	Lift and remove the sound blanket (top).  (R7231)	

Step		Procedure	Points
4	Pull the sound blanket (inner) out.	 <p>(R7232)</p>	<ul style="list-style-type: none">■ Since the piping ports on the sound blanket are torn easily, remove the blanket carefully.




2.1.5 Removal of Four Way Valve




Procedure





Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the peripherals.		
1	Remove the electronic expansion valve coil.	
2	Remove the terminal cover.	<ul style="list-style-type: none">■ Remove the four way valve and the sheets of putty so as not to burn them.■ Be careful so as not to burn the compressor terminals or the name plate. <p>Make a note.</p>



Step		Procedure	Points
3	Loosen the screw of the four way valve coil.	 <p>(R7247)</p>	<p>⚠ Caution Be careful not to get yourself burnt with the pipes and other parts that are heated by the gas welding rod.</p> <p>⚠ Caution From the viewpoint of global environment protection, do not discharge the refrigerant gas in the atmosphere. Make sure to recover the refrigerant gas with the recovery system.</p>
4	Remove the sheets of putty.	 <p>(R7248)</p>	<p>Reassembling precautions</p> <ol style="list-style-type: none"> 1. Use non-oxidizing brazing method. If nitrogen gas is not available, braze the parts speedily. 2. Avoid deterioration of the gaskets due to carbonization of oil inside the four way valve or thermal influence. For this purpose, wrap the four way valve with wet cloth. Splash water over the cloth against becoming too hot (keep it below 120°C).
5	Heat up the brazed part and withdraw the piping with pliers. ■ Before working, make sure that the refrigerant is empty in the circuit. ■ Be sure to apply nitrogen replacement when heating up the brazed part.	 <p>(R7249)</p>	<p>■ In pulling the pipes, be careful not to over-tighten them with pliers. The pipes may get deformed.</p> <p>If the gas welding machine fails to remove the four way valve, take the steps below.</p> <ol style="list-style-type: none"> 1. Disconnect the brazed pipe sections that are readily easy to separate and join together later. 2. With a small copper tube cutter, cut off the internal pipes to easily take out the four way valve. <p>Note: Never use a metal saw. The sawdust may come into the circuit.</p>



Step	Procedure	Points
	<div data-bbox="199 219 470 548"><p> Warning If refrigerant gas leaks during the job, ventilate the room. (Bear in mind that if the refrigerant gas is exposed to open flames, noxious gas may be generated.)</p></div> <div data-bbox="486 219 1077 660"><p>(R7250)</p></div>	<ul style="list-style-type: none">■ Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.■ Be careful so as not to break the pipes by pressing it excessively by pliers when withdrawing it.



2.1.6 Removal of Compressor

Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the compressor.		
1	<p>Unscrew the nut of the compressor.</p> <ul style="list-style-type: none"> Before working, make sure that the refrigerant is empty in the circuit. Be sure to apply nitrogen replacement when heating up the brazed part. 	 <p>(R7251)</p> <p>Warning Ventilate when refrigerant leaks during the work. (If refrigerant contacts fire, it will cause to arise toxic gas.)</p> <ul style="list-style-type: none"> Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries. Be careful so as not to burn the compressor terminals or the name plate. Be careful so as not to burn the heat exchanger fin. <p>Warning Since it may happen that refrigeration oil in the compressor will catch fire, prepare wet cloth so as to extinguish fire immediately.</p> <p>In case of the difficulty with gas brazing machine</p> <ol style="list-style-type: none"> Disconnect the brazed part where is easy to disconnect and restore. Cut pipes on the main unit by a miniature copper tube cutter in order to make it easy to disconnect. <p>Cautions for restoration</p> <ol style="list-style-type: none"> Restore the piping by non-oxidation brazing. It is required to prevent the carbonization of the oil inside the four way valve and the deterioration of the gaskets affected by heat. For the sake of this, wrap the four way valve with wet cloth and provide water so that the cloth will not be dried and avoid excessive heating. (Keep below 120°C) <p>Note: Do not use a metal saw for cutting pipes by all means because the sawdust come into the circuit.</p>
2	<p>Heat up the brazed part of the discharge side and disconnect.</p>	 <p>(R7252)</p>

Step		Procedure	Points
3	Heat up the brazed part of the suction side and disconnect.	 (R7253)	
4	Lift the compressor up and remove it.	 (R7254)	


2.1.7 Removal of PCB

Procedure




Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.


Step	Procedure	Points
1. Remove the PCB.		
1	Feature of the PCB	<ul style="list-style-type: none"> ■ You can remove the PCB when you disconnect the read wires on the terminal board without removing the electrical box. ■ PbF (Pb free brazing) is adopted.
2	Loosen the screw on the terminal strip board.	
3	Release the 2 earth terminals.	






(R7255)




(R7256)



(R7257)

Step	Procedure	Points
4	Loosen the 4 screws.	
	 <p>(R7258)</p>	
5	Undo the 3 hooks on the upper side.	
	 <p>(R7259)</p>	
6	Lift and pull out the PCB.	
	 <p>(R3291)</p>	

Step	Procedure		Points
7	Feature of the PCB S70: fan motor S80: four way valve S90: thermistor (outdoor air, heat exchanger, discharge pipe)	 <p>The diagram shows the internal PCB of an outdoor unit. At the top, a thermistor (S90) is connected to a terminal. Below it, a fan motor (S70) is shown. At the bottom, a four-way valve (S80) is connected to four pipes. A glass fuse (3.15 A) is located near the top right, and an LED A is at the bottom center. Wires connect these components to the PCB.</p> <p>(R7260)</p>	■ See page 11 for detail.




2.2 ARXS 50 E




2.2.1 Removal of the Panels and Plates




Procedure






Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the panels and plates.		
1	Loosen the 4 screws and lift the top panel .	<p>■ Take care not to cut your finger by the fins of the heat exchanger.</p>
	 <p>(R5243)</p>  <p>(R5244)</p>	
2	Loosen the 4 screws and remove the discharge grille .	
	 <p>(R5245)</p>	

Step	Procedure	Points
	<div data-bbox="518 257 1045 660">  <p>(R5246)</p> </div> <div data-bbox="518 728 1061 1142">  <p>Front panel</p> <p>(R5247)</p> </div> <div data-bbox="502 1209 1045 1624">  <p>Clamp plate</p> <p>① Push the front panel.</p> <p>② Lift the clamp plate upwards.</p> <p>(R5248)</p> </div>	<p>■ The front grille has 4 hooks. Slide the discharge grille upwards and remove it.</p>

Step	Procedure	Points
5	<p>Undo the left side hooks, and then the right side hook. Remove the front panel.</p>  <p>(R5249)</p>  <p>(R5250)</p>  <p>(R5251)</p>	<ul style="list-style-type: none"> ■ Lift the front panel and remove it while pushing the left side panel inwards. ■ Lift the front panel and undo the right side hook. ■ Fit the right side of the front panel first when installing.

Step	Procedure	Points
2. Remove the stop valve cover .	<div data-bbox="193 280 478 851"> <p>1 Loosen the screw of the stop valve cover.</p> </div> <div data-bbox="531 315 1037 869">  <p>Stop valve cover</p> <p>(R5252)</p> </div> <div data-bbox="193 851 478 1456"> <p>2 Pull down the stop valve cover to undo the hooks and remove it.</p> </div> <div data-bbox="531 920 1026 1464">  <p>(R5253)</p> </div> <div data-bbox="531 1514 1026 2098">  <p>(R5254)</p> </div>	<p>■ The stop valve cover has 6 hooks.</p>




2.2.2 Removal of the Fan Motor / Propeller Fan



Procedure








Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<p>■ Remove the top panel and the front panel.</p> <p>1. Remove the electrical box cover.</p>	 <p>(R5255)</p>	<p>■ This procedure is not necessary to remove the propeller fan only.</p>
<p>2. Undo the 2 hooks and remove it.</p>	 <p>(R5256)</p>	<p>■ The hooks have been released since the front panel was removed.</p>
<p>3. Release the 4 hooks of the electrical box cover and remove it.</p>	 <p>(R5257)</p>	

Step	Procedure		Points
		 <p>(R5258)</p>	
2. Remove the fan motor.			
1	Disconnect the connector for fan motor (S70).	 <p>(R5259)</p>	

Step	Procedure	Points
2	<p>The illustration shows arrangement of the fan motor lead wire.</p>  <p>Fan motor lead wire</p> <p>(R5260)</p>	
3	<p>Unscrew the washer-fitted nut (M10) of the propeller fan with a spanner.</p>  <p>Propeller fan</p> <p>(R5262)</p>  <p>(R5263)</p>	<p>■ Align ▼ mark of the propeller fan with D-cut section of the motor shaft when reassembling.</p>

Step	Procedure	Points
4	Remove the 4 screws from the fan motor.  <p>(R5264)</p>	
5	Pull the fan motor out.  <p>(R5265)</p>	<ul style="list-style-type: none"> Put the lead wire through the back of the motor when reassembling (so as not to be entangled with the propeller fan).




2.2.3 Removal of the Electrical Box




Procedure









Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points	
■ Remove the top panel and the front panel.			
1. Remove the shield plate.			
1	Loosen the 2 screws.	 <p>(R5266)</p>	
2	Slide the cover upward to undo the one hook on the bottom left, and then remove the plate.	 <p>(R5267)</p>	
3	Disconnect the 2 power supply cables and the 1 earth wire.	 <p>(R5268)</p>	

Step	Procedure	Points
4	Disconnect the 2 earth wires. 	
5	Loosen the 3 screws of the right side panel. 	
6	Loosen the fixing screw of the electrical box. 	

Step	Procedure	Points
	 	<p>■ Insert the 2 hooks of the lower part and the 1 hook of the upper back when reassembling.</p>
7	<p>Disconnect the connectors of the front side.</p> <p>S20: electronic expansion valve S40: overload protector S80: four way valve S90: thermistors (discharge pipe, outdoor air, heat exchanger)</p> 	
8	<p>Disconnect the relaying wire connector for the compressor.</p> 	




Step	Procedure		Points
9	Release the clamp and undo the wire from the hook.	 <p>(R5278)</p>	
10	Lift the electrical box and remove it.	 <p>(R5279)</p>	





2.2.4 Removal of the PCB

Procedure






Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
■ Remove the electrical box.		
1. Remove the PCB.		
1	Disconnect the connectors for the control PCB (S52, S102).	
		
2	Undo the 4 clamps by pliers.	
		
3	Loosen the fixing screw of the cable way board and disconnect the earth wire.	
		

Step		Procedure	Points
4	Undo the hook on the right.	 <p>(R5283)</p>	
5	Open the cable way board.	 <p>(R5284)</p>	
6	Disconnect the harnesses.	 <p>(R5285)</p>	1: Black 2: White 3: Red L1: Black L2: Brown N1: White N2: Blue
7	Disconnect the 2 harnesses for the reactor (HR1, HR2).	 <p>(R5286)</p>	

Step	Procedure	Points
8	Loosen the 3 fixing screws for the main PCB.	
9	Undo the 4 hooks.	
10	Lift up and remove the PCB.	






2.2.5 Removal of the Sound Blanket





Procedure



Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the sound blanket (back). 	
2	Remove the sound blanket (outer). 	■ Since the piping ports on the sound blanket (outer) are torn easily, remove the blanket carefully.
3	Remove the sound blanket (top-upper). 	

Step	Procedure	Points
4	<p>Remove the sound blanket (top-lower).</p> 	
5	<p>Remove the sound blanket (inner).</p> 	<ul style="list-style-type: none"> ■ Since the piping ports on the sound blanket (inner) are torn easily, remove the blanket carefully.
6	<p>Release the discharge pipe thermistor.</p> 	<ul style="list-style-type: none"> ■ Pay attention to the direction of the clip so as not to touch the lead wire of the thermistor when reassembling.
7	<p>Cut the clamp by nippers. Disconnect the outdoor heat exchanger thermistor.</p> 	<ul style="list-style-type: none"> ■ Clamps should be always available. Fix it as it was before.

2.2.6 Removal of the Four Way Valve




Procedure




Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the electronic expansion valve coil .	<ul style="list-style-type: none"> ■ The illustration is for heat pump models as representative.
2	Loosen the screw of the four way valve coil .	<ul style="list-style-type: none"> ■ Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries. ■ Be careful so as not to break the pipes by pressing it excessively by pliers when withdrawing it.
3	Heat up the brazed part of the four way valve and disconnect. <ul style="list-style-type: none"> ■ Be sure to apply nitrogen replacement when heating up the brazed part. 	<p>Caution</p> <p>Be careful about the four way valve, pipes and so on, which were heated up by a gas brazing machine, so as not to get burnt your hands.</p> <p>Cautions for restoration</p> <ol style="list-style-type: none"> 1. Restore the piping by non-oxidation brazing. Braze it quickly when no nitrogen gas can be used. 2. It is required to prevent the carbonization of the oil inside the four way valve and the deterioration of the gaskets affected by heat. For the sake of this, wrap the four way valve with wet cloth and provide water so that the cloth will not be dried and avoid excessive heating. (Keep below 120°C)



Step		Procedure	Points
4	Heat up every brazed part in turn and disconnect.	 <p>(R5299)</p>	<p>In case of the difficulty with gas brazing machine</p> <ol style="list-style-type: none">1. Disconnect the brazed part where is easy to disconnect and restore.2. Cut pipes on the main unit by a miniature copper tube cutter in order to make it easy to disconnect. <p>■ i Note: Do not use a metal saw for cutting pipes by all means because the sawdust come into the circuit.</p>




2.2.7 Removal of the Compressor




Procedure






Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the terminal cover.	
2	Disconnect the lead wires of the compressor.	<p>Be careful so as not to burn the compressor terminals or the name plate.</p> <p>Make a note.</p> <div style="border: 1px solid black; padding: 5px; display: inline-block;"> U V W </div> <p>U : red V : yellow W : blue</p>



Step	Procedure	Points
3	<p>Release the clamp by pliers to detach the wire harness for the compressor.</p>  <p>(R5304)</p>	
4	<p>Remove the putty.</p> <ul style="list-style-type: none"> ■ Before working, make sure that the refrigerant is empty in the circuit. ■ Be sure to apply nitrogen replacement when heating up the brazed part.  <p>(R5305)</p>	<ul style="list-style-type: none"> ■ The illustration is for 50 class heat pump models as representative.
5	<p>Heat up the brazed parts indicated by the arrows.</p>  <p>(R5306)</p>	<ul style="list-style-type: none"> ■ The illustration is for 50 class heat pump models as representative. <p>⚠ Warning Ventilate when refrigerant leaks during the work. (If refrigerant contacts fire, it will cause to arise toxic gas.)</p> <ul style="list-style-type: none"> ■ Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries. ■ Be careful so as not to burn the compressor terminals or the name plate. ■ Be careful so as not to burn the heat exchanger fin. <p>⚠ Warning Since it may happen that refrigeration oil in the compressor will catch fire, prepare wet cloth so as to extinguish fire immediately.</p>

Step	Procedure	Points
6	<p>Unscrew the nut of the compressor.</p>  <p>(R5307)</p>	
	<ul style="list-style-type: none"> Before working, make sure that the refrigerant is empty in the circuit. Be sure to apply nitrogen replacement when heating up the brazed part. 	
7	<p>Heat up the brazed part of the discharge side and disconnect.</p>  <p>(R5308)</p>	<p>Warning Ventilate when refrigerant leaks during the work. (If refrigerant contacts fire, it will cause to arise toxic gas.)</p> <ul style="list-style-type: none"> Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries. Be careful so as not to burn the compressor terminals or the name plate.
8	<p>Heat up the brazed part of the suction side and disconnect.</p>  <p>(R5309)</p>	<ul style="list-style-type: none"> Be careful so as not to burn the heat exchanger fin.
9	<p>Lift the compressor up and remove it.</p>	<p>Warning Since it may happen that refrigeration oil in the compressor will catch fire, prepare wet cloth so as to extinguish fire immediately.</p>

Part 8

Others

1. Others	218
1.1 Test Run from the Remote Controller	218
1.2 Jumper Settings	219
1.3 Application of Silicon Grease to a Power Transistor and a Diode Bridge.....	220

1. Others

1.1 Test Run from the Remote Controller

For Heat pump

In cooling mode, select the lowest programmable temperature; in heating mode, select the highest programmable temperature.

- Trial operation may be disabled in either mode depending on the room temperature.
- After trial operation is complete, set the temperature to a normal level.
(26°C to 28°C in cooling mode, 20°C to 24°C in heating mode)
- For protection, the system disables restart operation for 3 minutes after it is turned off.

For Cooling Only

Select the lowest programmable temperature.


- Trial operation in cooling mode may be disabled depending on the room temperature.
Use the remote control for trial operation as described below.
- After trial operation is complete, set the temperature to a normal level (26°C to 28°C).
- For protection, the machine disables restart operation for 3 minutes after it is turned off.

Trial Operation and Testing

1. Measure the supply voltage and make sure that it falls in the specified range.
 2. Trial operation should be carried out in either cooling or heating mode.
 3. Carry out the test operation in accordance with the Operation Manual to ensure that all functions and parts, such as louver movement, are working properly.
- The air conditioner requires a small amount of power in its standby mode. If the system is not to be used for some time after installation, shut off the circuit breaker to eliminate unnecessary power consumption.
 - If the circuit breaker trips to shut off the power to the air conditioner, the system will restore the original operation mode when the circuit breaker is opened again.

Trial operation from Remote Controller

- (1) Press ON/OFF button to turn on the system.
- (2) Simultaneously press centre of TEMP button and MODE buttons.
- (3) Press MODE button twice.
("T" will appear on the display to indicate that Trial Operation mode is selected.)
- (4) Trial run mode terminates in approx. 30 minutes and switches into normal mode. To quit a trial operation, press ON/OFF button.




1.2 Jumper Settings

1.2.1 When Two Units are Installed in One Room

When two indoor units are installed in one room, the two wireless remote controllers can be set for different addresses.

How to set the different addresses

- Control PCB of the indoor unit
 - (1) Remove the front grille. (3 screws)
 - (2) Remove the electrical box (1-screw).
 - (3) Remove the drip proof plate. (4 tabs)
 - (4) Cut the address jumper **JA** on the control PCB.
- Wireless remote controller
 - (1) Slide the front cover and take it off.
 - (2) Cut the address jumper **J4**.



1.2.2 Jumper Setting

Jumper (On indoor control PCB)	Function	When connected (factory set)	When cut
JC	Power failure recovery function	Auto-restart	Unit does not resume operation after recovering from a power failure. Timer ON-OFF settings are cleared.
JB	Fan speed setting when compressor is OFF on thermostat. (effective only at cooling operation)	Fan speed setting ; Remote controller setting	Fan rpm is set to "0" <Fan stop>

1.3 Application of Silicon Grease to a Power Transistor and a Diode Bridge

Applicable Models

All outdoor units using inverter type compressor for room air conditioner.

When the printed circuit board of an outdoor unit is replaced, it is required that silicon grease (*1) is certainly applied to the heat radiation part (the contact point to the heat radiation fin) of the power transistor and diode bridge.

*1: Parts number of the silicon grease – 1172698 (Drawing number 3FB03758-1)


Details

The silicon grease is an essential article for encouraging the heat radiation of the power transistor and the diode bridge. Applying the paste should be implemented in accordance with the following instruction.

Remark: There is the possibility of failure with smoke in case of bad heat radiation.

- To completely wipe off the old silicon grease on a heat radiation fin.
- To evenly apply the silicon grease to the whole.
- Do not have any foreign object such as solder or paper waste between the power transistor, the diode bridge and the heat radiation fin.
- To firmly tighten the screws of the power transistor and the diode bridge, and to surely contact to the heat radiation fin without any gap.

<Example>



(R7100)

Part 9


Appendix

1. Piping Diagrams.....	222
1.1 Indoor Units.....	222
1.2 Outdoor Units	223
2. Wiring Diagrams.....	224
2.1 Indoor Units.....	224
2.2 Outdoor Units	225

1. Piping Diagrams


1.1 Indoor Units

ATXS25/35EV1B7



4D047912J


ATXS50EV1B7



4D047913F

1.2 Outdoor Units


ARXS25/35F3V1B



REFRIGERANT FLOW
 ---> COOLING
 —> HEATING

3D047316J

ARXS50E3V1B




REFRIGERANT FLOW
 —> COOLING
 ---> HEATING

3D051637H

2. Wiring Diagrams


2.1 Indoor Units

ATXS25/35EV1B7



3D051268B


ATXS50EV1B7




3D051652A

2.2 Outdoor Units

ARXS25/35F3V1B



ARXS50E3V1B



Index

Numerics

00	81
3-minute standby	29, 35

A

A1	82
A5	83
A6	85
AC1	12
AC2	12
address setting jumper	8
adjusting the airflow direction	59
air filter	138
airflow control	19
airflow direction control	18
ARC433 series	78
AUTO · DRY · COOL · HEAT · FAN operation	57
automatic operation	21
auto-restart	8, 29, 219
auto-swing	18

C

C4	87
C9	87
capacitor voltage check	133
care and cleaning	68
centralized control	8
check	
capacitor voltage check	133
discharge pressure check	131
electronic expansion valve check	128
fan motor connector output check	128
four way valve performance check	129
installation condition check	131
inverter units refrigerant system check	132
main circuit electrolytic capacitor check	135
outdoor unit fan system check	132
power supply waveforms check	132
power transistor check	133
thermistor resistance check	130
turning speed pulse input on the outdoor unit PCB	
check	135
check No.01	128
check No.04	128
check No.05	129
check No.06	130
check No.07	131
check No.08	131
check No.09	132
check No.10	132
check No.11	132
check No.12	133
check No.13	133
check No.14	135
check No.15	135

clamp plate	195
comfort airflow mode	18
compressor	189, 213
compressor lock	94
compressor motor	178
compressor overload	93
compressor protection function	35
compressor system sensor abnormality	105
connectors	8, 10, 12
control PCB	9, 11, 155
crank assembly	159
CT or related abnormality	110

D

DC fan lock	95
DC voltage / current sensor abnormality	109
defrost control	40
diagnosis mode	79
diode bridge	220
discharge grille	170, 194
discharge pipe temperature control	36, 43, 101
discharge pipe thermistor	30, 42, 113, 180, 210
discharge pressure check	131
display PCB	9, 155
drain hose	159
drain pan unit	157
drip proof plate	149, 170

E

E1	91, 92
E5	93
E6	94
E7	95
E8	96, 97
EA	99
earth	149, 203
ECONO mode	24
ECONO operation	63
electrical box	148, 178, 205
electrical box cover	198
electrical box temperature rise	114
electronic expansion valve check	128
electronic expansion valve coil	179, 186, 211
electronic expansion valve control	41
error codes	
00	81
A1	82
A5	83
A6	85
C4	87
C9	87
E1	91, 92
E5	93
E6	94
E7	95

E8	96, 97
EA	99
F3	101
F6	103
H0	105, 106
H6	108
H8	109, 110
H9	112
J3	112
J6	112
L3	114
L4	116, 118
L5	120
P4	112
U0	122, 124
U2	126
U4	88
U7	127
UA	90
error codes and description	81

F

F3	101
F6	103
facility setting jumper	10, 46
fan control	39
fan motor	161, 173, 199
fan motor (DC motor) or related abnormality	85
fan motor connector output check	128
fan motor fixing frame	174
fan rotor	166
fan speed control	19
fan speed setting	8, 219
field setting switch	12
filter PCB	11
filters	
mold proof air filter	28
titanium apatite photocatalytic air-purifying filter	28
forced operation mode	45
forced operation ON/OFF switch	8, 12
four way valve	186, 211
four way valve abnormality	99
four way valve coil	179, 211
four way valve operation compensation	35
four way valve performance check	129
four way valve switching	34
freeze-up protection control	38, 83
frequency control	16, 32
frequency principle	16
front grille	142
front panel	140, 171, 195
FU1	8, 10, 12
FU2	10, 12
FU3	10, 12
function of thermistor	30
functions	2
fuse	8, 10, 12

H

H0	105, 106
----------	----------

H6	108
H8	109, 110
H9	112
HA	8, 156
Hall IC	19, 85
HC3	10
HC4	10
heat exchanger	163, 194
heat exchanger thermistor	87, 149, 151, 180
heating peak-cut control	38
high pressure control	83
high pressure control in cooling	103
HL3	10
HN3	10
horizontal blades	145
hot-start function	28
HR1	12, 207
HR2	12, 207

I

indoor heat exchanger thermistor	30
indoor unit PCB abnormality	82
input current control	37
input over current detection	96
installation condition check	131
instruction	49
insufficient gas	122
insufficient gas control	44
INTELLIGENT EYE	25
INTELLIGENT EYE operation	64
INTELLIGENT EYE sensor PCB	9, 154
inverter POWERFUL operation	27
inverter principle	16
inverter units refrigerant system check	132

J

J3	112
J4	219
J6	112
J8	10
JA	8, 219
JB	8, 219
JC	8, 219
jumper settings	219

L

L3	114
L4	116, 118
L5	120
LED A	8, 10, 12
LED1	8
LED2	8
LED3	8
liquid compression protection function 2	39
lower limit for cooling	12

M

main circuit electrolytic capacitor check	135
main PCB	13
mode hierarchy	31
mold proof air filter	28

N

name of parts	51
NIGHT SET mode	23

O

OL activation	93
ON/OFF button on indoor unit	28
opening limit	42
operation lamp	76
outdoor air temperature thermistor	113
outdoor heat exchanger thermistor	30, 113, 210
outdoor unit fan system check	132
outdoor unit PCB abnormality	91
OUTDOOR UNIT QUIET operation	62
output over current detection	120
over current	44, 96, 120
overload	44, 93
overload protector	10, 179
over-voltage detection	126

P

P4	112
partition plate	182
PCB	151, 191, 206
PI control	33
piping diagrams	222
position sensor abnormality	108
power failure recovery function	8, 219
power supply waveforms check	132
power transistor	220
power transistor check	133
power-airflow dual flaps	18
POWERFUL operation	27, 61
POWERFUL operation mode	45
preheating operation	34
preparation before operation	54
pressure equalization control	42
printed circuit board (PCB)	
control PCB	9, 11, 155
display PCB	9, 155
filter PCB	11
INTELLIGENT EYE sensor PCB	9, 154
main PCB	13
service monitor PCB	13
signal receiver PCB	9, 153
problem symptoms and measures	77
programme dry function	20
propeller fan	172, 200

R

radiation fin temperature rise	116
radiation fin thermistor	113
reactor	182
reactor harnesses	178
remote controller	78
room temperature thermistor	87
RTH1	8

S

S1	8, 156
S10	10, 12

S101	12
S102	12, 206
S11	10
S20	10, 12, 179, 204
S21	8, 156
S26	8, 156
S27	8
S28	8, 156
S29	8
S30	10, 178
S32	8, 156
S35	8, 156
S36	8
S40	10, 12, 179, 204
S51	12
S52	12, 206
S6	8, 156
S70	10, 12, 173, 193, 199
S80	10, 12, 179, 193, 204
S90	10, 12, 193, 204
safety precautions	49
self-diagnosis digital display	28
sensor malfunction detection	44
service check function	78
service monitor PCB	13
shelter	151, 169, 198
shield plate	202
signal receiver PCB	9, 153
signal receiver unit	152
signal receiving sign	28
signal transmission error	88
signal transmission error (on outdoor unit PCB)	
.....	127
silicon grease	220
sound blanket	184, 209
specifications	4
starting operation control	42
stop valve cover	169, 197
SW1	8, 12
SW4	12
swing motor	158
switch A	12
switch B	12, 46
switch C	12

T

terminal cover	186, 213
terminal strip	152
terminal strip board	191
test run	218
thermistor	
discharge pipe thermistor	
.....	30, 42, 113, 180, 210
heat exchanger thermistor	87, 149, 151, 180
indoor heat exchanger thermistor	30
outdoor air temperature thermistor	113
outdoor heat exchanger thermistor	
.....	30, 113, 210
radiation fin thermistor	113
room temperature thermistor	87
thermistor or related abnormality (indoor unit)	87

thermistor or related abnormality (outdoor unit) ...	112
thermistor resistance check	130
thermostat control	22
TIMER operation	66
titanium apatite photocatalytic air-purifying filter	28
top panel	170, 194
troubleshooting	71, 81
troubleshooting with LED indication	76
turning speed pulse input on the outdoor unit PCB check	135

U

U0	122, 124
U2	126
U4	88
U7	127
UA	90
unspecified voltage	90

V

V1	8, 10
V11	12
V2	10, 12
V3	10, 12
V5	12
V6	12
varistor	8, 10, 12
vertical blades	145
voltage detection function	45

W

wide-angle louvres	18
wiring diagrams	224

Drawings & Flow Charts

A		
ARC433 series	78	
automatic airflow control	19	
automatic operation	21	
auto-swing	18	
C		
capacitor voltage check	133	
comfort airflow mode	18	
compressor lock	94	
compressor protection function	35	
compressor system sensor abnormality	105	
control PCB	9, 11	
CT or related abnormality	110	
D		
DC fan lock	95	
DC voltage / current sensor abnormality	109	
defrost control	40	
diagnosis mode	79	
diode bridge	220	
discharge pipe temperature control	36, 101	
discharge pressure check	131	
display PCB	9	
E		
ECONO mode	24	
electrical box temperature rise	114	
electronic expansion valve check	128	
electronic expansion valve control	41	
F		
facility setting jumper	46	
fan motor (DC motor) or related abnormality	85	
fan motor connector output check	128	
filter PCB	11	
four way valve abnormality	99	
four way valve performance check	129	
freeze-up protection control	38	
freeze-up protection control or high pressure control	83	
frequency control	32	
frequency principle	16	
function of thermistor	30	
H		
heating peak-cut control	38	
high pressure control in cooling	103	
I		
indoor unit PCB abnormality	82	
input current control	37	
input over current detection	96	
installation condition check	131	
insufficient gas	122	
insufficient gas control	44	
INTELLIGENT EYE	25	
INTELLIGENT EYE sensor PCB	9	
inverter features	17	
inverter POWERFUL operation	27	
inverter units refrigerant system check	132	
J		
jumper settings	219	
M		
main circuit electrolytic capacitor check	135	
main PCB	13	
mode hierarchy	31	
N		
NIGHT SET mode	23	
O		
OL activation (compressor overload)	93	
ON/OFF button on indoor unit	28	
operation lamp	76	
outdoor unit fan system check	132	
outdoor unit PCB abnormality	91	
output over current detection	120	
over-voltage detection	126	
P		
pipings diagrams		
ARXS25/35F3V1B	223	
ARXS50E3V1B	223	
ATXS25/35EV1B7	222	
ATXS50EV1B7	222	
position sensor abnormality	108	
power supply waveforms check	132	
power transistor	220	
power transistor check	133	
POWERFUL operation	27	
programme dry function	20	
R		
radiation fin temperature rise	116	
remote controller	78	
S		
service check function	78	
service monitor PCB	13	
signal receiver PCB	9	
signal transmission error (between indoor and outdoor units)	88	
signal transmission error (on outdoor unit PCB)	127	
silicon grease	220	

T

target discharge pipe temperature control	43
thermistor or related abnormality (indoor unit)	87
thermistor or related abnormality (outdoor unit) ...	112
thermistor resistance check	130
thermostat control	22
trial operation from remote controller	218
turning speed pulse input	
on the outdoor unit PCB check	135

U

unspecified voltage	
(between indoor and outdoor units)	90

W

wiring diagrams	
ARXS25/35F3V1B	225
ARXS50E3V1B	225
ATXS25/35EV1B7	224
ATXS50EV1B7	224

Warning

- Daikin Industries, Ltd.'s products are manufactured for export to numerous countries throughout the world. Daikin Industries, Ltd. does not have control over which products are exported to and used in a particular country. Prior to purchase, please therefore confirm with your local authorised importer, distributor and/or retailer whether this product conforms to the applicable standards, and is suitable for use, in the region where the product will be used. This statement does not purport to exclude, restrict or modify the application of any local legislation.
- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorised parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Read the User's Manual carefully before using this product. The User's Manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any enquiries, please contact your local importer, distributor and/or retailer.

Cautions on product corrosion

1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided. If you need to install the outdoor unit close to the sea shore, contact your local distributor.



JMI-0107



JQA-1452

About ISO 9001

ISO 9001 is a plant certification system defined by the International Organization for Standardization (ISO) relating to quality assurance. ISO 9001 certification covers quality assurance aspects related to the "design, development, manufacture, installation, and supplementary service" of products manufactured at the plant.



EC99J2044

About ISO 14001

ISO 14001 is the standard defined by the International Organization for Standardization (ISO) relating to environmental management systems. Our group has been acknowledged by an internationally accredited compliance organisation as having an appropriate programme of environmental protection procedures and activities to meet the requirements of ISO 14001.

Dealer

DAIKIN INDUSTRIES, LTD.

Head Office:
Umeda Center Bldg., 2-4-12, Nakazaki-Nishi,
Kita-ku, Osaka, 530-8323 Japan

Tokyo Office:
JR Shinagawa East Bldg., 2-18-1, Konan,
Minato-ku, Tokyo, 108-0075 Japan

http://www.daikin.com/global_ac/

©All rights reserved