



SIE-86

Inverter Pair FTK(X)-J / RK(X)-J Series

●Cooling Only

Indoor Unit

FTK25JV1NB
FTK35JV1NB

Outdoor Unit

RK25JV1NB
RK35JV1NB




●Heat Pump


Indoor Unit

FTX25JV1NB
FTX35JV1NB


Outdoor Unit

RX25JV1NB
RX35JV1NB





1. Introduction	v
1.1 Safety Cautions	v
Part 1 List of Function	1
1. Functions.....	2
1.1 Indoor Unit and Outdoor Unit.....	2
Part 2 Printed Circuit Board Connector Wiring Diagram	3
1. Printed Circuit Board Connector Wiring Diagram and Name	4
1.1 FTK25/35J Series, FTX25/35J Series	4
1.2 RK25/35J Series, RX25/35J Series.....	6
Part 3 Main Function.....	9
1. General Functionality	10
1.1 Functions of Thermistors.....	10
1.2 Operating Modes	12
1.3 Frequency Principle.....	13
1.4 Defrost Control	15
1.5 Forced Operation Mode.....	16
1.6 Wide-angle Flaps, Diffuser, Louvres and Autoswing.....	17
1.7 Fan Speed Control for Indoor Units.....	19
1.8 Fan Speed Control for Outdoor Units	20
1.9 General Functions	21
1.10 Intelligent Eye (J type).....	23
1.11 Good Sleep Cooling Control (J Type).....	25
1.12 Automatic Operation.....	26
1.13 Input Current Control (H / J Type)	27
1.14 Freeze Protection Function in Cooling. (H / J Type).....	28
1.15 Peak-Cut Control Function (H / J Type)	29
1.16 Four-Way Valve Function Compensation (H / J Type)	30
1.17 Compressor Protection Function (H / J Type)	31
1.18 Wet Operation Protection (H / J Type)	32
1.19 Dew Condensation Sweating Prevention Function (H / J type).....	33
Part 4 System Configuration.....	35
1. Instruction.....	36
1.1 FTK25 / 35J, FTX25 / 35J	36
Part 5 Service Diagnosis.....	51
1. Caution for Diagnosis	52
1.1 Troubleshooting with The Operation Lamp	52
2. Problem Symptoms and Measures	54
3. Service Check Function	55
3.1 ARC423 Series.....	55
4. Code Indication on The Remote Controller.....	56
4.1 Error Codes and Description of Fault	56
5. Troubleshooting	57
5.1 Indoor Units	57

**SIE-86**

5.2	Outdoor Units	58
5.3	Faulty PCB	59
5.4	Operation Shutdown Due to High-Pressure Control or Freeze-Up Protection (Thermistor Activation)	60
5.5	Operation Halt Due to Fan Motor (AC Motor) or Related Abnormality. .	61
5.6	Operation Halt Due to Detection of Thermistor or Related Abnormality	62
5.7	Faulty Indoor Unit PCB.....	63
5.8	Faulty Indoor Unit PCB.....	64
5.9	Power Supply Abnormalities or Faulty Indoor Printed Circuit Boards ...	65
5.10	Signal Transmission Error (Between Indoor and Outdoor Units)	66
5.11	Operation Halt Due to Detection of CT Error.....	67
5.12	Operation Halt Due to Thermistor Error or Disconnection Detection....	68
5.13	Operation Halt Due to Compressor Startup Error.....	69
5.14	Output Overcurrent.....	70
5.15	Faulty Outdoor Unit PCB.....	72
5.16	Faulty Outdoor Unit PCB and Transmitting/Receiving Circuit	73
5.17	Operation Halt Due to Detection of Input Over Current.....	74
6.	Check.....	76
6.1	How to Check	76

Part 6 Removal Procedure85


1.	For FTK25J, FTK35J, FTX25J, FTX35J	86
1.1	Removal of Air Filter	86
1.2	Removal of Front Grille.....	88
1.3	Removal of Horizontal Blade and Vertical Blade.....	90
1.4	Removal of Switch Box, PC Board and Swing Motor	92
1.5	Removal of Heat Exchanger.....	97
1.6	Install of Drain Plug	99
1.7	Removal of Fan Rotor and Motor	100
2.	For RK25J, RK35J, RX25J, RX35J.....	103
2.1	Removal of External Casing	103
2.2	Removal of Bellmouth and Left Side Plate	105
2.3	Removal of PC Board and Switch Box	106
2.4	Removal of Propeller Fan and Fan Motor	111
2.5	Removal of Compressor Noise Absorption Pad	112
2.6	Removal of Partition Plate and Reactor.	114
2.7	Removal of Four-way Valve.	116
2.8	Removal of Compressor.....	118

Part 7 Others119

1.	Others	120
1.1	Explanation.....	120

Part 8 Appendix.....123




1.	Piping Diagram.....	124
1.1	Indoor Unit.....	124
1.2	Outdoor Unit.....	125
2.	Wiring Diagram	127
2.1	Indoor Unit.....	127
2.2	Outdoor Unit	129





Indexi

Drawings & Flow Chartsiii





1. Introduction

1.1 Safety Cautions


Cautions and Warnings








- Be sure to read the following safety cautions before conducting repair work.
- The caution items are classified into “ **Warning**” and “ **Caution**”. The “ **Warning**” items are especially important since they can lead to death or serious injury if they are not followed closely. The “ **Caution**” items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.
- About the pictograms
 - This symbol indicates an item for which caution must be exercised.
The pictogram shows the item to which attention must be paid.
 - This symbol indicates a prohibited action.
The prohibited item or action is shown inside or near the symbol.
 - This symbol indicates an action that must be taken, or an instruction.
The instruction is shown inside or near the symbol.
- After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer

1.1.1 Caution in Repair.


Warning	
Be sure to disconnect the power cable plug from the plug socket before disassembling the equipment for a repair. Working on the equipment that is connected to a power supply can cause an electrical shock. If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not touch any electrically charged sections of the equipment.	
If the refrigerant gas discharges during the repair work, do not touch the discharging refrigerant gas. The refrigerant gas can cause frostbite.	
When disconnecting the suction or discharge pipe of the compressor at the welded section, release the refrigerant gas completely at a well-ventilated place first. If there is a gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it can cause injury.	
If the refrigerant gas leaks during the repair work, ventilate the area. The refrigerant gas can generate toxic gases when it contacts flames.	
The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. Be sure to discharge the capacitor completely before conducting repair work. A charged capacitor can cause an electrical shock.	
Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug. Plugging or unplugging the power cable plug to operate the equipment can cause an electrical shock or fire.	









 Caution	
Do not repair the electrical components with wet hands. Working on the equipment with wet hands can cause an electrical shock.	
Do not clean the air conditioner by splashing water. Washing the unit with water can cause an electrical shock.	
Be sure to provide the grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.	
Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and cause injury.	
Do not tilt the unit when removing it. The water inside the unit can spill and wet the furniture and floor.	
Be sure to check that the refrigerating cycle section has cooled down sufficiently before conducting repair work. Working on the unit when the refrigerating cycle section is hot can cause burns.	
Use the welder in a well-ventilated place. Using the welder in an enclosed room can cause oxygen deficiency.	



1.1.2 Cautions Regarding Products after Repair

 Warning	
Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools can cause an electrical shock, excessive heat generation or fire.	
When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength and if the installation work is not conducted securely, the equipment can fall and cause injury.	
Be sure to install the product correctly by using the provided standard installation frame. Incorrect use of the installation frame and improper installation can cause the equipment to fall, resulting in injury.	For integral units only
Be sure to install the product securely in the installation frame mounted on a window frame. If the unit is not securely mounted, it can fall and cause injury.	For integral units only
Be sure to use an exclusive power circuit for the equipment, and follow the technical standards related to the electrical equipment, the internal wiring regulations and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work can cause an electrical shock or fire.	
Be sure to use the specified cable to connect between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections can cause excessive heat generation or fire.	











 Warning	
When connecting the cable between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section can cause an electrical shock, excessive heat generation or fire.	
Do not damage or modify the power cable. Damaged or modified power cable can cause an electrical shock or fire. Placing heavy items on the power cable, and heating or pulling the power cable can damage the cable.	
Do not mix air or gas other than the specified refrigerant (R22) in the refrigerant system. If air enters the refrigerating system, an excessively high pressure results, causing equipment damage and injury.	
If the refrigerant gas leaks, be sure to locate the leak and repair it before charging the refrigerant. After charging refrigerant, make sure that there is no refrigerant leak. If the leak cannot be located and the repair work must be stopped, be sure to perform pump-down and close the service valve, to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it can generate toxic gases when it contacts flames, such as fan and other heaters, stoves and ranges.	
When replacing the coin battery in the remote controller, be sure to disposed of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.	

 Caution	
Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.	
Do not install the equipment in a place where there is a possibility of combustible gas leaks. If a combustible gas leaks and remains around the unit, it can cause a fire.	
Be sure to install the packing and seal on the installation frame properly. If the packing and seal are not installed properly, water can enter the room and wet the furniture and floor.	For integral units only



1.1.3 Inspection after Repair

 Warning	
Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet all the way. If the plug has dust or loose connection, it can cause an electrical shock or fire.	
If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires can cause an electrical shock, excessive heat generation or fire.	
Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances, since it can cause an electrical shock, excessive heat generation or fire.	

 Caution	
Check to see if the parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections can cause excessive heat generation, fire or an electrical shock.	









 Caution	
If the installation platform or frame has corroded, replace it. Corroded installation platform or frame can cause the unit to fall, resulting in injury.	
Check the grounding, and repair it if the equipment is not properly grounded. Improper grounding can cause an electrical shock.	
Be sure to measure the insulation resistance after the repair, and make sure that the resistance is 1 Mohm or higher. Faulty insulation can cause an electrical shock.	
Be sure to check the drainage of the indoor unit after the repair. Faulty drainage can cause the water to enter the room and wet the furniture and floor.	


1.1.4 Using Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

1.1.5 Using Icons List

Icon	Type of Information	Description
 Note:	Note	A “note” provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
 Caution	Caution	A “caution” is used when there is danger that the reader, through incorrect manipulation, may damage equipment, loose data, get an unexpected result or has to restart (part of) a procedure.
 Warning	Warning	A “warning” is used when there is danger of personal injury.
	Reference	A “reference” guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.








Part 1

List of Function

1. Functions.....	2
1.1 Indoor Unit and Outdoor Unit.....	2





Functions


SIE-86


1. Functions

1.1 Indoor Unit and Outdoor Unit

Category	Functions	FTK25-35J Series RK25-35J Series	FTX25-35J Series RX25-35J Series	Category	Functions	FTK25-35J Series RK25-35J Series	FTX25-35J Series RX25-35J Series
Basic Function	Energy Saving	○	○	Health Health & Clean	Air Purifying Filter with Bacteriostatic, Virustatic & Deodorizing Functions	○	○
	Inverter (with Inverter Power Control)	○	○		Longlife Filter	—	—
	Lower Limit of Outdoor Temperature for Cooling Operation Limit : Outdoor Temp. °C	10°C	10°C		Ultra-Longlife Filter (Option)	—	—
	Microprocessor Control	○	○		Photocatalytic Deodorizing Filter	—	—
	PAM Control (Pulse Amplitude Modulation Control)	—	—		Photocatalytic Filter with UV Lamp	—	—
Compressor	Horizontal Scroll, Oval Scroll Compressor (DAIKIN SCROLL)	—	—		Mold Proof Air Filter	○	○
	Swing Compressor (DAIKIN ROTARY)	—	—		Washable Grille	○	○
	Rotary Compressor	○	○		Filter Cleaning Indicator	—	—
	Reluctance DC Motor	—	—		Healthy Cooling Operation	—	—
Comfortable Airflow	Dual Flaps	○	○	Timer	Good-Sleep Cooling Operation	○	○
	Power-Airflow Dual Flaps	○	○		72-Hour On/Off Timer	—	—
	Power-Airflow Flap 5 Step Control	○	○		24-Hour On/Off Timer	○	○
	Power-Airflow Diffuser	—	—		12-Hour Timer	—	—
	Wide-Angle Louvers	○	○		Night Set Mode	○	○
	Vertical Auto-Swing (Up and Down)	○	○		Just Fit Thermostatic Timer	—	—
	Horizontal Auto-Swing (Right and Left)	—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○
"Comfortable Control" Comfort Control	3-Step Airflow (H/P Only)	—	—		Self-Diagnosis Digital Display	○	○
	Auto Fan Speed	○	○		Self-Diagnosis LED Display	—	—
	Silent-Operation Control	—	—		LCD Remote Controller (Option)	—	—
	Double Thermostat Function	—	—		The Remote Controller Loss Prevention with the Chain (Option)	○	○
	Intelligent Eye	○	○		Wiring Error Check	—	—
	Automatic Sensible Comfort Control	○	○		Anticorrosion Treatment of Outdoor Heat Exchanger	○	○
	Quick Warming Function	—	○	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○
Operation	Hot-Start Function	—	○		Flexible Voltage Correspondence	○	○
	Automatic Defrosting	—	○		Chargeless	○	—
	Automatic Operation	—	○	Remote Control	5-Rooms Centralized Controller (Option)	○	○
	Programme Dry Function	○	○		Field-Supply Timer Operation	○	○
	Height-Ceiling Application	—	—		Remote Control Adaptor (Option) (Normal Open-Pluse Contact)	○	○
Lifestyle Convenience	Circulation	—	—		Remote Control Adaptor (Normal Open Contact)	○	○
	Fan Only	○	—		DIII-NET Compatible (Adaptor)	○	○
	New Powerful Operation (Non-Inverter)	—	—	Remote Controller	Wireless	○	○
	Inverter Powerful Operation (Increased Air Volume / Increased Compressor Rotation Speed)	○	○		Wired	—	—
	Priority-Room Setting	—	—				
	Quiet Operation	—	—				
	Laundry Programme Operation	—	—				
	Energy-Saving Operation	—	—				
	Power Selection	—	—				
	Indoor Unit On/Off Switch	○	○				
	Signal Reception Indicator	○	○				
	Temperature Display	—	—				
	Power-Control Function	—	—				

○ : Holding Functions — : No Functions







Part 2

Printed Circuit Board Connector Wiring Diagram

1. Printed Circuit Board Connector Wiring Diagram and Name	4
1.1 FTK25/35J Series, FTX25/35J Series	4
1.2 RK25/35J Series, RX25/35J Series.....	6





1. Printed Circuit Board Connector Wiring Diagram and Name

1.1 FTK25/35J Series, FTX25/35J Series

Printed circuit board (1) (Control PCB)
Printed circuit board (2) (Signal Receiver PCB)
Printed circuit board (3) (Intelligent Eye Sensor PCB)

Name of connector


- | | |
|-------------|---|
| 1) S1 | Connector for fan motor |
| 2) S6 | Connector for swing motor (Horizontal Flap) |
| 3) S7 | Connector for fan motor |
| 4) S21 | Connector for centralized control to 5 rooms |
| 5) S27, S36 | Connector for control PCB |
| 6) S26 | Connector for signal receiver PCB |
| 7) S32 | Connector for room temp/Heat exchanger thermistor |
| 8) S35 | Connector for Intelligent Eye Sensor PCB |



Note:

- Other designations
- | | |
|-------|---|
| 1) V1 | Varistor |
| 2) JA | ADDRESS SETTING JAMPER |
| JB | Fan speed setting when compressor is OFF on thermostat. |
| JC | Power failure recovery function. |
- * Refer to page 121 for more detail.
- | | |
|---------------|-------------------------|
| 3) SW7 | OPERATION SWITCH |
| 4) LED1 (GRN) | LED for operation |
| 5) LED2 (YLW) | LED for timer |
| 6) LED3 (GRN) | LED for intelligent eye |


Control PCB (1)




SIE-86

Printed Circuit Board Connector Wiring Diagram and Name

P.C.B (1) (Control P.C.B) Detail





Printed Circuit Board Connector Wiring Diagram and Name

SIE-86



1.2 RK25/35J Series, RX25/35J Series

Printed circuit board (1) (Main-PCB)

Name of connector

- | | |
|--------|---|
| 1) S30 | Connector for compressor motor (with internal thermostat) |
| 2) S70 | Connector for fan motor |
| 3) S80 | Connector for 4 WAY VALVE COIL (RX25 · 35J Series only) |
| 4) S91 | Connector for THERMISTOR |
| 5) S40 | Connector for OL |
| 6) SW1 | NONE (Forced operation ON/OFF switch) |
| 7) SW2 | NONE (Forced operation Mode selector switch (H/P only)) |

PCB (1)











Printed Circuit Board Connector Wiring Diagram and Name

SIE-86








Part 3

Main Function


1. General Functionality	10
1.1 Functions of Thermistors	10
1.2 Operating Modes	12
1.3 Frequency Principle	13
1.4 Defrost Control	15
1.5 Forced Operation Mode	16
1.6 Wide-angle Flaps, Diffuser, Louvres and Autoswing	17
1.7 Fan Speed Control for Indoor Units	19
1.8 Fan Speed Control for Outdoor Units	20
1.9 General Functions	21
1.10 Intelligent Eye (J type)	23
1.11 Good Sleep Cooling Control (J Type)	25
1.12 Automatic Operation	26
1.13 Input Current Control (H / J Type)	27
1.14 Freeze Protection Function in Cooling. (H / J Type)	28
1.15 Peak-Cut Control Function (H / J Type)	29
1.16 Four-Way Valve Function Compensation (H / J Type)	30
1.17 Compressor Protection Function (H / J Type)	31
1.18 Wet Operation Protection (H / J Type)	32
1.19 Dew Condensation Sweating Prevention Function (H / J type)	33



1. General Functionality

1.1 Functions of Thermistors

Location of thermistors The thermistors on the drawing below are used to control the system. This control secures a proper cooling and prevents problems of the unit:




Frequency control The following table shows the thermistors that control the frequency:


Controls	Outdoor heat exchanger thermistor	Outdoor ambient temperature thermistor	Indoor ambient temperature thermistor	Indoor heat exchanger thermistor
Symbol	R2T	R1T	R1T	R2T
Freeze-up prevention. Refer to page 11.	—	—	—	○
Peak cut off. Refer to page 11.	—	—	—	○
Defrost. Refer to page 15.	○	○	—	○
High pressure limitation in heating. Refer to page 11.	○	—	—	○

with ○: available functions and — : no available functions.

**Frequency controlled functions**

The following table shows the different functions, which are controlled by decreasing or increasing the frequency:

Function	Sensor Thermistor	Why?	How?	Set	Reset	Malfunction
Low outdoor temperature control	outdoor ambient thermistor (R1T)	To avoid condensation in cooling mode.  This control is not executed when the unit is in forced cooling mode or in test mode.	By setting a high frequency limit.	T _{outdoor ambient} < 18 °C (J type) 25 °C (H type)	T _{outdoor ambient} > 25 °C (J type) 33 °C (H type)	—
High pressure limitation in heating	■ outdoor temperature thermistor (R1T) ■ indoor heat exchanger thermistor (R2T)	To control the pressure.	By setting a high frequency limit.	■ heating mode ■ T _{outdoor} > 16 °C ■ T _{indoor heat exchanger} > 22 °C ■ compressor on	■ compressor stop ■ timer delay (70 s) has passed	—
Freeze-up prevention	indoor heat exchanger thermistor (R2T)	To prevent the freezing up of the indoor unit in cooling mode.	By setting a high frequency limit.	■ during cooling ■ 0 °C < T _{indoor heat exchanger} < 8 °C	T _{indoor heat exchanger} > 8 °C for 2 seconds	T _{indoor heat exchanger} < 0 °C (result: compressor stop)
Peak cut off	indoor heat exchanger thermistor (R2T)	To prevent an abnormal high temperature on the indoor heat exchanger in heating mode.	By setting a high frequency limit.	■ during heating ■ 50 °C < T _{indoor heat exchanger} < 67 °C	T _{indoor heat exchanger} < 50 °C for 2 seconds	T _{indoor heat exchanger} > 67 °C (result: compressor stop)





1.2 Operating Modes

Modes

There are two operating modes:

- normal operating mode
- forced operating mode.

Overview

The following table shows the different control modes of the Split inverter room air conditioners:

Mode	Item
Normal operating mode	Auto (Heat pump only)
	Cooling
	Dry keep
	Heating (Including Automatic defrost)
	Fan (for Cooling only)
	Stop mode: <ul style="list-style-type: none">■ Pre-heat operation. Refer to "Pre-heat operation".■ Stop
Test Operation	Forced cooling / heating
Forced operating mode	Forced cooling




Note:

The outdoor unit retains the operating mode, when the thermostat is switched off.



Refer to "Pre-heat operation" on page 21



1.3 Frequency Principle

Main control parameters

The compressor is frequency-controlled during normal operation. The target frequency is set by the following 2 parameters coming from the operating indoor unit:

- the load condition of the operating indoor unit
- the difference between the room temperature and the set temperature.

Additional control parameters

The target frequency is adapted by additional parameters in the following cases:

- frequency limits
- initial settings
- forced cooling/heating operation.


Inverter principle

To regulate the capacity, a frequency control is needed. The inverter makes it possible to vary the rotation speed of the compressor. The following table explains the conversion principle:


Phase	Description
1	The single phase power supply in AC is converted into DC.
2	<p>The single phase power supply DC is converted into a three phase shopped DC voltage with a variable frequency.</p> <ul style="list-style-type: none"> ■ When the frequency increases, the rotation speed of the compressor increases resulting in an increased refrigerant circulation. This leads to a higher amount of the heat exchange per unit. ■ When the frequency decreases, the rotation speed of the compressor decreases resulting in a decreased refrigerant circulation. This leads to a lower amount of the heat exchange per unit.

Drawing of inverter

The following drawing shows a schematic view of the inverter principle:




Min. frequency <u>A</u>	H type	J type	Max. frequency <u>B</u>	H type	J type
Cooling	36	34	Cooling	94	98
Heating	36	34	Heating	94	98



Inverter features

The inverter provides the following features:

- The regulating capacity can be changed according to the changes in the outside temperature and cooling/heating load.
- Quick heating and quick cooling
The compressor rotational speed is increased when starting the heating (or cooling). This enables a quick set temperature.



- Even during extreme cold weather, the high capacity is achieved. It is maintained even when the outside temperature is 0°C.
- Comfortable air conditioning
A detailed adjustment is integrated to ensure a fixed room temperature. It is possible to air condition with a small room temperature variation.
- Energy saving heating and cooling
Once the set temperature is reached, the energy saving operation enables to maintain the room temperature at low power.


Frequency limits


The following table shows the functions that define the minimum and maximum frequency:

Frequency limits	Limited during the activation of following functions
Low	<ul style="list-style-type: none">■ four way valve operation compensation. Refer to page 30.■ Wet Operation Protection Function. Refer to page 32.
High	<ul style="list-style-type: none">■ Input current control. Refer to page 27.■ Compressor protection function. Refer to page 31.■ low outdoor temperature control. Refer to page 11.■ high pressure limitation. Refer to page 11.■ peak cut off. Refer to page 11.■ freeze-up prevention. Refer to page 11.■ defrost control. Refer to page 15.

**Forced cooling/
heating operation**

For more information, refer to “Forced mode” on page 16.





1.4 Defrost Control

Principle

Defrost control is carried out by reversing the cycle from heating to cooling.

Start conditions

Defrost control is set by the following conditions:

- during heating
- More than 6 minutes after the compressor has started up
- when condition 1 or 2 in the table below are applicable:

Condition	Description
1	<ul style="list-style-type: none">■ <u>A</u> minutes of accumulated runtime■ not yet 90 minutes of accumulated runtime■ condition 1 or 2 or 3 in the table below
2	<ul style="list-style-type: none">■ 90 minutes of accumulated runtime■ condition 1 or 4 or 5 in the table below

Conditions

The following table shows the different conditions on which defrost control is based:

Conditions	Description
1	$T_{[\text{outdoor heat exchanger}]} < \underline{\text{B}}^{\circ}\text{C}$ for 1 min.
2	<ul style="list-style-type: none">■ $T_{[\text{ambient outdoor}]} < 5^{\circ}\text{C}$■ $T_{[\text{outdoor heat exchanger}]} < (-5 + T_{[\text{ambient outdoor}]} \infty 0,4)$■ check if $T_{[\text{indoor heat exchanger}]}$ decreases 5 times every 10 seconds
3	<ul style="list-style-type: none">■ $T_{[\text{ambient outdoor}]} \geq 5^{\circ}\text{C}$■ $T_{[\text{outdoor heat exchanger}]} < -3^{\circ}\text{C}$■ check if $T_{[\text{indoor heat exchanger}]}$ decreases 5 times every 10 seconds
4	<ul style="list-style-type: none">■ $T_{[\text{ambient outdoor}]} < 5^{\circ}\text{C}$ for 60 seconds■ $T_{[\text{outdoor heat exchanger}]} < (-5 + T_{[\text{ambient outdoor}]} \infty 0,4)$ for 60 seconds
5	<ul style="list-style-type: none">■ $T_{[\text{ambient outdoor}]} \geq 5^{\circ}\text{C}$ for 60 seconds■ $T_{[\text{outdoor heat exchanger}]} < -3^{\circ}\text{C}$ for 60 seconds

Stop conditions

Defrost control is reset by the following conditions:

- $T_{[\text{heat exchanger}]} > 4^{\circ}\text{C}$ if $T_{[\text{ambient outdoor}]} < 19^{\circ}\text{C}$
- $T_{[\text{heat exchanger}]} > 18^{\circ}\text{C}$ if $T_{[\text{ambient outdoor}]} < -3^{\circ}\text{C}$
- $T_{[\text{heat exchanger}]} > (-1^{\circ}\text{C} \infty T_{[\text{ambient outdoor}]} + \underline{\text{C}}$ if $-3^{\circ}\text{C} < T_{[\text{ambient outdoor}]} < 19^{\circ}\text{C}$.

	Class	<u>A</u>	<u>B</u>	<u>C</u>
H type	25	32	-15	23
	35	40	-15	17
J type	25	32	-15	17
	35	32	-14	17





1.5 Forced Operation Mode

1.5.1 H type

Forced mode

The following table explains the different forced operation modes, forced cooling and forced heating:

Item	Forced cooling	Forced heating
Conditions	<ul style="list-style-type: none">■ not in the 3-minute stand-by mode■ normal operation mode■ outdoor unit off■ no malfunction in the outdoor unit■ forced mode: cooling mode.	<ul style="list-style-type: none">■ not in the 3-minute stand-by mode■ normal operation mode■ outdoor unit off■ no malfunction in the outdoor unit■ forced mode: heating mode.
Start Adjustment (H type)	<ul style="list-style-type: none">■ Press the forced operation switch SW1 to start the following items:■ command frequency: 66 Hz■ timer: 60-minute■ fan speed: H■ swing flap: preservation of last setting■ indoor adjustment: send forced mode to unit.	<ul style="list-style-type: none">■ Press the forced operation switch SW1 while short circuiting SW2 to start the following items:■ command frequency: 66 Hz■ timer: 60-minute■ fan speed: H■ swing flap: preservation of last setting■ indoor adjustment: send forced mode to unit.
Reset (H type)	Press the forced operation switch again or after 60 minutes.	Press the forced operation switch again or after 60 minutes.




The protective functions overrule the forced mode. (H type only)

1.5.2 J type

Forced mode

Item	Forced cooling	Forced heating
Conditions	<ul style="list-style-type: none">■ not in the 3-minute stand-by mode■ normal operation mode■ outdoor unit off■ no malfunction in the outdoor unit■ forced mode: cooling mode.	<ul style="list-style-type: none">■ not in the 3-minute stand-by mode■ normal operation mode■ outdoor unit off■ no malfunction in the outdoor unit■ forced mode: heating mode.
Start Adjustment	<ol style="list-style-type: none">1. Keep pushing the operation switch of the indoor unit for 5 to 10 seconds.2. Change the remote controller setting to a cooling test operation. (Regarding a way to enter the test operation, refer to the note in a margin below) <p>Possible to enter the forced cooling mode by either way of 1. or 2..</p> <ul style="list-style-type: none">■ Fix operation frequency to 66 Hz.■ Operation-on timer :15 min.■ Indoor unit's fan : H tap.■ Swing flap: the latest set position.	<p>With a change of the remote controller setting to a heating test operation, the unit enters the forced heating mode. (Regarding a way to enter the test operation mode, refer to the note in a margin below)</p> <ul style="list-style-type: none">■ Fix operation frequency to 66 Hz.■ Operation-on timer :15 min.■ Indoor unit's fan : H tap.■ Swing flap: the latest set position.
Reset	<ol style="list-style-type: none">1. Push the operation switch of the indoor unit in an usual way.2. Push the stop button on a remote controller.3. Operation-on timer : 15 min. overtime.	<ol style="list-style-type: none">1. Push the operation switch of the indoor unit in an usual way.2. Push the stop button on a remote controller.3. Operation-on timer : 15 min. overtime.

A way to enter the test operation mode by a remote controller.

1. Set on the desirous mode and push ON/OFF button. (operation ON)
2. Two buttons; Center of temperature set buttons “  ”, and “ Mode” button, should be pushed simultaneously. (then a left figure of the liquid crystal temperature's display number starts to blink.)
3. Moreover, push “MODE” button twice. (If the liquid crystal display becomes “ τ ”, the test operation mode will startup under the mode displayed in a liquid crystal.)





SIE-86


General Functionality


1.6 Wide-angle Flaps, Diffuser, Louvres and Autoswing

1.6.1 H type


Wide-angle flap	The large flaps send a large volume of air downwards to the floor. The flap provides an optimum control in cooling, heating and dry mode.
Diffuser	The diffuser enables the air coming out of the indoor unit to reach all surfaces in cooling mode.
Heating mode	During heating mode, the large flap enables direct warm air straight downwards. The diffuser presses the warm air above the floor to reach the entire room.
Cooling mode	During cooling mode, the diffuser retracts into the indoor unit. This enables a distribution of cooled air throughout the entire room.
Louvres	The louvres, made of elastic synthetic resin, provide a wide range of airflow that guarantees a comfortable air distribution.
Autoswing	The following table explains the autoswing process for heating and cooling:

Item	Description	Drawing
heating	The flap swings up and down as shown in the drawing alongside.	 (RL004)
cooling	The flap swings up and down as shown in the drawing alongside.	 (RL005)



**General Functionality****SIE-86****1.6.2 J type****Outline of the action**




It can be commanded for J type by means of a user setting to select either any one desired position among the five-step directions of air flow adjusted on a remote controller, or Auto-swing.



Although the liquid crystal display of the five-step directions of the air flow is common for the modes of Cooling-Dry/Heating as illustrated above, in fact the range of the swing angle is slightly different in every operation mode.

The position a user set will be selected among the five positions calculated through the preliminary and evenly divided into four partitions which were taken from the upper and lower flap angle's range limits of each mode.


When Auto-swing is chosen, the flap swings in the swing range which meets the operation mode selected.



* Fan mode is available for the models of cooling-only.

Others

- The vertical louver can be adjusted manually. The movable range is 60 degrees for left or right, and total 120 degrees.
- A diffuser is not available for J type.



1.7 Fan Speed Control for Indoor Units

Control mode The airflow rate can be automatically controlled depending on the difference between the set temperature and the room temperature. This is done through phase control and Hall IC control.



For more information about Hall IC, refer to 'Hall IC check (A6)' on page 61.

Phase steps Phase control and fan speed control contains 8 steps: LLL, LL, L, ML, M, HM, H and HH.

Step	Cooling	Heating	Dry mode
LLL (Heating thermostat OFF)			H type : 500 - 860 rpm (During powerful operation : 850 - 910 rpm) J type : 800 - 980 rpm (During powerful operation : 1050 rpm)
LL (Cooling thermostat OFF)			
L			
ML			
M			
MH			
H			
HH (Powerful)			

= Within this range the airflow rate is automatically controlled when the AIRFLOW ADJUSTING button is set to AUTOMATIC




Refer to automatic airflow rate control on page 19.



- Note:**
1. During powerful operation, fan operate H tap + 50 - 70 rpm.
 2. Fan stops during defrost operation.

Automatic air flow control for heating


The following drawing explains the principle for fan speed control for heating:




Note: When there is no operation and the night set mode turns on, the step is low. Refer to "Night set mode" on page 22.

Automatic air flow control for cooling

The following drawing explains the principle of fan speed control for cooling:






1.8 Fan Speed Control for Outdoor Units

Control

The following drawing explains the fan speed control:



Fan off delay


When the compressor turns off and $T_{[\text{outdoor ambient}]} > \underline{D}^{\circ}\text{C}$, the outdoor fan stays running at the same speed for \underline{E} seconds.


	$\underline{A}^{\circ}\text{C}$	$\underline{B}^{\circ}\text{C}$	$\underline{C}^{\circ}\text{C}$	$\underline{D}^{\circ}\text{C}$	$\underline{E} \text{ (sec)}$
H type	28	34	0 - 18	10	30
J type	33	39	0 - 9	10	60



Caution

* J type operates the outdoor unit fans in the cooling mode even at the condition that a compressor is not operated. (In case of existing model H series, the outdoor unit fans stops at the condition that a compressor is not operated.)






1.9 General Functions

Pre-heat operation

When the equipment has stopped and $t_{\text{outside}} < 11.5^{\circ}\text{C}$, the compressor is warmed-up by passing a single-phase (U, V phase) current through the compressor motor to speed up the start. The power consumption is 30-40W.



* For both H / J type

Hot start function

During defrosting or when the thermostat is on in heating mode, the indoor heat exchanger temperature $\geq 29^{\circ}\text{C}$ to fan starts to avoid cold draft.

Dry mode

The dry mode removes humidity while maintaining the room temperature. The temperature and fan cannot be regulated during dry mode.

<Management>

1. Decision of the dry setting temperature

■ When entering the following dry mode,

1 Stop → an operation will start with Dry.

2 Mode except Dry → changing to dry mode


Thermostat ON/OFF point is decided in accordance with the following conditions.


Room temp. cond. at entering Dry.	Set temp. (thermostat ON)	Thermostat OFF temp.
$24^{\circ}\text{C} \leq \text{Room temp.}$	Room temp. at the entering.	Room temp. -2°C at the entering.
$18^{\circ}\text{C} \leq \text{Room temp.} < 24^{\circ}\text{C}$	Room temp. at the entering.	Room temp. -1.5°C at the entering.
Room temp. $< 18^{\circ}\text{C}$	18°C	17°C

2. Frequency command

■ The frequency command is decided based on a room temperature zone.

The room temperature zone is decided as follows.





General Functionality

SIE-86

- The frequency command for every zone is stated below.
(Please note that an operation will not carry out in the commanded frequency sometimes in case a protection control like a freeze-protection etc. will be actuated.)

Room temperature	Room temp. zone	Command frequency	
		H type (25 / 35)	J type (25 / 35)
Room temp. < 18°C	A	0 / 0Hz	0 / 0Hz
	except A	36 / 36Hz	34 / 34Hz
Room temp. ≥ 18°C	A	0 / 0Hz	0 / 0Hz
	B	36 / 36Hz	34 / 34Hz
	D	36 / 36Hz	40 / 40Hz
	E	40 / 40Hz	42 / 42Hz
	F	40 / 44Hz	42 / 42Hz



3. Required fan speed
- Fan speed changes the rotation speed every time when a thermostat switches over ON and OFF.
 - When the thermostat becomes Off, fan continues to operate 10 minutes more with low speed so as to prevent recovery of humidity caused by reevaporation of the drain water, and then stops.

	Fan rpm (thermostat ON)	
	H type (25 / 35)	J type (25 / 35)
Thermostat ON	800 / 800rpm	970 / 980rpm
Thermostat OFF	700 / 700rpm	800 / 800rpm
Thermostat ON and dry on powerful operation	850 / 910rpm	1050 / 1050rpm



* For both H / J type

Night set mode

The night set mode is activated when the off timer is set. It restricts the operation frequency, to minimize the noise.

Item	Description	Drawing
cooling	The set temperature stays on for one hour, then decreases slightly for economical operation.	
heating	The set temperature stays on for one hour, then increases slightly for economical operation.	

* For both H / J type




1.10 Intelligent Eye (J type)

Outline

The function that detects existence of humans in the air-conditioned room and reduces the capacity when no humans are available in the room in order to save electricity by means of a human motion sensor.


Processing

1. Detection method by human motion sensor



- This sensor detects human motion by receiving infrared rays and displays the pulse wave output.
- A micro computer in an indoor unit carries out a sampling every 20 msec. and if it detects 10 cycles of the wave in one second in total (corresponding to $20\text{msec.} \times 10 = 100\text{msec.}$), it judges human is in the room as the motion signal is ON.

2. The motions (for example: in cooling)



- When a micro computer doesn't have a signal from the sensor in 20 minutes, it judges that no body is in the room and turns off the human detection LED, operating the unit in temperature sifted 2°C from the set temperature. (Cooling : 2°C higher, Dry: 1°C higher and Auto : according to the operation mode at that time.)

★1 In case of Fan mode, the fan speed reduces by 50 rpm.

- Since the set temperature is shifted by 2°C higher for 40 minutes, compressor speed becomes low and can realize energy saving operation. But as thermostat is prone to be off by the fact that the set temperature has been shifted, the thermostat-off action is prohibited in 40 minutes so as to prevent this phenomena. After this 40 minutes, the prohibition of the thermostat-off is cancelled and it can realize the conditions to conduct thermostat-off depending on the room temperature. In or after this forty minutes, if the sensor detects human motion detection signal, it turns on "Human detection LED" and let the set temperature and the fan speed return to the original set point, keeping a normal operation.




General Functionality

SIE-86



Others

- The dry operation can't command the setting temperature with a remote controller, but internally the set temperature is shifted by 1°C.




1.11 Good Sleep Cooling Control (J Type)

Outline


The function to create deep sleeping and to offer good sleep by altering the set temperatures in certain intervals to give temperature variation to a living space based on "1/f temperature fluctuation" principle, in case of going to bed while air conditioner keeps operating in cooling mode.

Processing



Notes:

- Each timer's counting/stop is not related to a thermostat ON/OFF.
- When the sleeping control works by the OFF timer, the shift from the set temperature should be just 1°C with this control function.
(The temperature shift of the normal OFF-timer will not be carried out. However, the passed time should be remembered since the OFF-timer was set.)
- While operation with the good sleep cooling control and off-timer setting, if the signal of the good sleep cooling OFF signal comes, the level of the set temperature shift should be set corresponding to the same with an existing value in accordance with the passed time since the OFF-timer was set.
- When the good sleep cooling control is on while a normal operation with a OFF-timer is going on, once returning to the original criterion which doesn't shift the timer's set temperature, and the shift alteration at every sequence by 1°C is carried out in accordance with the value above mentioned.
- Fan speed will change by the alteration of the set temperature by 1°C at the automatic fan speed operation mode, and it causes an alteration of fan noise. So, the fan tap should be fixed at L tap position during the good sleep cooling even at the auto fan speed operation.
- The function of the good sleep cooling is cancelled, when the good sleep cooling operation is off or operation OFF command is received or also the operation mode changes to the mode except cooling.
- The priority order for each function is ; 'Powerful', 'Intelligent eye', 'Good sleep', and 'Night set mode'.




1.12 Automatic Operation


The unit automatically switches the operation mode to cooling or heating to maintain the room temperature at the main unit setting temperature.

Detailed explanation of the function

1. Remote controller setting temperature is set as automatic cooling / heating setting temperature (18 to 30°C).
2. Main unit setting temperature equals remote controller setting temperature plus correction value (correction value / cooling: 0 deg, heating: 2 deg.).
3. Operation ON / OFF point and mode switching point are as follows.
 - 1 Heating → Cooling switching point: Room temperature \geq Main unit setting temperature +2.5 deg.
 - 2 Cooling → Heating switching point: Room temperature $<$ Main unit setting temperature -2.5 deg.
 - 3 Thermostat ON / OFF point is the same as the ON / OFF point of cooling or heating operation.
4. During initial operation
Room temperature \geq Remote controller setting temperature: Cooling operation
Room temperature $<$ Remote controller setting temperature: Heating operation




However, in the automatic Powerful cooling/heating mode, the guard timer is set as follows to prevent hunting in cooling / heating mode.



1.13 Input Current Control (H / J Type)

Outline

The frequency control will be carried out so that the input current will not exceed the rated value in the zone which is divided by the input current detected with CT as the figure below shows.



- I4, I3, I3-Iα are included in the stop zone, step down, steady zone, respectively.

Processing

1. Frequency control in each zone

- Step down zone (judged as the step down zone with the input current $I_{IN} \geq I_3$)
 - The upper limit FNYD of the frequency in this control is defined as 'operation frequency - 2 Hz'.
 - After this, the output frequency is dealt with step down by 2 Hz every one second till it will reach the steady zone.
- Steady zone (judged as the step down zone with $I_3 - I_\alpha \leq I_{IN} < I_3$ by step down operation)
 - Keeping the present frequency's upper limit FNYD.
- Return zone (judged as the return zone with $I_{IN} < I_3 - I_\alpha$ ($I_\alpha = 1A$))
 - Limit of frequency is cancelled.
- Stop zone (judged as the stop zone with $I_{IN} \geq I_4$)
 - Compressor is stopped and countermeasure for the malfunction is carried out.

2. Current step down : deciding I3


- In cooling mode
 - At outdoor temperature > DOAIC
 - $I_3 = I_{3C} - 0.5 \infty$ (outdoor temp. DOAIC) * At POWER FULL, I3CPWF is used instead of I3C.
 - At outdoor temperature ≤ DOAIC
 - $I_3 = I_{3C}$ * At POWER FULL, I3CPWF is used instead of I3C.
- In heating mode
 - At outdoor temperature > DOAIW
 - $I_3 = I_{3W} - 0.25 \infty$ (outdoor temp. - DOAIW) * At POWER FULL, I3WPWF is used instead of I3C.
 - At outdoor temperature ≤ DOAIW
 - $I_3 = I_{3W}$ * At POWER FULL, I3WPWF is used instead of I3W.

(a constant)	H type 25	H type 35	J type 25	J type 35
I3C	6.50 A	7.75 A	6.50 A	8.00 A
I3CPWF	7.25 A	8.50 A	7.25 A	8.50 A
DOAIC	40°C	40°C	40°C	40°C
I3W	6.50 A	7.50 A	6.50 A	7.50 A
I3WPWF	6.50 A	7.50 A	6.50 A	7.50 A
DOAIW	10°C	10°C	12°C	12°C

C : Cooling PWF : Powerful W : Heating

DOAIC : Ambient temperature at cooling

DOAIW : Ambient temperature at heating




1.14 Freeze Protection Function in Cooling. (H / J Type)

Outline

During Cooling/Dry operation, when the heat exchanger's temperature falls down excessively, the capacity supply will be reduced (frequency step down) so as to prevent freeze of the heat exchanger and the creation of dew on a rotor caused by a excessive capacity supply to the indoor unit.



Processing




Setting a constant	H type	J type
DTO4	13°C	15°C
DTO3	6°C	8°C
DTO2	5°C	7°C
DTO1	3°C	5°C
DTO0	0°C	0°C

* DTO : Freeze protection temperature of heat exchanger

- The restriction for frequency is not conducted in the return area by means of freeze protection control.
- Frequency is increased approximately every 2 Hz/min. in the up-area.
- Frequency alteration in the steady area is not conducted.
- Frequency - down is carried out in the step down area approximately every 2 ~ 4 Hz/min..
- Compressors stop in the stop area. After compressor stops, fan keeps operating in 700 rpm for H type and 800 rpm for J type (LL operation), aiming at rising heat exchanger's temperature.






1.15 Peak-Cut Control Function (H / J Type)

Outline

In a heating operation, there will be anxiety that a head pressure excessively increases and exceeds the permissible limit in an over load conditions.
For avoiding this fact, when the head pressure increases, frequency step down control is carried out for the protection so that the head pressure will not exceed the permissible limit after detecting the temperature of the indoor unit's heat exchanger (saturation temperature equivalent to head pressure).



Processing



Setting a constant	H type	J type
DP0	67°C	67°C
DP1	58°C	56°C
DP2	56°C	54°C
DP3	55°C	53°C
DP4	48°C	46°C

- * J type makes DP1 ~ DP4 increase 2°C in POWER FULL heating operation. There is no change in H type even if POWER FULL is applied.
- * DP : Peak cut temperature of heat exchanger

- The restriction for frequency is not conducted in the return area by means of peak-cut control.
- Frequency is increased approximately every 2 Hz/min. in the up-area.
- Frequency alteration in the steady area is not conducted.
- Frequency - down is carried out in the step down area approximately every 2 ~ 4 Hz/20sec.. (2 Hz for H type, 4 Hz for J type)
- Compressors stop in the stop area.





1.16 Four-Way Valve Function Compensation (H / J Type)




Outline When the initial start of compressors is required after power is on or at operation mode's alteration (Cooling/Dry ↔ Heating) that the a switch-over of a four-way valve takes place, it secures the necessary differential pressure by restricting the operation frequency in the lower limit in a certain period, and the switch-over action is ensured.


Processing

1. If a four-way valve is OFF when compressors stop, it will be ON at this time.
2. If a four-way valve was ON when compressors operated in the last time, it will be ON at this time.
3. At the start of compressors.
4. At the initial start of compressors after power is reset.

In case 1. and 3. are under the simultaneous condition of AND (it indicates Cooling) or 2. and 3 are under the simultaneous satisfaction of AND (it indicates Heating), or condition 4. is adapted, the processing applies A seconds after compressors begin operating and to set B Hz for the lower limit of operation frequency.

	A (sec)	B (Hz)
H type 25 / 35	45	66
J type 25 / 35	45	66






1.17 Compressor Protection Function (H / J Type)

Outline

An refrigeration oil level descent and progression of the dilution which will arise at operation of the compressors will be avoided by controlling the upper limit of frequency at the edge of compressor's changeover from OFF to ON as follows.

Processing



1. A choice of a constant based on the starting conditions.

A constant is chosen in the following conditions at the start of compressors.

- 1 In case $TCG0 < TDEN$
A type starting is adopted.
- 2 In case $TCG0 \geq TDEN$
B type starting is adopted.

* $TCG0$ is set only at power-ON and then start, keep counting regardless of the operation mode.

* The judge above should be done only at the start of compressors.

* TCG : Timer guard for compressor protection * $TDEN$: Power on time

2. Frequency control

The following control is carried out after the judge of 1. above. A constant is chosen in accordance with A, B decided in 1).

- 1 Timer $TCG1$ (A,B) will start at the start of compressors.
The upper limit of output frequency in between $TCG1$ (A,B) is set at $FCG1$ (A,B).
- 2 In exceeding $TCG1$ (A,B), timer $TCG2$ (A,B) starts and the upper limit of output frequency in between $TCG2$ (A,B) is set at $FCG2$ (A,B).
- 3 In exceeding $TCG2$ (A,B), timer $TCG3$ (A,B) starts and the upper limit of output frequency in between $TCG3$ (A,B) is set at $FCG3$ (A,B).
- 4 In exceeding $TCG3$ (A,B), the frequency limit is cancelled.


3. Others


- 1 If compressors go off at the start of this function, the timer under counting should be reset and cancelled the frequency limit.
- 2 This function doesn't work under the control of defrosting.

Setting a constant	H/J type	Setting a constant	H/J type
FCG1A	46 Hz	TCG1A	120 sec
FCG1B	46 Hz	TCG1B	120 sec
FCG2A	66 Hz	TCG2A	570 sec
FCG2B	66 Hz	TCG2B	360 sec
FCG3A	90 Hz	TCG3A	120 sec
FCG3B	80 Hz	TCG3B	180 sec
		TDEN	30 min

* FCG : Frequency guard for compressor protection

* TCG : Timer guard for compressor protection





1.18 Wet Operation Protection (H / J Type)

Outline

The lower limit of output frequency is limited in two steps in accordance with outdoor conditions in order to secure the reliability of compressor (suction dryness and differential pressure).

Processing

1. at the first step

1 During operation of compressors.

2 Outdoor temperature \leq DOA1CG

■ If 1 and 2 are under the simultaneous condition with AND, the lower limit of frequency in this function is set at FCG7.

3 Compressors stop.

4 Outdoor temperature \geq DOA2CG

■ If 3 and 4 are under the simultaneous condition with OR, the lower limit of frequency at the first step control is cancelled.

2. at the second step

1 During operation of compressors

2 Outdoor temperature \leq DOA3CG

■ If 1 and 2 are under the simultaneous condition with AND, the lower limit of frequency in this function is set at FCG8.


3 Compressors stop.

4 Outdoor temperature \geq DOA4CG

■ If 3 and 4 are under the coordinate condition with OR, the lower limit of frequency at the second step control is cancelled.

3. The set of a constant

DOA1CG, DOA2CG, DOA3CG, FCG7 and FCG8 have constants for Cooling /Heating separately and these constants are distinguished with a suffix c/w.




4. Actual constant

(In cooling)	H type 25 / 35	J type 25 / 35
DOA1CGC	18°C	18°C
DOA2CGC	20°C	20°C
DOA3CGC	14°C	14°C
DOA4CGC	16°C	16°C
FCG7C	40 Hz	34Hz
FCG8C	40 Hz	34 Hz

(In heating)	H type 25 / 35	J type 25 / 35
DOA1CGW	0°C	0°C
DOA2CGW	2°C	2°C
DOA3CGW	-4°C	-4°C
DOA4CGW	-2°C	-2°C
FCG7W	48 Hz	48 Hz
FCG7W	54 Hz	54 Hz

* DOA : Outdoor air temperature
CGC : Compressor guard for cooling
CGW : Compressor guard for heating
FCG : Frequency guard for compressor protection





1.19 Dew Condensation Sweating Prevention Function (H / J type)

Outline During Cooling/Dry operation, when the heat exchanger's temperature falls down excessively, the capacity supply will be reduced (frequency step down) so as to prevent dew formation around a discharge grille caused by a excessive capacity supply to an indoor unit.


Processing

1. Conditions of beginning/ending for this function.

1 Operation mode is in Cooling/Dry.
2 Compressors operate.
3 Fan speed < MH tap
4 Outdoor temperature ≤ 32°C
Dew condensation sweating prevention function will start, if 1234 are under the simultaneous condition with AND.

5 Operation mode is not in Cooling/Dry.
6 Compressors stop
7 MH tap ≤ fan speed
8 Outdoor temperature > 32°C
Dew condensation sweating prevention function will be completed if 5678 are under the coordinate condition with OR.

2. Control details






(RL028)

- It controls the operation frequency in accordance with the temperature zone in the step down area ~ the return area which are set in every model.
- Frequency limitation by means of freeze protection control will not be carried out in the return area.
- Frequency is increased approximately every 2 Hz/min. in the up-area.
- Frequency alteration will not be conducted in the steady area.
- Frequency - down is carried out in the step down area approximately every 2 ~ 4 Hz/min.

Setting a constant	H type pair/multi.	J type pair	J type multi.
DCTUYU	12°C	Room temp. ∞ 0.94 - 12.5	11°C

DCTUYU : Heat exchanger temperature of dew condensation sweating prevention










Part 4

System Configuration

1. Instruction.....	36
1.1 FTK25 / 35J, FTX25 / 35J	36





1. Instruction

1.1 FTK25 / 35J, FTX25 / 35J

Safety Precautions

- Read the following warnings and cautions carefully before operating the system and use it correctly.
- This manual classifies the precautions to the user into the following two categories. Be sure to follow all as they are all important to ensure safety.
- After reading this manual, keep it in a place easily accessible to the user for future reference.



WARNING

Failure to follow a warning is very likely to result in such grave consequences as death or serious injury.



CAUTION

Failure to follow a caution may result in serious injury or property damage, and in certain conditions, may result in a grave consequence.



WARNING

Do not attempt to extend the power cord by joining it to another cord, or by using an extension cord. Do not put any other loads on the power supply socket.
Failure to follow this will cause electric shocks, abnormal heating or fire.

Do not damage or attempt to modify the power cord. Do not use the cord in a damaged state or tied in a bundle.
Applying a heavy weight, heat or tension on the power cord will damage it, causing electric shocks or fire.

Do not expose your body to the cool (heat) air for a longtime; do not cool (heat) the room too much.
It will affect your physical conditions and cause health problems.

Do not put a finger, a rod or other objects into the air outlet or inlet.
As the fan is rotating at a high speed, it will cause injury.

Do not attempt to repair, relocate, modify or reinstall the air conditioner by yourself.
Incorrect work will cause electric shocks, fire etc. For repairs and reinstallation, consult the shop where you bought the air conditioner.

If anything abnormal such as a burning smell occurs, stop the operation immediately and turn the breaker OFF.
Continued abnormal operation will cause troubles, electric shocks, fire etc. If anything is abnormal, consult the shop where you bought the air conditioner.



CAUTION

Do not use the air conditioner for preservation purposes.
Do not use it for preserving precision instruments, foods, plants, animals, works of fine arts etc. Performance or quality may deteriorate and animal or plant life may be shorter.

Do not operate the air conditioner with a wet hand.
It may cause an electric shock.

Ventilate the room from time to time.
Be careful especially when using a burning appliance in the same room. Insufficient ventilation may cause shortage of oxygen.

Before cleaning, be sure to stop the operation and turn the breaker OFF.
As a fan is rotating at a high speed, cleaning during operation may cause injury.

After a long use, check the unit stand and fittings for damage.
The unit may drop and cause injury if damage is left unrepaired.

Do not stand or sit on the outdoor unit. Do not place any object on the unit.
The object or the person may fall down or drop, causing injury.

Do not place under the indoor or outdoor unit anything which must be kept away from moisture.
Indoor unit: moisture in the air may condense and drip in certain conditions.
Outdoor unit: during cooling operation, condensation may drip from the piping connections.

Do not wash the unit with water.
It may cause an electric shock.

Do not expose plants or animals directly to the air flow.
It may cause adverse effects on the plant or the animal.

Do not place a vessel containing water on the unit.
Water may penetrate into the unit and degrade electrical insulations, resulting in an electric shock.


Do not place a burning appliance in places exposed to the air flow from the unit or under the indoor unit.
It may cause incomplete combustion or deformation of the unit from heat.

Do not block air inlets nor outlets.
Impaired air flow may result in insufficient performance or troubles.



Names of Parts

Indoor unit




Opening the front grille

How to open the front grille : (See page 47 "Care and Cleaning".)


CAUTION

Before opening the front grille, be sure to stop the operation and turn the breaker OFF. If the power is on, the fan may rotate inside and may cause injury.




Names of Parts

Outdoor unit



Remote controller

<FTK25, 35 FTX25, 35>







Preparation Before Operation

Remote controller

■ Setting the batteries



- 1** Press  with a finger and slide the back cover to take it off.
- 2** Set two dry batteries (AAA).
- 3** Set the back cover as before.
 - This will cause the figures on the display to flash. Set the clock at this point.


ATTENTION

About batteries

- When replacing the batteries, use batteries of the same type, and replace the two old batteries together.
- When the system is not used for a long time, take the batteries out.
- When the operation display screen of the remote controller is hard to see and the reception become hard, replace the batteries with new AAA batteries.
- The attached batteries are provided for the initial use of the system.
The usable period of the batteries may be short depending on the manufactured date of the air conditioner.


■ Operating the remote controller

- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- Do not drop the remote controller. Do not get it wet.
- The maximum distance for communication is about 7 m.



■ To fix the remote controller holder on the wall

- 1** Choose a place from where the signals reach the unit.
- 2** Fix the holder to a wall, a pillar, etc. with the screws supplied with the holder.
- 3** Fit the claw of the holder into the bottom of the remote controller, and push the remote controller onto the wall.



- To remove, pull it upwards.

ATTENTION

About the remote controller

- Never expose the remote controller to direct sunlight.
- Dust on the signal transmitter or receiver will reduce the sensitivity. Wipe off dust with soft cloth.
- Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
- If the remote control signals happen to operate another appliance, move that appliance to somewhere else, or consult the shop.






Preparation Before Operation

Indoor unit

■ Setting the air purifying filters


1 Open the front grille

- Hold the grille by the tabs on the two sides and lift it until it stops with a click. (about 60°)



2 Pull out the air filters.

- Push upwards the tab at the center of each air filter, then pull it down.



3 Set the air purifying filters.


- Attach an air purifying filter to each air filter. (See page 47 "Care and cleaning")

4 Set the air filters in their original positions and close the front grille.


- Operation without air filters may result in troubles as dust will accumulate inside the indoor unit.

■ Setting the clock

1 Press .



2 Press to set the clock to the present time. **TIMER**



- Holding down () or () button

rapidly increases or decreases the time display.

3 Press .



(Now the clock is set.)

■ Turn the breaker ON

- Turning ON the breaker opens the flap, then closes it again. (This is a normal procedure.)

NOTE

Tips for saving energy

- Be careful not to cool (heat) the room too much. Keeping the temperature setting at a moderate level helps save energy.

Recommended temperature setting

For cooling: 26°C – 28°C
For heating: 20°C – 24°C

- Cover windows with a blind or a curtain. Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every two weeks.

Please note

- The air conditioner always consumes 15 – 35 watts of electricity even while it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker OFF.
- Use the air conditioner in the following conditions.


Mode	Operating conditions	If operation is continued out of this range:
COOL	Outdoor temperature : 10 to 46°C Indoor temperature : 18 to 32°C Indoor humidity : 80% max.	• A safety device may work to stop the operation. • Condensation may occur on the indoor unit and drip.
HEAT	Outdoor temperature : -10 to 21°C Indoor temperature : 10 to 30°C	• A safety device may work to stop the operation.
DRY	Outdoor temperature : 21 to 46°C Indoor temperature : 18 to 32°C Indoor humidity : 80% max.	• A safety device may work to stop the operation. • Condensation may occur on the indoor unit and drip.

- Operation outside this humidity or temperature range may cause a safety device to disable the system.

AUTO • DRY • COOL • HEAT • FAN Operation


The air conditioner operates with the settings of your choice.
From the next time on, the air conditioner will operate with the same settings.

1 Press **MODE** and select a mode.




- Each pressing of the button advances the mode setting in sequence.

<FTK>



<FTX>



2 Press **ON/OFF**. Then OPERATION lamp lights up.



■ To stop:

Press **ON/OFF** once again.

Then OPERATION lamp goes off.

■ To change the temperature setting:

DRY or FAN mode	AUTO or HEAT or COOL mode
The temperature setting is not variable.	Press ▲ to raise the temperature and press ▼ to lower the temperature.
	Set to the temperature you like.

To change the air flow rate setting:

Press **FAN**.

DRY mode	AUTO or HEAT or COOL or FAN mode
The air flow rate setting is not variable.	Five levels of air flow rate setting from " " to " "plus " " are available.

- At smaller air flow rates, cooling or heating effect is also smaller.

■ To change the air flow direction:

(See page 43.)

NOTE

<Note on HEAT mode operation>

Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.

The heat pump system heats the room by circulating hot air around all parts of the room. After the start of heating operation, it takes some time before the room gets warmer.

In heating operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost. During defrosting operation, hot air does not flow out of indoor unit.

<Note on DRY mode operation>


This operation dehumidifies the indoor air when it is humid.

<Note on AUTO operation>

In AUTO operation, the system selects a temperature setting and an appropriate mode (COOL or HEAT) based on the room temperature at the start of the operation.

The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.

If you do not like AUTO operation, you can select manually, you like the mode and setting.




POWERFUL Operation

POWERFUL operation quickly maximizes the cooling effect in any operation mode. You can get the maximum capacity with a touch of a button.

- Pressing the (POWERFUL) button during operation starts POWERFUL operation.
- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the settings which were used before POWERFUL operation.

1 Press  .








■ To cancel POWERFUL operation:

Press  .

Notes on POWERFUL operation

- **In COOL and HEAT mode**
To maximize the cooling and heating effect, the capacity of outdoor unit must be increased and the air flow rate be fixed to the maximum setting.
The temperature and air flow settings are not variable.
- **In DRY mode**
The temperature setting is lowered by 3°C and the air flow rate is slightly increased.
- **In FAN mode**
The air flow rate is fixed to the maximum setting.






Adjusting the Air Flow Direction

You can adjust the air flow direction to increase your comfort.

Adjusting the horizontal blade (flap)


Press  .

- Every time the button is pressed, "" appears or disappears.




..... The flap automatically swings up and down.




..... To stop the flap at an angle you like, press  .


Notes on flap angles

- When  is selected, the flap swinging range depends on the operation mode. (See the figure.)
- The real flap angles are different from the display of remote controller.

In DRY mode or COOL mode




In HEAT or FAN mode



ATTENTION

- Always use a remote controller to adjust the flap angle. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.

Adjusting the louvre



Hold the knob and move the louvre.

(You will find a knob on the left-side and the right-side blades.)

ATTENTION

- Be careful when adjusting the louvre. Inside the air outlet, a fan is rotating at a high speed.




Timer Operation

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

OFF TIMER operation

- Check that the clock is correct.
If not, set the clock to the present time. (See page 40.)

- Press **OFF** while the air conditioner is operating.



AM 0:00 is displayed.



⊕ ⊖ blinks.

* Previous time setting appears on display.

- Press **TIMER** until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

- Press **OFF** once again.



Then the TIMER lamp lights up.

■ To cancel the timer:

Press **CANCEL** . Then the TIMER lamp goes off.


Notes on OFF TIMER

- NIGHT SET MODE**
When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time (See page 40).

- Press **ON** while the air conditioner is not operating.



AM 6:00 is displayed.



⊕ ⊖ blinks.

* Previous time setting appears on display.

- Press **TIMER** until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

- Press **ON** once again.



Then the TIMER lamp lights up.

■ To cancel the timer:

Press **CANCEL** .

Then the TIMER lamp goes off.

Combining ON TIMER and OFF TIMER

- A sample setting for combining the two timers is shown below.

(Example)

Present time: 11:00 PM
(The unit operating)
OFF TIMER at 0:00 a.m.
ON TIMER at 7:00 a.m.

Combined




Notes on ON,OFF TIMER

- When TIMER is set, the present time is not displayed.
- Once you set ON,OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote controller batteries are replaced.)

ATTENTION

- In the following cases, set the timer again.
 - After a breaker has turned OFF.
 - After a power failure.
 - After replacing batteries in the remote controller.



Good Sleep Cooling Operation (G-SLEEP)

- The "Good Sleep Cooling Operation" makes the **1/f Fluctuating Temperature**. It brings you comfortable sleep as it prevents from getting chilled.

1 Press  in cooling operation.



■ **To change the temperature setting.** (See page 41.)

■ **To change the air flow rate setting.** (See page 41.)

■ **To change the air flow direction setting.** (See page 43.)


■ **To cancel the "Good Sleep Cooling Operation",** press  .
→ Back to the normal cooling operation.

Notes on "Good sleep cooling operation "

- We adopt the 1/f fluctuation rhythm in temperature control.
A 1/f fluctuation rhythm is used in temperature control. With it, temperature is fluctuated within a $\pm 1^{\circ}\text{C}$ range of the set temperature.
The 1/f fluctuation is comfortable rhythm existed in the natural world. (refer to "What's the 1/f fluctuation")
- Air blow is the lowest when the fan is set to "AUTO".  
- If you don't like this function, change the operation mode. (See page 41)

What is 1/f fluctuation...


It seems irregular but there seems to be a self-resemblance rule in our mother nature.
For example, the waves in the ocean forms irregularly but when you look at the coast line, there are some places where they look similar.
When you look close around you, our heart doesn't beat in regular intervals but shows "1/f fluctuation" in a long term. The research shows this "1/f fluctuation" and comfort has some kind of relation and is applied to the comfort control fiels.







Intelligent Eye

"Intelligent Eye" is the infrared sensor which detects the human movement.

- 1** Press **SENSOR**  While the air conditioner is operating. (The Sensor lamp lights up.)

- **To cancel the "Intelligent Eye",**
press **SENSOR** . (The Sensor lamp goes off.)



[EX.]



"Intelligent Eye" is useful for Energy Saving


- * **Save operation**
- Change the temperature -2°C in heat/ $+2^{\circ}\text{C}$ in cool/ $+1^{\circ}\text{C}$ in dry mode from set temperature.
 - Decrease the air flow rate slightly in fan operation.

Notes on "Intelligent Eye"


- Application range is as follows.
Vertical angle 40° (Side View)
Horizontal angle 50° (Top View)


- Sensor may not respond when you are 5m or more away. (Check the application range)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.

Adjusting the angle of the Intelligent-eye sensor


- You can adjust the angle of the Intelligent-eye sensor to remove the detection area. (Adjustable angle: 15° to right and left of centre)



- Gently push and slide the sensor to adjust the angle.



Moving the sensor to the left



Moving the sensor to the right

- After adjusting the angle, gently wipe the sensor with a clean cloth, being careful not to scratch the sensor.


CAUTION


- Do not hit or violently push the Intelligent-eye sensor. This can lead to damage and malfunction.

- Saving operation will not go on during powerful operation.
- Night set mode (see page 44.) will not go on during you use Intelligent Eye.
- You can sleep more comfortably by using "Good Sleep Cooling Operation (G-SLEEP)" function (see page 45.) at the same time.

CAUTION

Do not place large objects near the sensor. Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect objects it shouldn't as well as not detect objects it should.





Care and Cleaning



CAUTION


Before cleaning, be sure to stop the operation and turn the breaker OFF.

Cleaning the air filters

(It is recommended to clean them every two weeks.)


1 Open the front grille

- Hold the grille by the tabs on the two sides and lift it until it stops with a click. (about 60°)




2 Pull out the air filters.

- Push a little upwards the tab at the center of each air filter, then pull it down.




3 Take off the air purifying filters and clean them.

- Wash them with water, or clean them with a vacuum cleaner.
- If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.



4 Set the air purifying filters and the air filters as they were and close the front grille .



- Insert claws of the filters into slots of the front panel. The front grille should lock at both sides and at the point in the middle. Push the grille at the 3 points indicated by ↓.

NOTE

- In a dusty environment, clean the air filters at least once in every two weeks even before the cleaning lamp lights up.
- Operation with dusty air filters lowers the cooling and heating capacity and wastes energy.

Cleaning the indoor and outdoor units and the remote controller

- Wipe them with dry soft cloth.
For cleaning, do not use water hotter than 40°C, benzene, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes nor other hard stuff.

Replacing air purifying filters


(It is recommended to replace them every three months.)

- Air purifying filters need to be replaced regularly.


1 Open the front grille and pull out the air filters.

2 Take off the air purifying filters.


3 Detach the filter element and attach a new one .



- Hold the recessed parts of the frame and unhook the four claws.



4 Attach the air purifying filter .




5 Set the air filters as they were and close the front grille

(Push the grille at the 3 points, two at both sides and in the middle.)

NOTE

- To order air purifying filters, contact the service shop where you bought the air conditioner.
- Once the air purifying filter element gets dirty, it is not reusable but must be thrown away.
- Operation with dirty air purifying filters :
 - cannot clean the air.
 - results in poor cooling.
 - may cause odour.

Item	Part No.
Air purifying filter (with frame)	KAF918A41
Air purifying filter (without frame)	KAF918A42



Care and Cleaning

Cleaning the front grille

You may remove the front grille for cleaning.




CAUTION

- When removing or attaching the front grille, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front grille, support the grille securely with hand to prevent it from falling.
- For cleaning, do not use water hotter than 40°C, benzine, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes nor other hard stuff.
- After cleaning, make sure that the front grille is securely fixed.


1 Open the front grille.

- Hold the grille by the tabs on the two sides and lift it until it stops with a click.



2 Remove the front grille.

- Supporting the front grille with one hand, release the lock by sliding down the knob with the other hand.
- To remove the front grille, pull it toward yourself with both hands.




3 Clean the front grille.

- You may wipe it with a soft cloth soaked in water.
- Only neutral detergent may be used.
- You may wash the grille with water. After washing, dry it with cloth, then dry it up in the shade.

4 Attach the front grille.

- Set the 3 keys of the front grille into the slots and push them in all the way.
- Supporting the front grille with one hand, fit the lock by sliding up the knob with the other hand.
- Close the front grille slowly in this state. (Push the grille at the 3 points, two at both sides and in the middle.)



Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.

Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.

Check that the earth wire is not disconnected or broken.

Check that the drain comes smoothly out of the drain hose during COOL or DRY operation.

- If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

Before a long idle period

- 1 Operate the fan alone for several hours on a fine day to dry out the inside.


<FTK>

- 1 Press **MODE** and select "  ".

- 2 Press  .

<FTX>


- 1 Press **MODE** and select "  ".

- 2 Press  and set the temperature to 32°C

- 3 Press  .

- Perform this operation when the room temperature is under 28°C.

- 2 Clean the air filters and set them again.
- 3 Take out batteries from the remote controller.
- 4 Turn OFF the breaker for the room air conditioner.



Troubleshooting

● These cases are not troubles.

The following cases are not air conditioner troubles but have some reasons. You may just continue using it.

Case	Explanation
Operation does not start soon. <ul style="list-style-type: none">● When ON/OFF button was pressed soon after operation was stopped.● When the mode was reselected.	<ul style="list-style-type: none">● This is to protect the air conditioner. You should wait for about 3 minutes.
Hot air does not flow out soon after the start of heating operation.	<ul style="list-style-type: none">● The air conditioner is warming up. You should wait for 1 to 4 minutes. (The system is designed to start discharging air only after it has reached a certain temperature.)
The heating operation stops suddenly and a flowing sound is heard.	<ul style="list-style-type: none">● The system is taking away the frost on the outdoor unit. You should wait for about 3 to 8 minutes.
The outdoor unit emits water or steam.	<ul style="list-style-type: none">■ In HEAT mode<ul style="list-style-type: none">● The frost on the outdoor unit melts into water or steam when the air conditioner is in defrost operation.■ In COOL or DRY mode<ul style="list-style-type: none">● Moisture in the air condenses into water on the cool surface of outdoor unit piping and drips.
Mists come out of the indoor unit.	<ul style="list-style-type: none">■ This happens when the air in the room is cooled into mist by the cold air flow during cooling operation.
The indoor unit gives out odour .	<ul style="list-style-type: none">■ This happens when smells of the room, furniture, or cigarettes are absorbed into the unit and discharged with the air flow. (If this happens, we recommend you to have the indoor unit washed by a technician. Consult the service shop where you bought the air conditioner.)
The outdoor fan rotates while the air conditioner is not in operation.	<ul style="list-style-type: none">■ After operation is stopped:<ul style="list-style-type: none">● The outdoor fan continues rotating for another 30 seconds for system protection.■ While the air conditioner is not in operation:<ul style="list-style-type: none">● When the outdoor temperature is very high, the outdoor fan starts rotating for system protection.
The operation stopped suddenly. (OPERATION lamp is on)	<ul style="list-style-type: none">■ For system protection, the air conditioner may stop operating on a sudden large voltage fluctuation. It automatically resumes operation in about 3 minutes.







Troubleshooting

● Check again

Please check again before calling a repair person.

Case	Check
The air conditioner does not operate . (OPERATION lamp is off)	<ul style="list-style-type: none">● Hasn't a breaker turned OFF or a fuse blown?● Isn't it a power failure?● Are batteries set in the remote controller?● Is the address switch in the remote controller set correctly? (See page 39 "Preparation Before Operation".)● Is the timer setting correct?
Cooling or Heating effect is poor .	<ul style="list-style-type: none">● Are the air filters clean?● Is there anything to block the air inlet or the outlet of the indoor and the outdoor units?● Is the temperature setting appropriate?● Are the windows and doors closed?● Are the air flow rate and the air direction set appropriately?● Is the unit set to the Intelligent Eye mode? (See page 46.)
Operation stops suddenly. (OPERATION lamp blinks.)	<ul style="list-style-type: none">● Are the air filters clean?● Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? Clean the air filters or take all obstacles away and turn the breaker OFF. Then turn it ON again and try operating the air conditioner with the remote controller. If the lamp still blinks, call the service shop where you bought the air conditioner.
An abnormal functioning happens during operation.	<ul style="list-style-type: none">● The air conditioner may malfunction with lightening or radio waves. Turn the breaker OFF, turn it ON again and try operating the air conditioner with the remote controller.






Part 5

Service Diagnosis

1. Caution for Diagnosis	52
1.1 Troubleshooting with The Operation Lamp	52
2. Problem Symptoms and Measures	54
3. Service Check Function	55
3.1 ARC423 Series.....	55
4. Code Indication on The Remote Controller.....	56
4.1 Error Codes and Description of Fault	56
5. Troubleshooting	57
5.1 Indoor Units	57
5.2 Outdoor Units	58
5.3 Faulty PCB	59
5.4 Operation Shutdown Due to High-Pressure Control or Freeze-Up Protection (Thermistor Activation)	60
5.5 Operation Halt Due to Fan Motor (AC Motor) or Related Abnormality. .	61
5.6 Operation Halt Due to Detection of Thermistor or Related Abnormality	62
5.7 Faulty Indoor Unit PCB.....	63
5.8 Faulty Indoor Unit PCB.....	64
5.9 Power Supply Abnormalities or Faulty Indoor Printed Circuit Boards ...	65
5.10 Signal Transmission Error (Between Indoor and Outdoor Units)	66
5.11 Operation Halt Due to Detection of CT Error.....	67
5.12 Operation Halt Due to Thermistor Error or Disconnection Detection.....	68
5.13 Operation Halt Due to Compressor Startup Error.....	69
5.14 Output Overcurrent.....	70
5.15 Faulty Outdoor Unit PCB.....	72
5.16 Faulty Outdoor Unit PCB and Transmitting/Receiving Circuit	73
5.17 Operation Halt Due to Detection of Input Over Current.....	74
6. Check.....	76
6.1 How to Check	76






1. Caution for Diagnosis

1.1 Troubleshooting with The Operation Lamp



The Operation lamp flashes when any of the following errors is detected.


1. When a protection device of the indoor or outdoor unit is activated or when the thermistor malfunctions, disabling equipment operation.
 2. When a signal transmission error occurs between the indoor and outdoor units.
- In either case, conduct the diagnostic procedure described in the following pages.

Location of Operation Lamp



(RL029)






SIE-86

Caution for Diagnosis

Troubleshooting with The LED Indication

Outdoor Unit
RK25 / 35J Series
RX25 / 35J Series





There are green and red LEDs on the PCB. The flashing green LED indicates normal equipment condition, and the OFF condition of the red LED indicates normal equipment condition.

(Troubleshooting with the green LED)

The LED A of the outdoor unit indicate microcomputer operation condition.

Even after the error is canceled and the equipment operates in normal condition, the LED indication remains.





2. Problem Symptoms and Measures

Problem Symptom	Check Item	Details of Measure	Page No. to be referred
None of The Units Operates.	Check the power supply.	Check to make sure that the rated voltage is supplied.	—
	Check the type of the indoor units.	Check to make sure that the indoor unit type is compatible with the outdoor unit.	—
	Check the outside air temperature.	Heating operation cannot be used when the outside temperature is 30°C or higher (only for heat pump model), and cooling operation cannot be used when the outside temperature is below 0°C.	—
	Diagnosis with indoor unit LED indication	—	—
	Diagnosis with outdoor unit LED indication	—	58
	Check the remote controller addresses.	Check to make sure that address settings for the remote controller and indoor unit are correct.	—
Operation Sometimes Stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation. (Operation lamp OFF)	—
	Check the outside air temperature.	Heating operation cannot be used when the outside temperature is 30°C or higher (only for heat pump model), and cooling operation cannot be used when the outside temperature is below 0°C.	—
	Diagnosis with indoor unit LED indication	—	—
	Diagnosis with outdoor unit LED indication	—	58
Some indoor units do not operate.	Check the type of the indoor units.	Check to make sure that the indoor unit type is compatible with the outdoor unit.	—
	Diagnosis with indoor unit LED indication	—	—
	Diagnosis with outdoor unit LED indication	—	58
Equipment operates but does not cool, or does not heat (only for heat pump model).	Check for thermistor detection errors.	Check to make sure that the main unit's thermistor has not dismantled from the pipe holder.	—
	Diagnosis with indoor unit LED indication	—	—
	Diagnosis with outdoor unit LED indication	—	58
	Diagnosis by service port pressure and operating current	Check for insufficient gas.	82
Large Operating Noise and Vibrations	Check the output voltage of the power transistor.	—	78
	Check the power transistor.	—	—
	Check the installation condition.	Check to make sure that the required spaces for installation (specified in the Technical Guide, etc.) are provided.	—




3. Service Check Function

3.1 ARC423 Series

In the ARC423A series, the temperature display sections on the main unit indicate corresponding codes.

1. When the timer cancel button is held down for 5 seconds, a "00" indication flashes on the temperature display section.

< Cover in open position >



2. Press the timer cancel button repeatedly until a continuous beep is produced.

■ The code indication changes in the sequence shown below, and notifies with along beep

No.	Code	No.	Code	No.	Code
1	00	11	E1	21	UR
2	U4	12	C1	22	R5
3	F3	13	H8	23	J9
4	E6	14	J3	24	E8
5	L5	15	R3	25	P4
6	R6	16	R1	26	L3
7	E5	17	C4	27	L4
8	LC	18	C5	28	H6
9	C9	19	H9	29	H7
10	U0	20	J6	30	U2



Note:



1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.



4. Code Indication on The Remote Controller

4.1 Error Codes and Description of Fault

	Code Indication	Description of Problem
System	00	Normal
	U4	Signal transmission error (between indoor and outdoor units)
Indoor Unit	R1	Faulty indoor unit PCB
	R5	Operation halt due to the freeze protection function or high pressure control
	R6	Fan motor or related abnormality
	C4	Heat exchanger temperature thermistor abnormality
	C9	Room temperature thermistor abnormality
	CR	Discharge air temperature thermistor abnormality
Outdoor Unit	E6	Compressor startup error
	E8	Inverter units - Input overcurrent
	H8	CT or related abnormality
	H9	Outside air thermistor or related abnormality
	J3	Discharge pipe temperature thermistor or related abnormality
	J6	Heat exchanger temperature thermistor or related abnormality
	L5	Inverter units - Output overcurrent






5. Troubleshooting

5.1 Indoor Units

- : Not used for troubleshooting
* : Varies depending on the cases.

Indication on the remote controller	Description of The Fault		Details of fault (Refer to the indicated page.)
00 OR *	Indoor unit in normal condition (Conduct a diagnosis of the outdoor unit.)		—
R1	Inverter unit - Faulty indoor unit PCB		
R5	Operation halt due to the freeze protection function or high pressure control (heat pump model only)		60
R6	Faulty fan motor (AC motor stop)	AC motor	61
C4	Heat exchanger temperature thermistor or related abnormality		62
C9	Suction thermistor or related abnormality		62
CA	Discharge thermistor or related abnormality		62
*	Faulty indoor unit PCB		63
			64
* OR U4	Faulty power supply or indoor unit PCB		65
U4	Signal transmission error (between indoor and outdoor units)		66





5.2 Outdoor Units


























































☀: ON, ●: OFF, ⚡: Blinks

Green: Flashes when in normal condition

Red: OFF in normal condition

- : Not used for troubleshooting


* : Varies depending on the cases.

Outdoor Unit LED Indication					Indication on the remote controller	Description of The Fault	Details of Fault (Refer to the indicated page.)
Green	Red						
A	1	2	3	4			
					*	Outdoor unit in normal condition (Conduct a diagnosis of the indoor unit.)	—
					(U0)	Operation halt due to detection of insufficient gas.	
					(E5)	Abnormal discharge pipe temperature.	
						Operation halt due to IT activation.	
					E6	Operation halt due to detection of compressor startup error.	69
					—	Operation halt due to radiation fin temperature rise. (Protection of driver overheating)	
					H8	Operation halt due to detection of CT abnormality.	67
					H9	Operation halt due to outside air thermistor abnormality.	68
					J3	Operation halt due to discharge pipe thermistor abnormality, or due to detection of disconnected discharge pipe thermistor.	68
					J6	Operation halt due to outdoor unit heat exchanger thermistor abnormality.	68
					L5	Operation halt due to detection of output overcurrent.	70
					E8	Operation halt due to detection of input overcurrent.	74
					—	Operation halt due to the freeze protection function.	
					—	Operation halt due to the freeze protection function or indoor unit icing protection.	(Conduct a diagnosis of the indoor unit.)
	*	*	*	*	*	Faulty outdoor unit PCB	72
	*	*	*	*	*	Faulty outdoor unit PCB or signal transmitting/receiving circuit.	73

**Note:**

- The indications in the parenthesis () in the remote controller display column are displayed only when system-down occurs.
- When a sensor error occurs, check the remote controller display to determine which sensor is malfunctioning.
If the remote controller does not indicate the error type, conduct the following operation.
*Turn the power switch off and back on again. If the same LED indication appears again immediately after the power is turned on, the fault is in the thermistor.
*If the above condition does not result, the fault is in the CT.
- The indoor unit error indication may take the precedence in the remote controller display.





5.3 Faulty PCB (A1)

Remote Controller
Display

A1

Indoor unit LED
Display

Method of
Malfunction
Detection

Evaluation of zero-cross detection of power supply by indoor unit.


Malfunction
Decision
Conditions

When there is no zero-cross detection in approximately 10 continuous seconds.


Supposed Causes


- Faulty indoor unit PCB
- Faulty connector connection

Troubleshooting



Note: Connector Nos. vary depending on models.
Control connector.....S35 and S26





5.4 Operation Shutdown Due to High-Pressure Control or Freeze-Up Protection (Thermistor Activation) (A5)

Remote Controller
Display

A5

Indoor unit LED
Display

Method of
Malfunction
Detection

- High pressure control
During heating operations, the temperature detected by the indoor heat exchanger thermistor is used for the high pressure control (stop, outdoor fan stop, etc.)
- The freeze protection control (operation halt) is activated during cooling operation according to the temperature detected by the indoor unit heat exchanger thermistor.


Malfunction
Decision
Conditions

- High pressure control
During heating operations, the temperature detected by the indoor heat exchanger thermistor is above 67°C
- Freeze protection
When the indoor unit heat exchanger temperature is below 0°C during cooling operation.


Supposed Causes

- Operation halt due to clogged air filter of the indoor unit.
- Operation halt due to dust accumulation on the indoor unit heat exchanger.
- Operation halt due to short-circuit.
- Detection error due to faulty indoor unit heat exchanger thermistor.
- Detection error due to faulty indoor unit PCB.

Troubleshooting



(RF002)



5.5 Operation Halt Due to Fan Motor (AC Motor) or Related Abnormality.(A6)

Remote Controller
Display

A6

Indoor unit LED
Display

Method of
Malfunction
Detection

The rotation speed detected by the hall IC during fan motor operation is used to determine abnormal fan motor operation.

Malfunction
Decision
Conditions

When the detected rotation speed is less than 50% of the HH tap under maximum fan motor rotation demand.


Supposed Causes

- Operation halt due to short circuit inside the fan motor winding.
- Operation halt due to breaking of wire inside the fan motor.
- Operation halt due to breaking of the fan motor lead wires.
- Operation halt due to faulty capacitor of the fan motor.
- Detection error due to faulty indoor unit PCB (1).

Troubleshooting




Check No.16
Refer to P.83




(MF002)

5.6 Operation Halt Due to Detection of Thermistor or Related Abnormality (C4,C9,CA)


Remote Controller Display	C4, C9, CA
Indoor unit LED Display	
Method of Malfunction Detection	The temperatures detected by the thermistors are used to determine thermistor errors.
Malfunction Decision Conditions	When the thermistor input is more than 4.96 V or less than 0.04 V during compressor operation*. * (reference) When above about 212°C (less than 120 ohms) or below about -50°C (more than 1,860 kohms).
 Note:	The values vary slightly in some models.
Supposed Causes	<ul style="list-style-type: none">■ Faulty connector connection■ Faulty thermistor■ Faulty PCB

Troubleshooting


Check No.5
Refer to P.79



C4 : Heat exchanger temperature thermistor
C9 : Suction air thermistor
CA : Discharge air thermistor



5.7 Faulty Indoor Unit PCB

Remote Controller Display

*

Indoor unit LED Display**Method of Malfunction Detection**




The proper program operation of the microcomputer is checked by the program.


Malfunction Decision Conditions

When the microcomputer program does not function properly.

Supposed Causes

- Microcomputer program is in abnormal condition due to an external factor.
 - *Noise.
 - *Momentary voltage drop.
 - *Momentary power failure, etc.
- Faulty indoor unit PCB.


Troubleshooting



5.8 Faulty Indoor Unit PCB

Remote Controller Display	*
Indoor unit LED Display	
Method of Malfunction Detection	The condition of the transmission circuit for indoor-outdoor signal transmission is detected.
Malfunction Decision Conditions	When the transmission circuit remains ON.
Supposed Causes	■ Faulty indoor unit PCB
Troubleshooting	Replace the indoor unit PCB.





5.9 Power Supply Abnormalities or Faulty Indoor Printed Circuit Boards(U4)

Remote Controller
Display

* or **U4**

Indoor unit LED
Display

Method of
Malfunction
Detection

1. The proper program operation of the microcomputer is checked by the program.
2. In indoor-outdoor signal communications, the indoor unit determines whether the outdoor unit receives signals properly by detecting signals transmitted by the outdoor unit to the indoor unit.


Malfunction
Decision
Conditions

1. When the microcomputer program does not function properly.
2. When the indoor unit determines that the indoor unit does not properly receive signals transmitted by the outdoor unit in indoor-outdoor signal communications.


Supposed Causes

- Display disabled by fault power supply.
- Faulty signal transmitting/receiving circuit in indoor printed circuit boards (1) and (2)
- Microcomputer program is in abnormal condition due to an external factor.
 - Noise.
 - Momentary voltage drop.
 - Momentary power failure, etc.
- Faulty indoor unit PCBs (1) and (2).

Troubleshooting



(RF003)



5.10 Signal Transmission Error (Between Indoor and Outdoor Units) (U4)

Remote Controller
Display

U4

Indoor unit LED
Display

Method of
Malfunction
Detection

The data received from the outdoor unit in indoor unit-outdoor unit signal transmission is checked whether it is normal.

Malfunction
Decision
Conditions

When the data sent from the outdoor unit cannot be received normally, or when the content of the data is abnormal.


Supposed Causes

- Faulty outdoor unit PCB.
- Faulty indoor unit PCB.
- Indoor unit-outdoor unit signal transmission error due to wiring error.
- Indoor unit-outdoor unit signal transmission error due to disturbed power supply waveform.
- Indoor unit-outdoor unit signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units (wire No. 2).

Troubleshooting



Check No.13
Refer to P.82



(MF007)

5.11 Operation Halt Due to Detection of CT Error(H8)

Remote Controller
Display

H8

Outdoor unit LED
Display

A 1 2 3 4

Method of
Malfunction
Detection

CT errors are detected using the compressor's operating frequency and the input current detected by the CT.

Malfunction
Decision
Conditions

When the compressor's operating frequency is more than 62 Hz and the CT input is less than 0.1 V.
* Inlet current 0.75 A

- When a CT error is generated 4 times, the system shuts down.
- The malfunction counter will be reset unless the emergency stop will take place within sixty minutes of the compressor operation time (as integrated time) after the return from the malfunction (including the other emergency stops).

Supposed Causes

- Faulty power transistor
- Breaking of wire or faulty connection of internal wiring
- Faulty outdoor PCB (1).


Troubleshooting



Check No.3
Refer to P.76



Check No.11
Refer to P.81








5.12 Operation Halt Due to Thermistor Error or Disconnection Detection(J3,J6,H9)

Remote Controller
Display

J3, J6, H9

Indoor unit LED
Display

A  1  2  3  4 

Method of
Malfunction
Detection

Thermistor errors are detected using thermistor input voltage to micro computer. (Thermistor errors are detected using the temperatures detected by the thermistors.)

Malfunction
Decision
Conditions

When the thermistor input during compressor operation is more than 4.96 V or less than 0.04 V.
* Value changes depends on models


Supposed Causes

- Faulty connector connection
- Faulty thermistor
- Faulty PCB

Troubleshooting



Check No.5
Refer to P.79



J3 : Discharge pipe thermistor
J6 : Outdoor unit heat exchanger thermistor
H9 : Outside air thermistor

5.13 Operation Halt Due to Compressor Startup Error(E6)

Remote Controller
Display

E6

Indoor unit LED
Display

A 1 2 3 4

Method of
Malfunction
Detection

Compressor startup errors are detected using input current detected by CT and compressor's operation frequency.

Malfunction
Decision
Conditions

When the inlet current is over the setting value.

* Setting value = $(145 / 256 \times \text{Output frequency}) - 6 \text{ (A)}$

- When a compressor startup error is generated 16 times consecutively, the system shuts down. (The 16 time counter resets itself when OL, insufficient gas or compressor startup error does not occur within 60 minutes of compressor operation time (cumulative time) after the error generation.)

Supposed Causes


- Startup error due to faulty compressor.
- Startup error due to faulty outdoor unit PCB.
- Startup error due to closed stop valve.
- Detection error due to faulty outdoor unit PCB.

Troubleshooting

Check No.3
Refer to P.76

Check No.4
Refer to P.78

Check No.15
Refer to P.82



(MF012)



5.14 Output Overcurrent (L5)

Remote Controller
Display

L5

Indoor unit LED
Display

A 1 2 3 4

Method of
Malfunction
Detection

Detection of output overcurrent based on current flowing in DCCT.
(Inverter direct current part)


Malfunction
Decision
Conditions

When output overcurrent enters microcomputer from output overcurrent detection circuit.
When error occurs 16 times, system shuts down.

Condition for error counter reset
When compressor operates for 5 minutes without output overcurrent.


Supposed Causes

- Overcurrent due to faulty power transistor.
- Overcurrent due to faulty internal wiring.
- Overcurrent due to supply voltage abnormality.
- Overcurrent due to faulty PCB.
- Overcurrent due to closed stop valve.
- Overcurrent due to faulty compressor.
- Overcurrent due to improper installation condition.



Troubleshooting

* Erroneous internal wiring can result in output overcurrent in some cases. If system stops due to output overcurrent after parts replacement that requires disconnection of wires, check wiring carefully



(RF006)



Troubleshooting

SIE-86

5.15 Faulty Outdoor Unit PCB

Remote Controller
Display

*

Indoor unit LED
Display

A ☀ 1 * 2 * 3 * 4 *

Method of
Malfunction
Detection

The proper program operation of the microcomputer is checked by the program.


Malfunction
Decision
Conditions

When the microcomputer program does not function properly.

Supposed Causes

- Microcomputer program run-away due to an external factor.
 - *Noise
 - *Momentary voltage drop
 - *Momentary power failure, etc.
- Faulty outdoor unit PCB.

Troubleshooting



(MF027)




5.16 Faulty Outdoor Unit PCB and Transmitting/Receiving Circuit


Remote Controller Display	*
Indoor unit LED Display	A ● 1 * 2 * 3 * 4 *
Method of Malfunction Detection	<ol style="list-style-type: none"> 1. The proper program operation of the microcomputer is checked by the program. 2. Signals transmitted from the outdoor unit to the indoor unit are received by the outdoor unit itself in indoor unit -outdoor unit signal transmission mode, and proper receiving of the signals by the indoor unit is checked.
Malfunction Decision Conditions	<ol style="list-style-type: none"> 1. When the microcomputer program does not function properly. 2. When the signals transmitted from the outdoor unit to the indoor unit are received by the outdoor unit itself in indoor unit-outdoor unit signal transmission mode, but not properly. 3. When the zero cross signal is not detected over 10 seconds.
Supposed Causes	<ul style="list-style-type: none"> ■ Display disabled by faulty power supply. ■ Microcomputer program run-away due to an external factor. <ul style="list-style-type: none"> *Noise *Momentary voltage drop *Momentary power failure, etc. ■ Faulty outdoor unit PCB.

Troubleshooting



Check No.13
Refer to P.82





5.17 Operation Halt Due to Detection of Input Over Current (E8)

Remote Controller
Display

E8

Indoor unit LED
Display

A 1 2 3 4

Method of
Malfunction
Detection

Input over current is checked using the input current detected by the CT during compressor operation.

Malfunction
Decision
Conditions





When the CT input remains above the value shown in the below table for 2.5 seconds during compressor operation.

Table for constant

Model	Input current (A)
RK(X)25, 35 Series	0.75





Supposed Causes


- Over current due to faulty compressor.
- Over current due to faulty power transistor.
- Over current due to faulty electrolytic capacitor of the main inverter circuit.
- Over current due to faulty PCB (1).
- Detection error due to faulty PCB (1).
- Over current due to short-circuit.



Troubleshooting

* Internal wiring errors can cause an input over current. If the equipment stops due to an input over current after the wires are disconnected and connected again for parts replacement, etc., check for wiring errors.

- 
Check No.3
Refer to P.76
- 
Check No.4
Refer to P.78
- 
Check No.12
Refer to P.81
- 
Check No.6
Refer to P.80



(MF022)

6. Check

6.1 How to Check

6.1.1 Power transistor check Capacitor voltage check (CHEK 3)

Check No.3

1. Power transistor check



Note: Check to make sure that the voltage between the terminal of Power transistor (+) and (-) is approx. 0 volt before checking power transistor.

< Measuring method >


Disconnect the compressor harness connector from the outdoor unit PCB. To disengage the connector, press the protrusion on the connector.

Then, follow the procedure below to measure resistance between power transistor (+) and (-) and the U, V and W terminals of the compressor connector with a multi-tester. Evaluate the measurement results for a pass/fail judgment.

<Power transistor check>

Negative (-) terminal of tester (positive terminal (+) for digital tester)	Power transistor (+)	UVW	Power transistor (-)	UVW
Positive (+) terminal of tester (negative terminal (-) for digital tester)	UVW	Power transistor (+)	UVW	Power transistor (-)
Normal resistance	Several kΩ to several MΩ (*)			
Unacceptable resistance	Short (0 Ω) or open			

<Measuring positions>



2. Capacitor voltage check


< Measuring method >

Before measuring, operate the unit for several minutes, then shut down the operation by force using the circuit breaker.

- If the unit is shut down using the remote controller instead of the circuit breaker, the capacitor discharges the electric load, thus disallowing accurate measurement.



Note: The charge section is applied with high voltage. Therefore, exercise caution during measurement to prevent electric shock.



SIE-86



Check



< Measuring positions >

Take measurements at the power transistor (+) and (-) terminals in the same way as described in section 1.
Set the multi-tester to DC and VOLTAGE RANGE before measurement.

* Since capacitor (+) and (-) are connected to power transistor (+) and (-), capacitor voltage can be measured at the power transistor (+) and (-) terminals.





Check

SIE-86

6.1.2 Power Transistor Output Check (CHEK 4)

Check No.4

Measure the output current and voltage of the power transistor.

Output Current Measurement

Remove the front panel, and measure the current in the red, yellow and blue wire harness inside the compressor using a clamp meter.


1. Attach the clamp meter to the red, yellow and blue wire harness, and conduct forced cooling operation.
2. When the output frequency has stabilized, measure the output current of each phase.
3. If the current outputs of all the phase are balanced, it is normal.
4. If even one phase is out of balance, replace the outdoor unit PCB.
5. If the compressor stops before the output frequency stabilizes, measure the output voltage.

Output Voltage Measurement


Remove the front panel, and disconnect the red, yellow and blue wire harness inside the compressor from the terminals. Measure the output voltage of the red, yellow and blue wires using a tester.

1. Conduct forced cooling operation with the equipment in the condition shown in Fig.1.
2. Measure the voltage between the operation start (when the outdoor unit fan starts rotating) to operation halt caused by an CT error (about 15 seconds).
3. Reset the power, and repeat steps (1) to (3) for each phase of U-V, V-W and W-U.
4. If the voltages of all the phases show results similar to the solid line in the graph shown in Fig.2, the outdoor PCB is normal.
5. If the voltage of even one phase deviates from the solid line shown in Fig.2, conduct the following test.
■ Check the harness between the power transistor and compressor (check items: breaking of wire and wiring errors). If the harness is normal, replace the PCB..

[Fig.1]





[Fig.2]



Note:

1. Do not touch the terminals of the red, yellow and blue wires when the power is supplied. (Touching them is very dangerous since a voltage of over 100V is applied.)
2. Do not short-circuit the terminals of the red, yellow, and blue wires.





SIE-86

Check




6.1.3 Thermistor Resistance Check No.5

Check No.5


Remove the connectors of the thermistors on the PCB, and measure the resistance of each thermistor using tester.

The relationship between normal temperature and resistance is shown in the graph and the table below.

Thermistor	R25°C=20kΩ B=3950
Temperature (°C)	
-20	211.0 (kΩ)
-15	150
-10	116.5
-5	88
0	67.2
5	51.9
10	40
15	31.8
20	25
25	20
30	16
35	13
40	10.6
45	8.7
50	7.2





(R25=20kΩ、B=3950)




(ML099)

For the models whose thermistor is directly equipped on the printed circuit board;

- Remove the signal receiver and the display printed circuit board (disconnect the connector too), and then measure ohm by an ohmmeter at the both ends.
- The relation between temperature and resistance is in common with the existing models.







Check

SIE-86

6.1.4 Installation Condition Check No.6

Check No.6






SIE-86

Check

6.1.5 Rectifier Check No.11

Check No.11







There are several different terminal position patterns. Therefore, be sure to check the terminal marks.

Negative (-) terminal of tester (positive terminal (+ for digital tester)	~	+	~	-
Positive (+) terminal of tester (negative terminal (-) for digital tester)	+	~	-	~
Normal resistance	Several KΩ to MΩ	∞	∞	Several KΩ to MΩ
Unacceptable resistance	0 or ∞	0	0	0 or ∞

6.1.6 Discharge Pressure Check No.12

Check No.12





Check

SIE-86

6.1.7 Power Supply Waveforms Check No.13


Check No.13

Measure the power supply waveform between pins 1 and 3 on the terminal board, and check the waveform disturbance.


- Check to see if the power supply waveform is a sine wave (Fig.1).
- Check to see if there is waveform disturbance near the zero cross (sections circled in Fig.2)

[Fig.1]

[Fig.2]




(ML104)



(ML105)

6.1.8 Inverter Units Compressor/refrigerant System Check No.15

Check No.15







6.1.9 Inverter Units Hall IC Check No.16

Check No.16


- 1. Check the connector connection.
- 2. With the power ON, operation OFF, and the connector connected, check the following.
 - *Output voltage of about 5 V between pins 1 and 3.
 - *Generation of 3 pulses between pins 2 and 3 when the fan motor is operating.

Failure of (1) → faulty PCB → Replace the PCB.
Failure of (2) → faulty hall IC → Replace the fan motor.
Both (1) and (2) result → Replace the PCB.

The connector has 3 pins, and there are two patterns of lead wire colors.



(ML106)








Check



SIE-86






Part 6

Removal Procedure

1. For FTK25J, FTK35J, FTX25J, FTX35J	86
1.1 Removal of Air Filter	86
1.2 Removal of Front Grille.....	88
1.3 Removal of Horizontal Blade and Vertical Blade.....	90
1.4 Removal of Switch Box, PC Board and Swing Motor	92
1.5 Removal of Heat Exchanger.....	97
1.6 Install of Drain Plug	99
1.7 Removal of Fan Rotor and Motor	100
2. For RK25J, RK35J, RX25J, RX35J.....	103
2.1 Removal of External Casing	103
2.2 Removal of Bellmouth and Left Side Plate.....	105
2.3 Removal of PC Board and Switch Box	106
2.4 Removal of Propeller Fan and Fan Motor	111
2.5 Removal of Compressor Noise Absorption Pad.....	112
2.6 Removal of Partition Plate and Reactor.	114
2.7 Removal of Four-way Valve.	116
2.8 Removal of Compressor.....	118





For FTK25J, FTK35J, FTX25J, FTX35J

SIE-86




1. For FTK25J, FTK35J, FTX25J, FTX35J

1.1 Removal of Air Filter


Procedure



Warning Be sure to turn off all power supplies before disassembling work.




Step	Procedure	Points
1. External features (Illustrations show D series.)		<ul style="list-style-type: none">■ If ON/OFF button is kept pushing for 5 seconds, a forced cooling operation will be carried out for approx. 15 minutes.
2. Removing air filters	 	<ul style="list-style-type: none">■ Left and right filters are interchangeable.■ To re-install, insert air filter along the guide.







SIE-86

For FTK25J, FTK35J, FTX25J, FTX35J






Step	Procedure	Points
3. Opening and shutting front panel		
1	<p>Hook a finger onto the projection part provided on the both sides of the unit's panel and open up the panel to the position higher than it will stop.</p>  <p>Slide the center rotary axis the left and remove it out.</p> <p>(RR004)</p>	<p>Support the front panel by one hand, while remove the rotation axis at the upper center by the other hand.</p> <p>■ And pull out the front panel forward to remove.</p>
2	<p>Remove front panel from the unit.</p>  <p>(RR005)</p>	
3	<p>When restoring the air filter, make sure that the projection parts on the panel are in the guide groove, and then shut the panel.</p>  <p>(RR006)</p>	




For FTK25J, FTK35J, FTX25J, FTX35J

SIE-86

1.2 Removal of Front Grille


Procedure		<div>  Warning Be sure to turn off all power supplies before disassembling work. </div>	
Step	Procedure	Points	
1. Opening and closing of service cover			
1	Remove a service cover mounting screw. Open service cover upward	 <p>(RR007)</p>  <p>Connection wires (3 wires)</p> <p>(RR008)</p>	<div> <div></div> A switch for field setting is not provided in particular. </div>
2. Removal of front grille assembly.			
1	Remove the two screws, in the right and the left, which fix the main body with the front grille.	 <p>16mm</p> <p>(RR009)</p>  <p>(RR010)</p>	<div> <div></div> Screw stoppers inside the flap which were equipped in the existing models are not provided. </div>





SIE-86


For FTK25J, FTK35J, FTX25J, FTX35J

Step	Procedure	Points
2	<p>Disengage the two hooks on the upper part.</p> <p>In case that the hooks are not pressed from above, remove the front panel and then remove the grille while pushing the hook through a clearance between the front grille and the heat exchanger.</p>	<ul style="list-style-type: none">■ At the upper part there are two hooks in the left and the right.■ Disengage the hooks by pressing knobs with a screwdriver.
3	<p>The front grille can be removed in a manner to pull out the upper part forward and lift up the lower part.</p>	<ul style="list-style-type: none">■ When restoring the grille, Make sure whether each hook is set as it was.



(RR011)





For FTK25J, FTK35J, FTX25J, FTX35J




SIE-86



1.3 Removal of Horizontal Blade and Vertical Blade


Procedure



Warning Be sure to turn off all power supplies before disassembling work.




Step	Procedure	Points
1. Remove horizontal blade.		
1	Lift horizontal blade to open position.	<ul style="list-style-type: none">■ Screw stoppers inside the flap which were equipped in the existing models are not provided.
	 (RR014)	
2	Disengage horizontal blade from blade retaining section.	
	 (RR015)	
3	Bend blade slightly and remove it from the unit.	
	 (RR016)	







SIE-86

For FTK25J, FTK35J, FTX25J, FTX35J

Step	Procedure		Points
		 (RR017)	<ul style="list-style-type: none">■ For restoring.1. Since the key pattern hook is provided on the left side, insert the edge of the blade to the tip while rotating it.2. Restore the two fixed parts of the horizontal blade onto the hook.
2. Removal of vertical blade			
1	Disengage the vertical blade's joint from the fixed plate.	 (RR018)	
2	Remove the blade forward.	 (RR019)	<ul style="list-style-type: none">■ Five vertical blades are integrated with the joint rod. (so, only one blade can't be exchanged.)





For FTK25J, FTK35J, FTX25J, FTX35J




SIE-86



1.4 Removal of Switch Box, PC Board and Swing Motor


Procedure



Warning Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
■ Remove front grill.		
1. Remove switch box.		
1 Disconnect the connection wires.		
2 Disconnect connectors (S1 and S7) of fan motor.		
3 Disconnect one connector (S6) of swing motor.		■ Pay attention to the direction of the retainer of the thermister so that the retainer will not touch the harness (same as the existing models.)
4 Remove heat exchanger thermistor.		







SIE-86

For FTK25J, FTK35J, FTX25J, FTX35J


Step	Procedure	Points
5	Remove a screw on the terminal strip.	■ The switch box can be removed instead of disengaging the terminal strip.
6	Remove a screw on the switch box.	
7	Pull up the switch box forward to remove.	■ A hook is provided on the behind.




(RR023)




(RR024)






(RR025)








For FTK25J, FTK35J, FTX25J, FTX35J

SIE-86

Step	Procedure	Points
2. Removal of printed circuit board		
1	Remove the shelter.	
2	Disengage the front plate of the switch box. Disengage the knobs by pushing the two hooks at the top and the bottom.	
3	Sliding to the left, the front part of the switch box can be removed.	











SIE-86

For FTK25J, FTK35J, FTX25J, FTX35J



Step	Procedure	Points
4	Disengage the four knobs on the back of the display printed circuit board.	
5	Display printed circuit board.	







For FTK25J, FTK35J, FTX25J, FTX35J

SIE-86

Step	Procedure	Points
6	<p>Control printed circuit board.</p> 	<ul style="list-style-type: none">■ The control printed circuit board is integrated with the power supply printed circuit board.
3. Remove swing motor assembly.	<p>1 To remove swing motor assembly, remove two screws. (Manual adjusting for the vertical blades.)</p> 	<ul style="list-style-type: none">■ Provide a supporter so that the joint link will not drop off, in case the horizontal blade assembly is removed.





SIE-86





For FTK25J, FTK35J, FTX25J, FTX35J



1.5 Removal of Heat Exchanger


Procedure



Warning Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none">■ Conduct pump-down operation.■ Remove the installation frame from the mounting plate.		<p>Warning! If gas leaks, repair the leak location, then connect all refrigerant from the unit. Conduct vacuum drying, and charge proper amount of refrigerant.</p> <p>Warning! Do not mix any gas (including air) other than the specified refrigerant (R22) into refrigerating cycle. (Mixing of air or other gas causes abnormal temperature rise in refrigerating cycle, and this results in pipe rupture or personal injuries.)</p> <ul style="list-style-type: none">■ Pay attention so that the residual drain will not make a floor dirty.■ In case that a drain hose is buried inside a wall, remove it after the drain hose in the wall is pulled out.■ Use two wrenches to disconnect pipe.■ After pipes are disconnected, close all pipe openings with caps to prevent dust and moisture from entering pipes.
1	Remove the drain hose. Make curing so that the residual drain water will not leak out.	 <p>Drain hose</p> <p>(RR036)</p>
2	Disengage the insulation tube and disconnect the flare nuts for the gas line and the liquid line.	
3	Disengage the indoor unit from the installation plate.	 <p>(RR037)</p>
4	Disengage the hooks of the pipe retainer on the back.	 <p>(RR038)</p>  <p>Pipe retainer</p> <p>(RR039)</p>






For FTK25J, FTK35J, FTX25J, FTX35J

SIE-86

Step	Procedure	Points
5	<p>Pull auxiliary pipe forward to an angle of 10 to 20 degrees.</p>	<p>■ Be careful to prevent pipe deformation.</p>
6	<p>Disengage hooks located right and left side, and pull heat exchanger forward. The hooks are symmetrically placed in the right and the left.</p>	<p>■ Lifting the heat-exchanger slightly upward to the right, the left hook comes to be disengaged easily.</p>
7	<p>Lift and remove heat exchanger.</p>	<p>Caution! When removing or re-installing heat exchanger, be sure to wear protective gloves or wrap heat exchanger with cloths. (Fins can cut fingers.)</p>



SIE-86

For FTK25J, FTK35J, FTX25J, FTX35J

1.6 Install of Drain Plug





Procedure






Warning


Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
1	Disconnect drain hose.	<div>■ The drain pan is integrated with the bottom plate.</div> <div>■ Push it into the inner part firmly.</div> <div>■ Push it into the inner part firmly.</div>
2	Pull out the drain plug in the left on the drain pan by hand.	
3	Insert the drain hose,	
4	Push the drain plug into the right by Allen wrench.	



Removal Procedure





For FTK25J, FTK35J, FTX25J, FTX35J





SIE-86

1.7 Removal of Fan Rotor and Motor


Procedure



Warning Be sure to turn off all power supplies before disassembling work.




Step	Procedure	Points
■ Remove heat exchanger.		
1 To remove right side panel, remove three screws.		
2 Disengage hook.	 	







SIE-86

For FTK25J, FTK35J, FTX25J, FTX35J




Step	Procedure	Points
3	Loosen the hexagon head set screw on the fan rotor.  (RR052)	
4	Remove the motor and fan rotor.  (RR053)	
5	Remove a screw on the left side panel.  (RR054)	








For FTK25J, FTK35J, FTX25J, FTX35J

SIE-86

Step	Procedure	Points
6	<p>Disengage a hook from the backward.</p>  <p>(RR055)</p>  <p>Left-side plate</p> <p>(RR056)</p>	
7	<p>Since the fan bearing is made of rubber, push it strongly off from the inside. The bearing can be removed just as the left-side plate is attached with.</p>  <p>Bearing</p> <p>(RR057)</p>	





SIE-86

For RK25J, RK35J, RX25J, RX35J




2. For RK25J, RK35J, RX25J, RX35J

2.1 Removal of External Casing

Procedure





Warning Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
1	<p>The stop valve cover can be removed when the fixed screw is removed.</p>  	<ul style="list-style-type: none">■ As three hooks are provided(at three portions), slide the cover downward to remove.■ The forced cooling operation in the pumping down mode can be carried out by pushing the operation switch on the main unit for five seconds. (The existing models can do it through the switch on the PC board just as well.)■ The layout of the connection ports for the flares has been changed to horizontal position from vertical position.
2	<p>The top plate and the front plate are constructed in a monoblock. Remove the three screws at the right side and the two screws at the front plate.</p> 	

Removal Procedure





103






For RK25J, RK35J, RX25J, RX35J

SIE-86

Step	Procedure	Points
3	Remove the three screws at the left side. 	
4	Remove the one fixed screw in the rear of the top plate. Once lift the top plate and then remove it forward. 	<ul style="list-style-type: none">■ The left side plate and the bellmouth can be removed all at once.■ When restoring the top plate, move it horizontally and get it down for the easy work.
5	The front plate and the left side plate can be removed when the one fixed screw is removed. 	<ul style="list-style-type: none">■ Sectional view at the front. 



SIE-86

For RK25J, RK35J, RX25J, RX35J









2.2 Removal of Bellmouth and Left Side Plate

Procedure



Warning Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
1	<p>The bellmouth is attached with two screws and four hooks.</p> 	<ul style="list-style-type: none">■ Remove the bellmouth, beginning the front plate after removing the two screws which are set below.
2	<p>Remove the two screws and pull the bellmouth forward to remove, as the four hooks are provided.</p> 	<ul style="list-style-type: none">■ Slide the bellmouth in the arrow direction to disengage the hook B.
3	<p>The rib is equipped on the left side plate and it can be disengaged when the one fixed screw is removed.</p> 	



For RK25J, RK35J, RX25J, RX35J




SIE-86


2.3 Removal of PC Board and Switch Box

Procedure



Warning Be sure to turn off all power supplies before disassembling work.


Step	Procedure	Points
1. To remove the shelter.		<ul style="list-style-type: none"> ■ The shelter has five hooks.
1 Remove the one fixed screw and the four portions of hooks A and B for removing the shelter.		
2 Remove the shelter.		<ul style="list-style-type: none"> ■ Be sure to avoid forgetting to restore the shelter and to avoid losing or damaging it.
2. To remove the wire harness		
1 This shows the printed circuit board.		




SIE-86

For RK25J, RK35J, RX25J, RX35J


Step	Procedure	Points
2	Disconnect the fan motor connector (S70).	
3	Disconnect the two connectors of the reactor. Further, disengage the lead wires from the hook.	
4	Disconnect the connectors of the compressor and of the four-way valve.	



(RR071)




(RR072)






(RR073)



■ There is another reactor located on bottom frame for JV1NB model.




For RK25J, RK35J, RX25J, RX35J

SIE-86




Step	Procedure	Points
5	Disconnect the connector (S91) of the thermister. 	
6	Remove the ground wire. 	
7	Disconnect the wires from the terminal strip. 	







SIE-86

For RK25J, RK35J, RX25J, RX35J

Step	Procedure	Points
3. Remove the printed circuit board.		
1	Remove the three screws fixing the printed circuit board.	 (RR077)
2	Disconnect the wires from capacitor.	 (RR078)
3	The printed circuit board can be disengaged then.	 (RR079)



- Since the radiating fins are available underneath, remove the screw while supporting the board by hand.









For RK25J, RK35J, RX25J, RX35J

SIE-86

Step	Procedure	Points
4. To remove the switch box.		
1	Remove the three screws fixing the switch box. 	(RR080)
2	Lift and remove the switch box. 	(RR081)





SIE-86






For RK25J, RK35J, RX25J, RX35J

2.4 Removal of Propeller Fan and Fan Motor

Procedure




Warning Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
■ Disconnect the fan motor connector S70.		■ Remove the external plates and the drip proof cover protecting the electric parts. ■ Be sure to avoid forgetting to restore the shelter and to avoid loosening or damaging it.
1 The lead-wires of the fan motor can be disengaged by passing through the clearance between the heat exchanger and the switch box.	 (RR082)	 (RR084)
2 The propeller fan can be removed when the washer faced nut (M8) is removed.	 (RR083)	■ When restoring, match the ▼ mark of the propeller fan with the D-cut of the motor shaft. ■ The fan should be restored so that the mark ● will be at upper part of the fan motor.
3 Remove two screws for removing the fan motor. The lead wires are disengaged by raising the hooks which fix the lead wires.	 (RR085)	
4 Remove the fan motor.	 (RR086)	

Removal Procedure








For RK25J, RK35J, RX25J, RX35J

SIE-86


2.5 Removal of Compressor Noise Absorption Pad

Procedure

**Warning** Be sure to turn off all power supplies before disassembling work.




Step	Procedure	Points
1. To remove the right side plate.		
1	Remove the three screws for removing the right side plate.	
		
2	Lift the right side plate to disengage the hooks.	■ Insert the three hooks for the restoration.
		
2. To remove the noise absorber		
1	Untie the string fixing the body of the compressor noise absorption pad.	■ Since the slit prepared for the piping connection on the noise absorption pad is torn easily, remove the pad carefully. ■ When restoring, the noise absorption pad should pass the internal side of the piping.
		








SIE-86

For RK25J, RK35J, RX25J, RX35J

Step	Procedure	Points
2	<p>Pull out the body of the noise absorption pad.</p> 	
3	<p>Pull out the top pad of the noise absorption (a).</p> 	<ul style="list-style-type: none">■ Since the slit prepared for the piping on the noise absorption pad is torn easily, remove the pad carefully.
4	<p>Pull out the body of the noise absorption pad (b).</p> 	<ul style="list-style-type: none">■ When restoring, the noise absorption pad should pass the internal side of the piping.





For RK25J, RK35J, RX25J, RX35J




SIE-86



2.6 Removal of Partition Plate and Reactor.


Procedure



Warning Be sure to turn off all power supplies before disassembling work.



Step	Procedure	Points
1. To remove the partition plate.		
1	Disengage the lead wires from the wire clip.  (RR093)	
2	Remove the two screws fixing the partition plate.  (RR094)	
3	Pull the partition plate upward to remove.  (RR095)	








SIE-86

For RK25J, RK35J, RX25J, RX35J

Step	Procedure	Points
4	<p>When restoring the partition plate, put the hook into the bottom frame.</p> 	
2. To remove the reactor		
1	<p>The reactor can be removed by removing the fixed screw.</p> 	



For RK25J, RK35J, RX25J, RX35J

SIE-86




2.7 Removal of Four-way Valve.

Procedure






Warning

Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
1. To remove the parts around the four-way valve.		
1	<p>Remove the terminal cover, the lead wires of the compressor and the partition plate so as not to be burnt out by a gas brazing machine.</p>  <p>(RR098)</p>	
2	<p>Remove the thermister for the heat exchanger.</p>  <p>(RR099)</p>	<ul style="list-style-type: none">■ The thermister for heat exchanger is fixed by a tie-lap at one portion. Be sure to fix the thermister on the original position when restoring.
3	<p>Remove the four-way valve's coil.</p>  <p>(RR100)</p>	<ul style="list-style-type: none">■ Pay attention so as not to loose the retainer for the thermister.

SIE-86

For RK25J, RK35J, RX25J, RX35J

Step	Procedure	Points
<p>■ Begin your work after recognizing complete empty of refrigerant in the refrigerant circuit.</p>		<p>Caution Be careful about four-way valve, pipes and so on, which were heated up by a gas brazing machine, so as not to get burnt on your hands.</p> <p>Cautions at the restoration.</p> <ol style="list-style-type: none"> 1. Restore the piping by non-oxidation brazing. Braze it quickly unless nitrogen gas can be used. 2. It is required to prevent the carbonization of the oil inside the four-way valve and the deterioration of the gaskets affected by heat. For the sake of this, rap the four-way valve with wet cloth and make up water so that the cloth will not be dried and avoid excessive heating.(it keeps below 120 degree C). <p>■ Be careful so as not to break pipes by pressing the pipes excessively by a plier when withdrawing the piping.</p> <p>In case that the removal seems to be hard;</p> <ol style="list-style-type: none"> 1. Remove the piping connection part(brazing part) easy to remove and restore. 2. Cut the pipes on the main unit by a miniature copper tube cutter in order to make it easy to remove. <p>NOTE: Don't use a metal saw for cutting pipes by all means because the chips come into the circuit.</p>
4	<p>Provide a protective sheet or a steel plate so that the brazing flame can't influence the circumstance around the four-way valve.</p>  <p>(RR101)</p>	
5	<p>Heat up the four portions of brazing parts on the four-way valve. Remove the four-way valve in the order of (a),(b),(c),(d).</p>  <p>(RR102)</p>	
6	<p>Heat up the blazing parts and withdraw the pipes connected to the four-way valve by a plier and so on.</p>  <p>(RR103)</p>	

For RK25J, RK35J, RX25J, RX35J

SIE-86

2.8 Removal of Compressor

Procedure





Warning Be sure to turn off all power supplies before disassembling work.

Step	Procedure	Points
1. To Remove the Parts Around the Compressor.		<ul style="list-style-type: none"> Be careful so as not to burn the compressor terminals or the name plate.
1 Remove the terminal cover, the lead wires of the compressor and the partition plate so as not to be burnt out by a gas brazing machine. 2 The compressor's mounting nut to be removed is one piece. 3 Remove the nut by means of an open-end wrench.	 (RR104)	Let's take notes of the gist.
<ul style="list-style-type: none"> Begin your work after recognizing complete empty of refrigerant in the refrigerant circuit. Be sure to apply nitrogen's permutation when heating up the brazing part. 	 (RR105)	<p>Warning Since it may happen that refrigeration oil in the compressor will catch fire, prepare wet cloth so as to extinguish fire quickly.</p> <p>Warning! Ventilate when refrigerant leaks during the work.(If refrigerant contacts fire, it will cause to arise toxic gas).</p> <p>Caution Be careful about pipes and so on , which were heated up by a gas brazing machine, so as not to get burnt on your hands.</p>
1 Remove the brazing part on the compressor discharge side. 2 Heat up the brazing part on the compressor suction part and then remove it. 3 Lift the compressor and remove it.	 (RR106)	<ul style="list-style-type: none"> Pay attention so that the heat exchanger's fins will not be burnt.



Part 7 Others

1. Others	120
1.1 Explanation.....	120



1. Others

1.1 Explanation

1.1.1 Test Run from The Remote Controller (For Heat Pump Model Only)

Trial Operation and Testing

1. Measure the supply voltage and make sure that it falls in the specified range.
2. Trial operation should be carried out in either cooling or heating mode.

For Heat pump

In cooling mode, select the lowest programmable temperature; in heating mode, select the highest programmable temperature.

- Trial operation may be disabled in either mode depending on the room temperature.
- After trial operation is complete, set the temperature to a normal level (26°C to 28°C in cooling mode, 20°C to 24°C in heating mode).
- For protection, the system disables restart operation for 3 minutes after it is turned off.


For Cooling operation in case of low ambient temperature

Select the lowest programmable temperature.

- Trial operation in cooling mode may be disabled depending on the room temperature. Use the remote control for trial operation as described below.

Trial operation from Remote Controller

- (1) Press ON/OFF button to turn on the system.
 - (2) Simultaneously press center of TEMP button and MODE buttons.
 - (3) Press MODE button twice.
("7" will appear on the display to indicate that Trial Operation mode is selected.)
 - (4) Trial run mode terminates in approx. 15 minutes and switches into normal mode. To quit a trial operation, press ON/OFF button.
 - After trial operation is complete, set the temperature to a normal level (26°C to 28°C).
 - For protection, the machine disables restart operation for 3 minutes after it is turned off.
3. Carry out the test operation in accordance with the Operation Manual to ensure that all functions and parts, such as louver movement, are working properly.
- The air conditioner requires a small amount of power in its standby mode. If the system is not to be used for some time after installation, shut off the circuit breaker to eliminate unnecessary power consumption.
 - If the circuit breaker trips to shut off the power to the air conditioner, the system will restore the original operation mode when the circuit breaker is opened again.



(RL033)

1.1.2 Method of Operating Air Conditioners Individually (When Two Units are Installed in One Room)

For Cooling Only and Heat Pump Model


- **How to set the different addresses.**
- When two indoor units are installed in one room, the two wireless remote controllers can be set for different addresses.

PCB in the indoor unit

- Remove the front panel.
- Remove the sensor parts cover (2-screws), then remove the electric parts box (1-screw).
- Slide the metallic cover to remove it. (4-claws on the electric parts box.)
- Cut the jumper JA on PCB.

Wireless remote controller

- Cut the jumper J4.



1.1.3 Centralized Control (For KRC72, KRP413A1S)

For an explanation on usage, see the option handbook. However, do the following when using the KRP413A1S (Contact connection centralized control PC board).

Cut jumper JC on the indoor PC Bord.

(ML112)




- Note :** The power failure recovery function is controlled by the ON signal from the centralized control PC Board. The following may occur if the unit is used without cutting jumper JC.
- If the unit was running when a power failure occurred, it may not resume operation after recovering from a power failure.

1.1.4 Dry Keep Change-over Switch (All Indoor Models)


For Cooling Only and Heat Pump Model

Jumper (On indoor PC Board)	Function	When connected (factory set)	When cut
JC	Power failure recovery function	Auto start	Unit does not resume operation after recovering from a power failure. Timer ON-OFF settings are cleared.
JB	Fan speed setting when compressor is OFF on thermostat.	Fan speed setting ; Remote controller setting	Fan rpm is set to "0" <Fan stop>




1.1.5 Adjusting the Angle of the Intelligent-eye Sensor

- Once installation of the indoor unit is complete, adjust the angle of the Intelligent-eye sensor to ensure the detection area properly covers the room.
(Adjustable angle : 15° to right and left of center)



- Gently push and slide the sensor to adjust the angle. Aim so that the sensor is pointing to the center of the room, or to the part of the room that is most frequently used.






- After adjusting the angle, gently wipe the sensor with a clean cloth, being careful not to scratch the sensor.



Caution

- Do not hit or violently push the Intelligent-eye sensor. This can lead to damage and malfunction.
- Do not place large objects near the sensor. Also keep heating units or humidifiers outside the sensor's detection area.







SIE-86




Part 8

Appendix

1. Piping Diagram.....	124
1.1 Indoor Unit.....	124
1.2 Outdoor Unit.....	125
2. Wiring Diagram	127
2.1 Indoor Unit.....	127
2.2 Outdoor Unit.....	129







1. Piping Diagram

1.1 Indoor Unit

1.1.1 Cooling Only and Heat Pump




4D019960





1.2 Outdoor Unit
1.2.1 Cooling Only

RK25JV1NB



RK35JV1NB






Piping Diagram

SIE-86


1.2.2 Heat Pump

RX25JV1NB




3D019959

RX35JV1NB



3D019957




2. Wiring Diagram

2.1 Indoor Unit

2.1.1 Cooling Only

FTK25JV1NB

FTK35JV1NB



3D020027A


Wiring Diagram

SIE-86

2.1.2 Heat Pump

FTX25JV1NB

FTX35JV1NB



3D020026A


SIE-86

Wiring Diagram

2.2 Outdoor Unit

2.2.1 Cooling Only

RK25JV1NB, RK35JV1NB




Wiring Diagram


SIE-86

2.2.2 Heat Pump

RX25JV1NB, RX35JV1NB



3D012315B



Index

Symbols

*63, 64, 65, 72, 73

A

A159
A560
A661
Adjusting the Angle of the Intelligent-eye Sensor 122
Automatic Operation26

C

C4, C9, CA62
Centralized Control121
Compressor Protection Function (H / J Type)31

D

Defrost Control15
Dew Condensation Sweating Prevention Function
(H / J type)33
Discharge Pressure Check81
Dry Keep Change-over Switch121

E

E669
E874
Error Codes and Description of Fault56

F

Fan Speed Control for Indoor Units19
Fan Speed Control for Outdoor Units20
Faulty Indoor Unit PCB63, 64
Faulty Outdoor Unit PCB72
Faulty Outdoor Unit PCB
and Transmitting/Receiving Circuit73
Faulty PCB59
Forced Operation Mode16
Four-Way Valve Function Compensation
(H / J Type)30
Freeze Protection Function in Cooling.
(H / J Type)28
Frequency Principle13
Functions2
Functions of Thermistors10

G

General Functionality10
General Functions21
Good Sleep Cooling Control (J Type)25

H

H867

I

Input Current Control (H / J Type)27
Install of Drain Plug99

Installation Condition Check 80
Instruction
FTK25 / 35J, FTX25 / 35J 36
Intelligent Eye (J type) 23
Inverter Units Compressor/refrigerant
System Check 82
Inverter Units Hall IC Check 83

J

J3, J6, H9 68

L

L5 70
Location of Operation Lamp 52

M

Method of Operating Air Conditioners
Individually (When Two Units are Installed
in One Room) 121

O



Operating Modes 12
Operation Halt Due to
Compressor Startup Error 69
Operation Halt Due to Detection of CT Error 67
Operation Halt Due to
Detection of Input Over Current 74
Operation Halt Due to Detection of Thermistor
or Related Abnormality 62
Operation Halt Due to Fan Motor (AC Motor)
or Related Abnormality. 61
Operation Halt Due to Thermistor Error
or Disconnection Detection 68
Operation Shutdown Due to High-Pressure Control
or Freeze-Up Protection
(Thermistor Activation) 60
Output Overcurrent 70


P

Peak-Cut Control Function (H / J Type) 29
Power Supply Abnormalities
or Faulty Indoor Printed Circuit Boards 65
Power Supply Waveforms Check 82
Power transistor check Capacitor voltage check .. 76
Power Transistor Output Check 78
Printed Circuit Board Connector Wiring Diagram
and Name 4
Problem Symptoms and Measures 54

R

Rectifier Check 81
Removal of Air Filter 86
Removal of Bellmouth and Left Side Plate 105
Removal of Compressor 118
Removal of Compressor Noise Absorption Pad .. 112





Removal of External Casing	103
Removal of Fan Rotor and Motor	100
Removal of Four-way Valve.	116
Removal of Front Grille	88
Removal of Heat Exchanger	97
Removal of Horizontal Blade and Vertical Blade ...	90
Removal of Partition Plate and Reactor.	114
Removal of PC Board and Switch Box	106
Removal of Propeller Fan and Fan Motor	111
Removal of Switch Box, PC Board and Swing Motor	92

S

Service Check Function	55
Signal Transmission Error (Between Indoor and Outdoor Units)	66

T




Test Run from The Remote Controller (For Heat Pump Model Only)	120
Thermistor Resistance Check	79
Troubleshooting	
Indoor Units	57
Outdoor Units	58
Troubleshooting with The LED Indication	53
Troubleshooting with The Operation Lamp	52


U

U4	65, 66
----------	--------

W

Wet Operation Protection (H / J Type)	32
Wide-angle Flaps, Diffuser, Louvres and Autoswing	17





Drawings & Flow Charts

A

Adjusting the Angle of the Intelligent-eye Sensor	122
Automatic Operation	26

C

Compressor Protection Function (H / J Type)	31
---	----

D

Detection method by human motion sensor	23
Dew Condensation Sweating Prevention Function (H / J type)	33
Discharge Pressure Check	81

F

Faulty Indoor Unit PCB	63, 64
Faulty Outdoor Unit PCB	72
Faulty Outdoor Unit PCB and Transmitting/Receiving Circuit	73
Faulty PCB	59
For Cooling Only and Heat Pump Model	121
For FTK25J, FTK35J, FTX25J, FTX35J	
Install of Drain Plug	99
Removal of Air Filter	86
Removal of Fan Rotor and Motor	100
Removal of Front Grille	88
Removal of Heat Exchanger	97
Removal of Horizontal Blade and Vertical Blade	90
Removal of Switch Box, PC Board and Swing Motor	92
For RK25J, RK35J, RX25J, RX35J	
Removal of Bellmouth and Left Side Plate	105
Removal of Compressor	118
Removal of Compressor Noise Absorption Pad	112
Removal of External Casing	103
Removal of Four-way Valve.	116
Removal of Partition Plate and Reactor.	114
Removal of PC Board and Switch Box	106
Removal of Propeller Fan and Fan Motor	111
Freeze Protection Function in Cooling. (H / J Type)	28
Frequency command	21
Frequency Principle	13
FTK25/35J Series, FTX25/35J Series	
Control PCB (1)	4
P.C.B (1)	5
Functions of Thermistors	10

G

Good Sleep Cooling Control (J Type)	25
---	----

I

Input Current Control (H / J Type)	27
--	----

Installation Condition Check	80
Instruction	
FTK25 / 35J, FTX25 / 35J	36
Inverter features	14
Inverter Units Compressor/refrigerant	
System Check	82
Inverter Units Hall IC Check	83

L

Location of Operation Lamp	52
----------------------------------	----

O

Operation Halt Due to Compressor Startup Error ..	69
Operation Halt Due to Detection of CT Error	67
Operation Halt Due to Detection of Input Over Current	74
Operation Halt Due to Detection of Thermistor or Related Abnormality	62
Operation Halt Due to Fan Motor (AC Motor) or Related Abnormality.	61
Operation Halt Due to Thermistor Error or Disconnection Detection	68
Operation Shutdown Due to High-Pressure Control or Freeze-Up Protection (Thermistor Activation)	60
Outline of the action	18
Output Overcurrent	70

P

Peak-Cut Control Function (H / J Type)	29
Piping Diagram	
Indoor Unit	124
Outdoor Unit	125
Power Supply Abnormalities or Faulty Indoor Printed Circuit Boards	65
Power Supply Waveforms Check	82
Power transistor check Capacitor voltage check ..	76
Power Transistor Output Check	78
Pre-heat operation	21

R


Rectifier Check	81
RK25/35J Series, RX25/35J Series	
P.C.B (1)	7
PCB (1)	6


S

Service Check Function	55
Signal Transmission Error (Between Indoor and Outdoor Units)	66

T

The following drawing explains the fan speed control	20
The motions (for example in cooling)	23





Thermistor Resistance Check	79
Trial operation from Remote Controller	120
Troubleshooting with The LED Indication	53

W

Wet Operation Protection (H / J Type)	32
Wide-angle Flaps, Diffuser, Louvres and Autoswing	17
Wiring Diagram	
Indoor Unit	127
Outdoor Unit	129

