


Service Manual

Inverter Pair Wall Mounted Type C-Series - D-Series



Inverter Pair

C-Series

D-Series

●Cooling Only

Indoor Unit

FTKS20CVMB(9)	ATKS20DVMB	ATKS20CVMB(9)	FTN20CVMB9
FTKS25CVMB(9)(8)	ATKS25DVMB	ATKS25CVMB(9)	FTN25CVMB9
FTKS35CVMB(9)(8)	ATKS35DVMB	ATKS35CVMB(9)	FTN35CVMB9
ATKS20DAVMB			
ATKS25DAVMB			
ATKS35DAVMB			

Outdoor Unit

RKH20CVMB7	ARKH20CVMB7	ARKS20CVMB(9)	RN20CVMB7
RKH25CVMB7	ARKH25CVMB7	ARKS25CVMB(9)	RN25CVMB7
RKH35CVMB7	ARKH35CVMB7	ARKS35CVMB(9)	RN35CVMB7
ARKS20C2VMB			
ARKS25C2VMB			
ARKS35C2VMB			

●Heat Pump

Indoor Unit

FTXS20CVMB(9)	ATXS20DVMB	ATXS20CVMB(9)	FTYN20CVMB9
FTXS25CVMB(9)(8)	ATXS25DVMB	ATXS25CVMB(9)	FTYN25CVMB9
FTXS35CVMB(9)(8)	ATXS35DVMB	ATXS35CVMB(9)	FTYN35CVMB9
ATXS20DAVMB			
ATXS25DAVMB			
ATXS35DAVMB			

Outdoor Unit

RXH20CVMB7	ARXH20CVMB7	ARXS20CVMB(9)	RYN20CVMB7
RXH25CVMB7	ARXH25CVMB7	ARXS25CVMB(9)	RYN25CVMB7
RXH35CVMB7	ARXH35CVMB7	ARXS35CVMB(9)	RYN35CVMB7
ARXS20C2VMB			
ARXS25C2VMB			
ARXS35C2VMB			

1. Introduction	V
1.1 Safety Cautions	V
Part 1 List of Functions	1
1. List of Functions	2
1.1 High Grade Models	2
1.2 Standard Grade Models	4
1.3 Non-Inverter Models	7
Part 2 Specifications	9
1. Specifications	10
1.1 Cooling Only	10
1.2 Heat Pump	16
Part 3 Printed Circuit Board Connector Wiring Diagram	29
1. Printed Circuit Board Connector Wiring Diagram.....	30
1.1 Indoor Unit.....	30
1.2 Outdoor Unit / ARK(X)S-C.....	32
1.3 Outdoor Unit / RK(X)H-C, ARK(X)H-C, R(Y)N-C	34
Part 4 Function and Control.....	35
1. Main Functions.....	36
1.1 Frequency Principle.....	36
1.2 Power-Airflow Dual Flaps, Wide-Angle Louvres and Auto-Swing	38
1.3 Fan Speed Control for Indoor Units.....	39
1.4 Programme Dry Function	40
1.5 Automatic Operation.....	41
1.6 NIGHT SET Mode	42
1.7 INTELLIGENT EYE	43
1.8 HOME LEAVE Operation	45
1.9 Inverter POWERFUL Operation	46
1.10 Other Functions.....	47
2. Function of Thermistor	48
2.1 Heat Pump Model.....	48
2.2 Cooling Only Model	49
3. Control Specification	50
3.1 Mode Hierarchy	50
3.2 Frequency Control.....	51
3.3 Controls at Mode Changing / Start-up.....	53
3.4 Discharge Pipe Control	54
3.5 Input Current Control.....	55
3.6 Freeze-up Protection Control	55
3.7 Heating Peak-cut Control	56
3.8 Fan Control.....	56
3.9 Liquid Compression Protection Function 2.....	56
3.10 Defrost Control	57
3.11 Electronic Expansion Valve Control	58
3.12 Malfunctions	61
3.13 Forced Operation Mode	62

3.14 Additional Function.....	62
3.15 Facility Setting Jumper (cooling at low outdoor temperature)	63

Part 5 System Configuration..... 65

1. System Configuration.....	66
2. Instruction.....	67
2.1 Safety precautions.....	67
2.2 Names of parts	69
2.3 Preparation before Operation.....	72
2.4 AUTO · DRY · COOL · HEAT · FAN Operation	75
2.5 Adjusting the Air Flow Direction	77
2.6 POWERFUL Operation	79
2.7 OUTDOOR UNIT SILENT Operation	80
2.8 HOME LEAVE Operation	81
2.9 INTELLIGENT EYE Operation	83
2.10 TIMER Operation	85
2.11 Care and Cleaning	87
2.12 Troubleshooting.....	90

Part 6 Service Diagnosis..... 95





1. Caution for Diagnosis.....	96
2. Problem Symptoms and Measures	97
3. Service Check Function	98
4. Troubleshooting	101
4.1 Error Codes and Description	101
4.2 Indoor Unit PCB Abnormality	102
4.3 Freeze-up Protection Control or High Pressure Control.....	103
4.4 Fan Motor (AC Motor) or Related Abnormality.....	105
4.5 Thermistor or Related Abnormality (Indoor Unit).....	106
4.6 Signal Transmission Error (between Indoor and Outdoor Unit)	107
4.7 OL Activation (Compressor Overload)	108
4.8 Compressor Lock	109
4.9 DC Fan Lock	110
4.10 Input Over Current Detection	111
4.11 Four Way Valve Abnormality.....	112
4.12 Discharge Pipe Temperature Control.....	114
4.13 High Pressure Control in Cooling	115
4.14 Position Sensor Abnormality	117
4.15 DC Voltage / Current Sensor Abnormality.....	118
4.16 Thermistor or Related Abnormality (Outdoor Unit).....	119
4.17 Electrical Box Temperature Rise.....	121
4.18 Radiation Fin Temperature Rise	123
4.19 Output Over Current Detection.....	125
4.20 Insufficient Gas.....	127
4.21 Over-voltage Detection.....	129
5. Check.....	130
5.1 How to Check.....	130

Part 7 Removal Procedure	139
1. Indoor Unit.....	140
1.1 Removal of Air Filter	140
1.2 Removal of Front Grille	143
1.3 Removal of Horizontal Blade and Vertical Blade.....	146
1.4 Removal of Switch Box, PC Board and Swing Motor	148
1.5 Removal of Heat Exchanger	154
1.6 Install of Drain Plug	157
1.7 Removal of Fan Rotor and Fan Motor.....	158
2. Outdoor Unit / ARK(X)S-C	162
2.1 Removal of Panels and Fan Motor	162
2.2 Removal of Electrical Box	169
2.3 Removal of Reactor and Partition Plate	171
2.4 Removal of Sound Blanket.....	173
2.5 Removal of Four Way Valve.....	175
2.6 Removal of Compressor.....	177
2.7 Removal of PCB.....	179
3. Outdoor Unit / RK(X)H-C, ARK(X)H-C, R(Y)N-C	182
3.1 Removal of External Panels	182
3.2 Removal of Bell Mouth	185
3.3 Removal of PCB.....	186
3.4 Removal of Electrical Box	194
3.5 Removal of Propeller Fan and Fan Motor	197
3.6 Removal of Compressor Sound Insulation Pad	200
3.7 Removal of Compressor.....	209
3.8 Removal of Four Way Valve.....	212
3.9 Removal of Electronic Expansion Valve.....	215
Part 8 Others	217
1. Others	218
1.1 Test Run from the Remote Control	218
1.2 Jumper Settings	219
Part 9 Appendix.....	221
1. Piping Diagrams.....	222
1.1 Indoor Units	222
1.2 Outdoor Units	223
2. Wiring Diagrams.....	229
2.1 Indoor Units	229
2.2 Outdoor Units	230
Index	i
Drawings & Flow Charts	v







1. Introduction








1.1 Safety Cautions

Cautions and Warnings


- Be sure to read the following safety cautions before conducting repair work.
- The caution items are classified into “ **Warning**” and “ **Caution**”. The “ **Warning**” items are especially important since they can lead to death or serious injury if they are not followed closely. The “ **Caution**” items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.
- About the pictograms
 - △ This symbol indicates an item for which caution must be exercised.
The pictogram shows the item to which attention must be paid.
 - This symbol indicates a prohibited action.
The prohibited item or action is shown inside or near the symbol.
 - This symbol indicates an action that must be taken, or an instruction.
The instruction is shown inside or near the symbol.
- After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer.




1.1.1 Caution in Repair



 Warning	
Be sure to disconnect the power cable plug from the plug socket before disassembling the equipment for a repair. Working on the equipment that is connected to a power supply can cause an electrical shock. If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not touch any electrically charged sections of the equipment.	
If the refrigerant gas discharges during the repair work, do not touch the discharging refrigerant gas. The refrigerant gas can cause frostbite.	
When disconnecting the suction or discharge pipe of the compressor at the welded section, release the refrigerant gas completely at a well-ventilated place first. If there is a gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it can cause injury.	
If the refrigerant gas leaks during the repair work, ventilate the area. The refrigerant gas can generate toxic gases when it contacts flames.	
The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. Be sure to discharge the capacitor completely before conducting repair work. A charged capacitor can cause an electrical shock.	
Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug. Plugging or unplugging the power cable plug to operate the equipment can cause an electrical shock or fire.	

 Warning	
Do not repair the electrical components with wet hands. Working on the equipment with wet hands can cause an electrical shock.	
Do not clean the air conditioner by splashing water. Washing the unit with water can cause an electrical shock.	
Be sure to provide the grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.	
Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and cause injury.	
Do not tilt the unit when removing it. The water inside the unit can spill and wet the furniture and floor.	
Be sure to check that the refrigerating cycle section has cooled down sufficiently before conducting repair work. Working on the unit when the refrigerating cycle section is hot can cause burns.	
Use the welder in a well-ventilated place. Using the welder in an enclosed room can cause oxygen deficiency.	




1.1.2 Cautions Regarding Products after Repair



 Warning	
Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools can cause an electrical shock, excessive heat generation or fire.	
When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength and if the installation work is not conducted securely, the equipment can fall and cause injury.	
Be sure to install the product correctly by using the provided standard installation frame. Incorrect use of the installation frame and improper installation can cause the equipment to fall, resulting in injury.	For integral units only
Be sure to install the product securely in the installation frame mounted on a window frame. If the unit is not securely mounted, it can fall and cause injury.	For integral units only
Be sure to use an exclusive power circuit for the equipment, and follow the technical standards related to the electrical equipment, the internal wiring regulations and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work can cause an electrical shock or fire.	



 Warning	
Be sure to use the specified cable to connect between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections can cause excessive heat generation or fire.	
When connecting the cable between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section can cause an electrical shock, excessive heat generation or fire.	
Do not damage or modify the power cable. Damaged or modified power cable can cause an electrical shock or fire. Placing heavy items on the power cable, and heating or pulling the power cable can damage the cable.	
Do not mix air or gas other than the specified refrigerant (R-410A / R22) in the refrigerant system. If air enters the refrigerating system, an excessively high pressure results, causing equipment damage and injury.	
If the refrigerant gas leaks, be sure to locate the leak and repair it before charging the refrigerant. After charging refrigerant, make sure that there is no refrigerant leak. If the leak cannot be located and the repair work must be stopped, be sure to perform pump-down and close the service valve, to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it can generate toxic gases when it contacts flames, such as fan and other heaters, stoves and ranges.	
When replacing the coin battery in the remote controller, be sure to disposed of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.	

 Caution	
Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.	
Do not install the equipment in a place where there is a possibility of combustible gas leaks. If a combustible gas leaks and remains around the unit, it can cause a fire.	
Be sure to install the packing and seal on the installation frame properly. If the packing and seal are not installed properly, water can enter the room and wet the furniture and floor.	For integral units only

1.1.3 Inspection after Repair

 Warning	
Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet all the way. If the plug has dust or loose connection, it can cause an electrical shock or fire.	
If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires can cause an electrical shock, excessive heat generation or fire.	





 Warning	
Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances, since it can cause an electrical shock, excessive heat generation or fire.	

 Caution	
Check to see if the parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections can cause excessive heat generation, fire or an electrical shock.	
If the installation platform or frame has corroded, replace it. Corroded installation platform or frame can cause the unit to fall, resulting in injury.	
Check the grounding, and repair it if the equipment is not properly grounded. Improper grounding can cause an electrical shock.	
Be sure to measure the insulation resistance after the repair, and make sure that the resistance is 1 Mohm or higher. Faulty insulation can cause an electrical shock.	
Be sure to check the drainage of the indoor unit after the repair. Faulty drainage can cause the water to enter the room and wet the furniture and floor.	

1.1.4 Using Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

1.1.5 Using Icons List

Icon	Type of Information	Description
 Note:	Note	A “note” provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
 Caution	Caution	A “caution” is used when there is danger that the reader, through incorrect manipulation, may damage equipment, lose data, get an unexpected result or has to restart (part of) a procedure.
 Warning	Warning	A “warning” is used when there is danger of personal injury.
	Reference	A “reference” guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

Part 1

List of Functions

1. List of Functions	2
1.1 High Grade Models	2
1.2 Standard Grade Models	4
1.3 Non-Inverter Models	7

1. List of Functions

1.1 High Grade Models

Category	Functions	ATKS20-35DVMB ARKS20-35CVMB(9)	ATXS20-35DVMB ARXS20-35CVMB(9)	Category	Functions	ATKS20-35DVMB ARKS20-35CVMB(9)	ATXS20-35DVMB ARXS20-35CVMB(9)
Basic Function	Inverter (with Inverter Power Control)	○	○		Air Purifying Filter with Bacteriostatic, Virustatic Functions	—	—
	Operation Limit for Cooling (°CDB) ★1	-10 -46	-10 -46		Photocatalytic Deodorizing Filter	—	—
	Operation Limit for Heating (°CWB)	—	-15 -20		Air Purifying Filter with Photocatalytic Deodorizing Function	○	○
	PAM Control	○	○		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—
Compressor	Oval Scroll Compressor	—	—	Health & Clean	Mold Proof Air Filter	○	○
	Swing Compressor	○	○		Wipe-clean Flat Panel	○	○
	Rotary Compressor	—	—		Washable Grille	—	—
	Reluctance DC Motor	○	○		Mold Proof Operation	—	—
Comfortable Airflow	Power-Airflow Flap	—	—	Timer	Heating Dry Operation	—	—
	Power-Airflow Dual Flaps	○	○		Good-Sleep Cooling Operation	—	—
	Power-Airflow Diffuser	—	—		24-Hour On/Off Timer	○	○
	Wide-Angle Louvers	○	○		Night Set Mode	○	○
	Vertical Auto-Swing (Up and Down)	○	○	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○
	Horizontal Auto-Swing (Right and Left)	—	—		Self-Diagnosis (Digital, LED) Display	★2	★2
	3-D Airflow	—	—		Wiring Error Check	—	—
	Comfort Airflow Mode	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	○	○
3-Step Airflow (H/P Only)	—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	
Auto Fan Speed	○	○		Flexible Voltage Correspondence	○	○	
Indoor Unit Silent Operation	○	○		High Ceiling Application	—	—	
Night Quiet Mode (Automatic)	—	—		Chargeless	10m	10m	
Outdoor Unit Silent Operation (Manual)	○	○		Either Side Drain (Right or Left)	○	○	
Intelligent Eye	○	○		Power Selection	—	—	
Quick Warming Function	—	○		5-Rooms Centralized Controller (Option)	○	○	
Hot-Start Function	—	○		Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	○	
Automatic Defrosting	—	○	Remote Control Adapter (Normal Open Contact) (Option)	○	○		
Operation	Automatic Operation	—	○	Remote Control	DIII-NET Compatible (Adapter) (Option)	○	○
	Programme Dry Function	○	○		Infrared	○	○
	Fan Only	○	○		Wired	—	—
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—	Remote Control			
	Inverter Powerful Operation	○	○				
	Priority-Room Setting	—	—				
	Cooling / Heating Mode Lock	—	—				
	Home Leave Operation	○	○				
	ECONO Mode	—	—				
	Indoor Unit On/Off Switch	○	○				
	Signal Reception Indicator	○	○				
Temperature Display	—	—					
Another Room Operation	—	—					

Note: ○ : Holding Functions
— : No Functions

★1 : Lower limit can be extended to -15°C by cutting jumper. (facility use only)
★2 : Digital Only

Category	Functions	ATKS20-35DAVMB ARKS20-35C2VMB	ATXS20-35DAVMB ARXS20-35C2VMB	Category	Functions	ATKS20-35DAVMB ARKS20-35C2VMB	ATXS20-35DAVMB ARXS20-35C2VMB	
Basic Function	Inverter (with Inverter Power Control)	○	○	Health & Clean	Air Purifying Filter with Bacteriostatic, Virustatic Functions	—	—	
	Operation Limit for Cooling (°CDB) ★1	-10 -46	-10 -46		Photocatalytic Deodorizing Filter	—	—	
	Operation Limit for Heating (°CWB)	—	-15 -20		Air Purifying Filter with Photocatalytic Deodorizing Function	○	○	
	PAM Control	○	○		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—	
Compressor	Oval Scroll Compressor	—	—	Health & Clean	Mold Proof Air Filter	○	○	
	Swing Compressor	○	○		Wipe-clean Flat Panel	○	○	
	Rotary Compressor	—	—		Washable Grille	—	—	
	Reluctance DC Motor	○	○		Mold Proof Operation	—	—	
Comfortable Airflow	Power-Airflow Flap	—	—	Timer	Heating Dry Operation	—	—	
	Power-Airflow Dual Flaps	○	○		Good-Sleep Cooling Operation	—	—	
	Power-Airflow Diffuser	—	—		24-Hour On/Off Timer	○	○	
	Wide-Angle Louvers	○	○		Night Set Mode	○	○	
	Vertical Auto-Swing (Up and Down)	○	○	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	
	Horizontal Auto-Swing (Right and Left)	—	—		Self-Diagnosis (Digital, LED) Display	○ ★2	○ ★2	
	3-D Airflow	—	—		Wiring Error Check	—	—	
	Comfort Airflow Mode	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	○	○	
Comfort Control	3-Step Airflow (H/P Only)	—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	
	Auto Fan Speed	○	○		Flexible Voltage Correspondence	○	○	
	Indoor Unit Silent Operation	○	○		High Ceiling Application	—	—	
	Night Quiet Mode (Automatic)	—	—		Chargeless	10m	10m	
	Outdoor Unit Silent Operation (Manual)	○	○		Either Side Drain (Right or Left)	○	○	
	Intelligent Eye	○	○		Power Selection	—	—	
	Quick Warming Function	—	○		Remote Control	5-Rooms Centralized Controller (Option)	○	○
Hot-Start Function	—	○	Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○		○		
Automatic Defrosting	—	○	Remote Control Adapter (Normal Open Contact) (Option)	○		○		
Operation	Automatic Operation	—	○	Remote Control		DIII-NET Compatible (Adapter) (Option)	○	○
	Programme Dry Function	○	○		Infrared	○	○	
	Fan Only	○	○		Wired	—	—	
	Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—	Remote Control			
		Inverter Powerful Operation	○	○				
		Priority-Room Setting	—	—				
		Cooling / Heating Mode Lock	—	—				
		Home Leave Operation	○	○				
		ECONO Mode	—	—				
Indoor Unit On/Off Switch		○	○					
Signal Reception Indicator		○	○					
Temperature Display	—	—						
Another Room Operation	—	—						

Note: ○ : Holding Functions
— : No Functions

★1 : Lower limit can be extended to -15°C by cutting jumper. (facility use only)
★2 : Digital Only

1.2 Standard Grade Models

Category	Functions	FTKS20-35CVMB(9)(8) RKH20-35CVMB7		Category	Functions	FTKS20-35CVMB(9)(8) RKH25-35CVMB7		
		FTXS20-35CVMB(9)(8) RXH20-35CVMB7	FTXS20-35CVMB(9)(8) RXH20-35CVMB7			FTXS20-35CVMB(9)(8) RKH25-35CVMB7	FTXS20-35CVMB(9)(8) RXH20-35CVMB7	
Basic Function	Inverter (with Inverter Power Control)	○	○	Health & Clean	Air Purifying Filter with Bacteriostatic, Virustatic Functions	—	—	
	Operation Limit for Cooling (°CDB)	10 -46	10 -46		Photocatalytic Deodorizing Filter	—	—	
	Operation Limit for Heating (°CDB)	—	-10 -20		Air Purifying Filter with Photocatalytic Deodorizing Function	○	○	
	PAM Control	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—	
Compressor	Oval Scroll Compressor	—	—		Mold Proof Air Filter	○	○	
	Swing Compressor	—	—		Wipe-clean Flat Panel	○	○	
	Rotary Compressor	○	○		Washable Grille	—	—	
	Reluctance DC Motor	—	—		Mold Proof Operation	—	—	
Comfortable Airflow	Power-Airflow Flap	—	—		Heating Dry Operation	—	—	
	Power-Airflow Dual Flaps	○	○		Good-Sleep Cooling Operation	—	—	
	Power-Airflow Diffuser	—	—		Timer	24-Hour On/Off Timer	○	○
	Wide-Angle Louvers	○	○			Night Set Mode	○	○
	Vertical Auto-Swing (Up and Down)	○	○	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	
	Horizontal Auto-Swing (Right and Left)	—	—		Self-Diagnosis (Digital, LED) Display	○ ★1	○ ★1	
	3-D Airflow	—	—		Wiring Error Check	—	—	
	Comfort Airflow Mode	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	○	○	
Comfort Control	3-Step Airflow (H/P Only)	—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	
	Auto Fan Speed	○	○		Flexible Voltage Correspondence	○	○	
	Indoor Unit Silent Operation	○	○		High Ceiling Application	—	—	
	Night Quiet Mode (Automatic)	—	—		Chargeless	10m	10m	
	Outdoor Unit Silent Operation (Manual)	— ★2	— ★2		Either Side Drain (Right or Left)	○	○	
	Intelligent Eye	○	○		Power Selection	—	—	
	Quick Warming Function	—	○		Remote Control	5-Rooms Centralized Controller (Option)	○	○
Hot-Start Function	—	○	Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○		○		
Automatic Defrosting	—	○	Remote Control Adapter (Normal Open Contact) (Option)	○		○		
Operation	Automatic Operation	—	○	Remote Control	DIII-NET Compatible (Adapter) (Option)	○	○	
	Programme Dry Function	○	○		Infrared	○	○	
	Fan Only	○	○		Wired	—	—	
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—					
	Inverter Powerful Operation	○	○					
	Priority-Room Setting	—	—					
	Cooling / Heating Mode Lock	—	—					
	Home Leave Operation	○	○					
	ECONO Mode	—	—					
	Indoor Unit On/Off Switch	○	○					
	Signal Reception Indicator	○	○					
Temperature Display	—	—						
Another Room Operation	—	—						

Note: ○ : Holding Functions
— : No Functions

★1 : Digital Only
★2 : The button on the remote control does not work.

Category	Functions	ATKS20-35CVMB(9) ARKH20-35CVMB7	ATXS20-35CVMB(9) ARXH20-35CVMB7	Category	Functions	ATKS20-35CVMB(9) ARKH20-35CVMB7	ATXS20-35CVMB(9) ARXH20-35CVMB7	
Basic Function	Inverter (with Inverter Power Control)	○	○	Health & Clean	Air Purifying Filter with Bacteriostatic, Virustatic Functions	—	—	
	Operation Limit for Cooling (°CDB)	10 ~46	10 ~46		Photocatalytic Deodorizing Filter	—	—	
	Operation Limit for Heating (°CDB)	—	~10 ~20		Air Purifying Filter with Photocatalytic Deodorizing Function	○	○	
	PAM Control	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—	
Compressor	Oval Scroll Compressor	—	—		Mold Proof Air Filter	○	○	
	Swing Compressor	—	—		Wipe-clean Flat Panel	—	—	
	Rotary Compressor	○	○		Washable Grille	○	○	
	Reluctance DC Motor	—	—		Mold Proof Operation	—	—	
Comfortable Airflow	Power-Airflow Flap	—	—		Heating Dry Operation	—	—	
	Power-Airflow Dual Flaps	○	○		Filter Cleaning Indicator	—	—	
	Power-Airflow Diffuser	—	—	Good-Sleep Cooling Operation	—	—		
	Wide-Angle Louvers	○	○	Timer	24-Hour On/Off Timer	○	○	
	Vertical Auto-Swing (Up and Down)	○	○		Night Set Mode	○	○	
	Horizontal Auto-Swing (Right and Left)	—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	
	3-D Airflow	—	—		Self-Diagnosis (Digital, LED) Display	○ ★1	○ ★1	
	Comfort Airflow Mode	—	—		Wiring Error Check	—	—	
3-Step Airflow (H/P Only)	—	—	Anticorrosion Treatment of Outdoor Heat Exchanger		○	○		
Comfort Control	Auto Fan Speed	○	○	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	
	Indoor Unit Silent Operation	○	○		Flexible Voltage Correspondence	○	○	
	Night Quiet Mode (Automatic)	—	—		High Ceiling Application	—	—	
	Outdoor Unit Silent Operation (Manual)	★2	★2		Chargeless	10m	10m	
	Intelligent Eye	○	○		Either Side Drain (Right or Left)	○	○	
	Quick Warming Function	—	○		Power Selection	—	—	
	Hot-Start Function	—	○		Remote Control	5-Rooms Centralized Controller (Option)	○	○
	Automatic Defrosting	—	○			Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	○
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—	Remote Control Adapter (Normal Open Contact) (Option)		○	○	
	Inverter Powerful Operation	○	○	DIII-NET Compatible (Adapter) (Option)	○	○		
	Priority-Room Setting	—	—	Remote Control	Infrared	○	○	
	Cooling / Heating Mode Lock	—	—		Wired	—	—	
	Home Leave Operation	○	○					
	ECONO Mode	—	—					
	Indoor Unit On/Off Switch	○	○					
	Signal Reception Indicator	○	○					
	Temperature Display	—	—					
Another Room Operation	—	—						

Note: ○ : Holding Functions
— : No Functions

★1 : Digital Only
★2 : The button on the remote control does not work.

Category	Functions	ATKS20-35DVMB ARKH20-35CVMB7	ATXS20-35DVMB ARXH20-35CVMB7	Category	Functions	ATKS20-35DVMB ARKH20-35CVMB7	ATXS20-35DVMB ARXH20-35CVMB7	
Basic Function	Inverter (with Inverter Power Control)	○	○	Health & Clean	Air Purifying Filter with Bacteriostatic, Virustatic Functions	—	—	
	Operation Limit for Cooling (°CDB)	10 ~46	10 ~46		Photocatalytic Deodorizing Filter	—	—	
	Operation Limit for Heating (°CDB)	—	-10 ~20		Air Purifying Filter with Photocatalytic Deodorizing Function	○	○	
	PAM Control	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—	
Compressor	Oval Scroll Compressor	—	—		Mold Proof Air Filter	○	○	
	Swing Compressor	—	—		Wipe-clean Flat Panel	○	○	
	Rotary Compressor	○	○		Washable Grille	—	—	
	Reluctance DC Motor	—	—		Mold Proof Operation	—	—	
Comfortable Airflow	Power-Airflow Flap	—	—		Heating Dry Operation	—	—	
	Power-Airflow Dual Flaps	○	○		Filter Cleaning Indicator	—	—	
	Power-Airflow Diffuser	—	—		Good-Sleep Cooling Operation	—	—	
	Wide-Angle Louvers	○	○		Timer	24-Hour On/Off Timer	○	○
	Vertical Auto-Swing (Up and Down)	○	○	Night Set Mode		○	○	
	Horizontal Auto-Swing (Right and Left)	—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	
	3-D Airflow	—	—		Self-Diagnosis (Digital, LED) Display	○ ★1	○ ★1	
	Comfort Airflow Mode	—	—		Wiring Error Check	—	—	
3-Step Airflow (H/P Only)	—	—	Anticorrosion Treatment of Outdoor Heat Exchanger		○	○		
Comfort Control	Auto Fan Speed	○	○	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	
	Indoor Unit Silent Operation	○	○		Flexible Voltage Correspondence	○	○	
	Night Quiet Mode (Automatic)	—	—		High Ceiling Application	—	—	
	Outdoor Unit Silent Operation (Manual)	★2	★2		Chargeless	10m	10m	
	Intelligent Eye	○	○		Either Side Drain (Right or Left)	○	○	
	Quick Warming Function	—	○		Power Selection	—	—	
	Hot-Start Function	—	○		Remote Control	5-Rooms Centralized Controller (Option)	○	○
	Automatic Defrosting	—	○			Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	○
Operation	Automatic Operation	—	○	Remote Control Adapter (Normal Open Contact) (Option)		○	○	
	Programme Dry Function	○	○	DIII-NET Compatible (Adapter) (Option)		○	○	
	Fan Only	○	○	Remote Control	Infrared	○	○	
	New Powerful Operation (Non-Inverter)	—	—		Wired	—	—	
	Inverter Powerful Operation	○	○	Lifestyle Convenience				
	Priority-Room Setting	—	—					
	Cooling / Heating Mode Lock	—	—					
	Home Leave Operation	○	○					
ECONO Mode	—	—						
Indoor Unit On/Off Switch	○	○						
Signal Reception Indicator	○	○						
Temperature Display	—	—						
Another Room Operation	—	—						

Note: ○ : Holding Functions
— : No Functions

★1 : Digital Only
★2 : The button on the remote control does not work.

1.3 Non-Inverter Models

Category	Functions	FTN20-35CVMB9 RN20-35CVMB7	FTYN20-35CVMB9 RYN20-35CVMB7	Category	Functions	FTN20-35CVMB9 RN20-35CVMB7	FTYN20-35CVMB9 RYN20-35CVMB7	
Basic Function	Inverter (with Inverter Power Control)	—	—	Health & Clean	Air Purifying Filter with Bacteriostatic, Virustatic Functions	—	—	
	Operation Limit for Cooling (°CDB)	10 ~46	10 ~46		Photocatalytic Deodorizing Filter	—	—	
	Operation Limit for Heating (°CDB)	—	-10 ~20		Air Purifying Filter with Photocatalytic Deodorizing Function	○	○	
	PAM Control	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—	
Compressor	Oval Scroll Compressor	—	—		Mold Proof Air Filter	○	○	
	Swing Compressor	—	—		Wipe-clean Flat Panel	—	—	
	Rotary Compressor	○	○		Washable Grille	○	○	
	Reluctance DC Motor	—	—		Mold Proof Operation	—	—	
Comfortable Airflow	Power-Airflow Flap	—	—		Heating Dry Operation	—	—	
	Power-Airflow Dual Flaps	○	○		Good-Sleep Cooling Operation	—	—	
	Power-Airflow Diffuser	—	—		Timer	24-Hour On/Off Timer	○	○
	Wide-Angle Louvers	○	○			Night Set Mode	○	○
	Vertical Auto-Swing (Up and Down)	○	○	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	
	Horizontal Auto-Swing (Right and Left)	—	—		Self-Diagnosis (Digital, LED) Display	○ ★	○ ★	
	3-D Airflow	—	—		Wiring Error Check	—	—	
	Comfort Airflow Mode	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	○	○	
3-Step Airflow (H/P Only)	—	—	Flexibility		Multi-Split / Split Type Compatible Indoor Unit	—	—	
Comfort Control	Auto Fan Speed	○		○	Flexible Voltage Correspondence	○	○	
	Indoor Unit Silent Operation	—		—	High Ceiling Application	—	—	
	Night Quiet Mode (Automatic)	—		—	Chargeless	10m	10m	
	Outdoor Unit Silent Operation (Manual)	—		—	Either Side Drain (Right or Left)	○	○	
	Intelligent Eye	—		—	Power Selection	—	—	
	Quick Warming Function	—		○	Remote Control	5-Rooms Centralized Controller (Option)	○	○
	Hot-Start Function	—		○		Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	○
	Automatic Defrosting	—	○	Remote Control Adapter (Normal Open Contact) (Option)		○	○	
Operation	Automatic Operation	—	○	DIII-NET Compatible (Adapter) (Option)		—	—	
	Programme Dry Function	○	○	Remote Control	Infrared	○	○	
	Fan Only	○	○		Wired	—	—	
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	○	○					
	Inverter Powerful Operation	—	—					
	Priority-Room Setting	—	—					
	Cooling / Heating Mode Lock	—	—					
	Home Leave Operation	—	—					
	ECONO Mode	—	—					
	Indoor Unit On/Off Switch	○	○					
	Signal Reception Indicator	○	○					
	Temperature Display	—	—					
Another Room Operation	—	—						

Note: ○ : Holding Functions

— : No Functions

★ : Digital Only

Part 2

Specifications

1. Specifications	10
1.1 Cooling Only	10
1.2 Heat Pump	16

1. Specifications

1.1 Cooling Only

1.1.1 High Grade Models

50Hz 230V

Models	Indoor Units		ATKS20DVMB	ATKS25DVMB	ATKS35DVMB
	Outdoor Units		ARKS20CVMB(9)	ARKS25CVMB(9)	ARKS35CVMB(9)
Capacity Rated (Min.~Max.)	kW		2.0 (1.3~2.6)	2.5 (1.3~3.0)	3.4 (1.4~3.8)
	Btu/h		6,800 (4,450~10,250)	8,550 (4,450~10,250)	11,600 (4,750~12,950)
	kcal/h		1,720 (1,120~2,580)	2,150 (1,120~2,580)	2,920 (1,200~3,270)
Moisture Removal	L/h		0.9	1.2	1.9
Running Current (Rated)	A		2.8	3.9	4.9
Power Consumption Rated (Min.~Max.)	W		500 (300~880)	695 (300~980)	1,060 (300~1,300)
Power Factor	%		79.6	79.3	94.3
COP (Rated)	W/W		4.00	3.60	3.21
Piping Connections	Liquid	mm	φ 6.4	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5	φ 9.5
	Drain	mm	φ18.0	φ18.0	φ 18.0
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Indoor Units			ATKS20DVMB	ATKS25DVMB	ATKS35DVMB
Front Panel Color			White	White	White
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	7.7 (272)	7.7 (272)
		M	5.9 (208)	5.9 (208)	6.0 (212)
		L	4.2 (148)	4.2 (148)	4.4 (155)
		SL	3.6 (127)	3.6 (127)	3.8 (134)
Fan	Type		Cross Flow Fan	Cross Flow Fan	Cross Flow Fan
	Motor Output	W	18	18	18
	Speed	Steps	5 Steps, Silent, Auto	5 Steps, Silent, Auto	5 Steps, Silent, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof
Running Current (Rated)	A		0.18	0.18	0.18
Power Consumption (Rated)	W		40	40	40
Power Factor	%		96.6	96.6	96.6
Temperature Control			Microcomputer Control	Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)	mm		273x784x195	273x784x195	273x784x195
Packaged Dimensions (HxWxD)	mm		258x834x325	258x834x325	258x834x325
Weight	kg		7.5	7.5	7.5
Gross Weight	kg		11	11	11
Operation Sound	H/M/L/SL	dBA	38 / 32 / 25 / 22	38 / 32 / 25 / 22	39 / 33 / 26 / 23
Sound Power	H	dBA	56	56	57
Outdoor Units			ARKS20CVMB(9)	ARKS25CVMB(9)	ARKS35CVMB(9)
Casing Color			Ivory White	Ivory White	Ivory White
Compressor	Type	Hermetically Sealed Swing Type			
	Model	1YC23NXD#A			
	Motor Output	W	600	600	
Refrigerant Oil	Type	FVC50K			
	Charge	L	0.375	0.375	
Refrigerant	Type	R-410A			
	Charge	kg	0.80	0.80	
Air Flow Rate	m³/min (cfm)	H	34 (1,201)	34 (1,201)	
		L	24.8 (876)	24.8 (876)	
Fan	Type	Propeller			
	Motor Output	W	31	31	
Running Current (Rated)	A		2.62	3.72	
Power Consumption (Rated)	W		460	655	
Power Factor	%		76.3	76.6	
Starting Current	A		3.5	4.4	
Dimensions (HxWxD)	mm		550x765x285	550x765x285	
Packaged Dimensions (HxWxD)	mm		589x882x363	589x882x363	
Weight	kg		30	30	
Gross Weight	kg		35	35	
Operation Sound	H / L	dBA	46 / 43	46 / 43	
Sound Power	H	dBA	59	61	
Drawing No.			3D048480	3D048481	3D048482

- Note:**
- MAX. interunit piping length: 20m
 - MAX. interunit height difference: 15m
 - Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
 - The data are based on the conditions shown in the table below.

Cooling	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

50Hz 230V

Models	Indoor Units		ATKS20DAVMB	ATKS25DAVMB	ATKS35DAVMB
	Outdoor Units		ARKS20C2VMB	ARKS25C2VMB	ARKS35C2VMB
Capacity Rated (Min.-Max.)		kW	2.0 (1.3~2.6)	2.5 (1.3~3.0)	3.4 (1.4~3.8)
		Btu/h	6,800 (4,450~10,250)	8,550 (4,450~10,250)	11,600 (4,750~12,950)
		kcal/h	1,720 (1,120~2,580)	2,150 (1,120~2,580)	2,920 (1,200~3,270)
Moisture Removal		L/h	0.9	1.2	1.9
Running Current (Rated)		A	2.8	3.9	4.9
Power Consumption Rated (Min.-Max.)		W	500 (300~880)	695 (300~980)	1,060 (300~1,300)
Power Factor		%	79.6	79.3	94.3
COP (Rated)		W/W	4.00	3.60	3.21
Piping Connections	Liquid	mm	φ 6.4	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5	φ 9.5
	Drain	mm	φ18.0	φ18.0	φ 18.0
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Indoor Units			ATKS20DAVMB	ATKS25DAVMB	ATKS35DAVMB
Front Panel Color			White	White	White
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	7.7 (272)	7.7 (272)
		M	5.9 (208)	5.9 (208)	6.0 (212)
		L	4.2 (148)	4.2 (148)	4.4 (155)
		SL	3.6 (127)	3.6 (127)	3.8 (134)
Fan	Type		Cross Flow Fan	Cross Flow Fan	Cross Flow Fan
	Motor Output	W	18	18	18
	Speed	Steps	5 Steps, Silent, Auto	5 Steps, Silent, Auto	5 Steps, Silent, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof
Running Current (Rated)		A	0.18	0.18	0.18
Power Consumption (Rated)		W	40	40	40
Power Factor		%	96.6	96.6	96.6
Temperature Control			Microcomputer Control	Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	273x784x195	273x784x195	273x784x195
Packaged Dimensions (HxWxD)		mm	258x834x325	258x834x325	258x834x325
Weight		kg	7.5	7.5	7.5
Gross Weight		kg	11	11	11
Operation Sound	H/M/L/SL	dBA	38 / 32 / 25 / 22	38 / 32 / 25 / 22	39 / 33 / 26 / 23
Sound Power	H	dBA	56	56	57
Outdoor Units			ARKS20C2VMB	ARKS25C2VMB	ARKS35C2VMB
Casing Color			Ivory White	Ivory White	Ivory White
Compressor	Type		Hermetically Sealed Swing Type	Hermetically Sealed Swing Type	Hermetically Sealed Swing Type
	Model		1YC23NXD#A	1YC23NXD#A	1YC23NXD#A
	Motor Output	W	600	600	600
Refrigerant Oil	Type		FVC50K	FVC50K	FVC50K
	Charge	L	0.375	0.375	0.375
Refrigerant	Type		R-410A	R-410A	R-410A
	Charge	kg	0.80	0.80	1.00
Air Flow Rate	m³/min (cfm)	H	34 (1,201)	34 (1,201)	31.3 (1,105)
		L	24.8 (876)	24.8 (876)	22.4 (791)
Fan	Type		Propeller	Propeller	Propeller
	Motor Output	W	31	31	35
Running Current (Rated)		A	2.62	3.72	4.72
Power Consumption (Rated)		W	460	655	1,020
Power Factor		%	76.3	76.6	94.0
Starting Current		A	3.5	4.4	5.4
Dimensions (HxWxD)		mm	550x765x285	550x765x285	550x765x285
Packaged Dimensions (HxWxD)		mm	589x882x363	589x882x363	589x882x363
Weight		kg	30	30	32
Gross Weight		kg	35	35	38
Operation Sound	H / L	dBA	46 / 43	46 / 43	47 / 44
Sound Power	H	dBA	59	61	62
Drawing No.			3D050959	3D050961	3D050963

Note:

- MAX. interunit piping length: 20m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	7.5m

Conversion Formulae

kcal/h=kWx860
Btu/h=kWx3414
cfm=m³/minx35.3

1.1.2 Standard Grade Models

50Hz 230V

Models	Indoor Units		FTKS20CVMB(9)	FTKS25CVMB(9)(8)	FTKS35CVMB(9)(8)
	Outdoor Units		RKH20CVMB7	RKH25CVMB7	RKH35CVMB7
Capacity Rated (Min.~Max.)		kW	2.0 (1.3~2.6)	2.25 (1.3~3.0)	3.15 (1.4~3.8)
		Btu/h	6,800 (4,450~8,850)	7,650 (4,450~10,250)	10,750 (4,750~12,950)
		kcal/h	1,720 (1,120~2,240)	1,940 (1,120~2,580)	2,710 (1,200~3,270)
Moisture Removal		L/h	0.9	1.2	1.7
Running Current (Rated)		A	3.3	3.7	4.9
Power Consumption Rated (Min.~Max.)		W	620 (430~945)	700 (430~1,200)	1,045 (460~1,425)
Power Factor		%	81.7	82.3	92.7
COP (Rated)		W/W	3.23	3.21	3.01
Piping Connections	Liquid	mm	φ 6.4	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5	φ 9.5
	Drain	mm	φ18.0	φ18.0	φ 18.0
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Indoor Units			FTKS20CVMB(9)	FTKS25CVMB(9)(8)	FTKS35CVMB(9)(8)
Front Panel Color			White	White	White
Air Flow Rate	m ³ /min (cfm)	H	7.7 (272)	7.7 (272)	7.7 (272)
		M	5.9 (208)	5.9 (208)	6.0 (212)
		L	4.2 (148)	4.2 (148)	4.4 (155)
		SL	3.6 (127)	3.6 (127)	3.8 (134)
Fan	Type		Cross Flow Fan	Cross Flow Fan	Cross Flow Fan
	Motor Output	W	18	18	18
	Speed	Steps	5 Steps, Silent, Auto	5 Steps, Silent, Auto	5 Steps, Silent, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof
Running Current (Rated)		A	0.18	0.18	0.18
Power Consumption (Rated)		W	40	40	40
Power Factor		%	96.6	96.6	96.6
Temperature Control			Microcomputer Control	Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	273x784x195	273x784x195	273x784x195
Packaged Dimensions (HxWxD)		mm	258x834x325	258x834x325	258x834x325
Weight		kg	7.5	7.5	7.5
Gross Weight		kg	11	11	11
Operation Sound	H/M/L/SL	dB(A)	38 / 32 / 25 / 22	38 / 32 / 25 / 22	39 / 33 / 26 / 23
Sound Power	H	dB(A)	56	56	57
Outdoor Units			RKH20CVMB7	RKH25CVMB7	RKH35CVMB7
Casing Color			Ivory White	Ivory White	Ivory White
Compressor	Type		Hermetically Sealed Rotary Type	Hermetically Sealed Rotary Type	Hermetically Sealed Rotary Type
	Model		5RS092XDH01	5RS092XDH01	5RS092XDH01
	Motor Output	W	650	650	650
Refrigerant Oil	Type		RB68A	RB68A	RB68A
	Charge	L	0.320	0.320	0.320
Refrigerant	Type		R-410A	R-410A	R-410A
	Charge	kg	0.79	0.79	1.01
Air Flow Rate	m ³ /min (cfm)	H	29 (1,025)	29 (1,025)	27.5(972)
		L	— (—)	— (—)	— (—)
Fan	Type		Propeller	Propeller	Propeller
	Motor Output	W	25	25	25
Running Current (Rated)		A	3.12	3.52	4.72
Power Consumption (Rated)		W	580	660	1,005
Power Factor		%	80.8	81.5	92.6
Starting Current		A	3.3	3.7	4.9
Dimensions (HxWxD)		mm	560x695x265	560x695x265	560x695x265
Packaged Dimensions (HxWxD)		mm	599x824x337	599x824x337	599x824x337
Weight		kg	31	31	33
Gross Weight		kg	36	36	38
Operation Sound	H / L	dB(A)	46 / —	46 / —	48 / —
Sound Power	H	dB(A)	61	61	63
Drawing No.			3D048313	3D048314	3D048315

- Note:**
- MAX. interunit piping length: 15m
 - MAX. interunit height difference: 15m
 - Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
 - The data are based on the conditions shown in the table below.

Cooling	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m ³ /minx35.3

50Hz 230V

Models	Indoor Units		ATKS20CVMB(9)	ATKS25CVMB(9)	ATKS35CVMB(9)
	Outdoor Units		ARKH20CVMB7	ARKH25CVMB7	ARKH35CVMB7
Capacity Rated (Min.-Max.)	kW		2.0 (1.3~2.6)	2.25 (1.3~3.0)	3.15(1.4~3.8)
	Btu/h		6,800 (4,450~8,850)	7,650 (4,450~10,250)	10,750 (4,750~12,950)
	kcal/h		1,720 (1,120~2,240)	1,940 (1,120~2,580)	2,710 (1,200~3,270)
Moisture Removal	L/h		0.9	1.2	1.7
Running Current (Rated)	A		3.3	3.7	4.9
Power Consumption Rated (Min.-Max.)	W		620 (430~945)	700 (430~1200)	1,045 (460~1,425)
Power Factor	%		81.7	82.3	92.7
COP (Rated)	W/W		3.23	3.21	3.01
Piping Connections	Liquid	mm	φ 6.4	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5	φ 9.5
	Drain	mm	φ18.0	φ18.0	φ 18.0
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Indoor Units			ATKS20CVMB(9)	ATKS25CVMB(9)	ATKS35CVMB(9)
Front Panel Color			White	White	White
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	7.7 (272)	7.7 (272)
		M	5.9 (208)	5.9 (208)	6.1 (215)
		L	4.2 (148)	4.2 (148)	4.4 (155)
		SL	3.6 (127)	3.6 (127)	3.8 (134)
Fan	Type		Cross Flow Fan	Cross Flow Fan	Cross Flow Fan
	Motor Output	W	18	18	18
	Speed	Steps	5 Steps, Silent, Auto	5 Steps, Silent, Auto	5 Steps, Silent, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof
Running Current (Rated)	A		0.18	0.18	0.18
Power Consumption (Rated)	W		40	40	40
Power Factor	%		96.6	96.6	96.6
Temperature Control			Microcomputer Control	Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)	mm		273x784x185	273x784x185	273x784x185
Packaged Dimensions (HxWxD)	mm		258x834x325	258x834x325	258x834x325
Weight	kg		7.5	7.5	7.5
Gross Weight	kg		11	11	11
Operation Sound	H/M/L/SL	dBA	38 / 32 / 25 / 22	38 / 32 / 25 / 22	39 / 33 / 26 / 23
Sound Power	H	dBA	56	56	57
Outdoor Units			ARKH20CVMB7	ARKH25CVMB7	ARKH35CVMB7
Casing Color			Ivory White	Ivory White	Ivory White
Compressor	Type		Hermetically Sealed Rotary Type	Hermetically Sealed Rotary Type	Hermetically Sealed Rotary Type
	Model		5RS092XDH01	5RS092XDH01	5RS092XDH01
	Motor Output	W	650	650	650
Refrigerant Oil	Type		RB68A	RB68A	RB68A
	Charge	L	0.320	0.320	0.320
Refrigerant	Type		R-410A	R-410A	R-410A
	Charge	kg	0.79	0.79	1.01
Air Flow Rate	m³/min (cfm)	H	29 (1,025)	29 (1,025)	27.5 (972)
		L	— (—)	— (—)	— (—)
Fan	Type		Propeller	Propeller	Propeller
	Motor Output	W	25	25	25
Running Current (Rated)	A		3.12	3.52	4.72
Power Consumption (Rated)	W		580	660	1,005
Power Factor	%		80.8	81.5	92.6
Starting Current	A		3.3	3.7	4.9
Dimensions (HxWxD)	mm		560x695x265	560x695x265	560x695x265
Packaged Dimensions (HxWxD)	mm		599x824x337	599x824x337	599x824x337
Weight	kg		31	31	33
Gross Weight	kg		36	36	38
Operation Sound	H / L	dBA	46 / —	46 / —	48 / —
Sound Power	H	dBA	61	61	63
Drawing No.			3D048316	3D048317	3D048318

Note:

- MAX. interunit piping length: 15m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	7.5m

Conversion Formulae

kcal/h=kW×860
Btu/h=kW×3414
cfm=m³/min×35.3

50Hz 230V

Models	Indoor Units		ATKS20DVMB	ATKS25DVMB	ATKS35DVMB
	Outdoor Units		ARKH20CVMB7	ARKH25CVMB7	ARKH35CVMB7
Capacity Rated (Min.-Max.)	kW		2.0 (1.3~2.6)	2.25 (1.3~3.0)	3.15 (1.4~3.8)
	Btu/h		6,800 (4,450~8,850)	7,650 (4,450~10,250)	10,750 (4,750~12,950)
	kcal/h		1,720 (1,120~2,240)	1,940 (1,120~2,580)	2,710 (1,200~3,270)
Moisture Removal	L/h		0.9	1.2	1.7
Running Current (Rated)	A		3.3	3.7	4.9
Power Consumption Rated (Min.-Max.)	W		620 (430~945)	700 (430~1,200)	1,045 (460~1,425)
Power Factor	%		81.7	82.3	92.7
COP (Rated)	W/W		3.23	3.21	3.01
Piping Connections	Liquid	mm	φ 6.4	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5	φ 9.5
	Drain	mm	φ18.0	φ18.0	φ 18.0
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Indoor Units			ATKS20DVMB	ATKS25DVMB	ATKS35DVMB
Front Panel Color			White	White	White
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	7.7 (272)	7.7 (272)
		M	5.9 (208)	5.9 (208)	6.0 (212)
		L	4.2 (148)	4.2 (148)	4.4 (155)
		SL	3.6 (127)	3.6 (127)	3.8 (134)
Fan	Type		Cross Flow Fan	Cross Flow Fan	Cross Flow Fan
	Motor Output	W	18	18	18
	Speed	Steps	5 Steps, Silent, Auto	5 Steps, Silent, Auto	5 Steps, Silent, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof
Running Current (Rated)	A		0.18	0.18	0.18
Power Consumption (Rated)	W		40	40	40
Power Factor	%		96.6	96.6	96.6
Temperature Control			Microcomputer Control	Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)	mm		273x784x195	273x784x195	273x784x195
Packaged Dimensions (HxWxD)	mm		258x834x325	258x834x325	258x834x325
Weight	kg		7.5	7.5	7.5
Gross Weight	kg		11	11	11
Operation Sound	H/M/L/SL	dBA	38 / 32 / 25 / 22	38 / 32 / 25 / 22	39 / 33 / 26 / 23
Sound Power	H	dBA	56	56	57
Outdoor Units			ARKH20CVMB7	ARKH25CVMB7	ARKH35CVMB7
Casing Color			Ivory White	Ivory White	Ivory White
Compressor	Type		Hermetically Sealed Rotary Type	Hermetically Sealed Rotary Type	Hermetically Sealed Rotary Type
	Model		5RS092XDH01	5RS092XDH01	5RS092XDH01
	Motor Output	W	650	650	650
Refrigerant Oil	Type		RB68A	RB68A	RB68A
	Charge	L	0.320	0.320	0.320
Refrigerant	Type		R-410A	R-410A	R-410A
	Charge	kg	0.79	0.79	1.01
Air Flow Rate	m³/min	H	29 (1,025)	29 (1,025)	27.5 (972)
	cfm	L	—	—	—
Fan	Type		Propeller	Propeller	Propeller
	Motor Output	W	25	25	25
Running Current (Rated)	A		3.12	3.52	4.72
Power Consumption (Rated)	W		580	660	1005
Power Factor	%		80.8	81.5	92.6
Starting Current	A		3.3	3.7	4.9
Dimensions (HxWxD)	mm		560x695x265	560x695x265	560x695x265
Packaged Dimensions (HxWxD)	mm		599x824x337	599x824x337	599x824x337
Weight	kg		31	31	33
Gross Weight	kg		36	36	38
Operation Sound	H/L	dBA	46 / —	46 / —	48 / —
Sound Power	H	dBA	61	61	61
Drawing No.			3D048483A	3D048484A	3D048485A

- Note:**
- MAX. interunit piping length: 15m
 - MAX. interunit height difference: 10m
 - Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
 - The data are based on the conditions shown in the table below.

Cooling	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

1.1.3 Non-Inverter Models

50Hz 230V

Models	Indoor Units		FTN20CVMB9	FTN25CVMB9	FTN35CVMB9
	Outdoor Units		RN20CVMB7	RN25CVMB7	RN35CVMB7
Capacity Rated (Min.~Max.)		kW	2.0	2.25	3.15
		Btu/h	6,800	7,650	10,750
		kcal/h	1,720	1,940	2,710
Moisture Removal		L/h	0.9	1.2	1.7
Running Current (Rated)		A	3.3	3.7	4.9
Power Consumption Rated (Min.~Max.)		W	620	700	1,045
Power Factor		%	81.7	82.3	92.7
COP (Rated)		W/W	3.23	3.21	3.01
Piping Connections	Liquid	mm	φ 6.4	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5	φ 9.5
	Drain	mm	φ 18.0	φ 18.0	φ 18.0
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Indoor Units			FTN20CVMB9	FTN25CVMB9	FTN35CVMB9
Front Panel Color			White	White	White
Air Flow Rate	m ³ /min (cfm)	H	7.7 (272)	7.7 (272)	7.7 (272)
		M	5.9 (208)	5.9 (208)	6.1 (215)
		L	4.2 (148)	4.2 (148)	4.4 (155)
		SL	—	—	—
Fan	Type		Cross Flow Fan	Cross Flow Fan	Cross Flow Fan
	Motor Output	W	18	18	18
	Speed	Steps	5 Steps, Auto	5 Steps, Auto	5 Steps, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof	Removable / Washable / Mildew Proof
Running Current (Rated)		A	0.18	0.18	0.18
Power Consumption (Rated)		W	40	40	40
Power Factor		%	96.6	96.6	96.6
Temperature Control			Microcomputer Control	Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	273x784x185	273x784x185	273x784x185
Packaged Dimensions (HxWxD)		mm	258x834x325	258x834x325	258x834x325
Weight		kg	7.5	7.5	7.5
Gross Weight		kg	11	11	11
Operation Sound	H/M/L/SL	dB(A)	38 / 32 / 26 / —	38 / 32 / 26 / —	39 / 33 / 26 / —
Sound Power	H	dB(A)	56	56	57
Outdoor Units			RN20CVMB7	RN25CVMB7	RN35CVMB7
Casing Color			Ivory White	Ivory White	Ivory White
Compressor	Type		Hermetically Sealed Rotary Type	Hermetically Sealed Rotary Type	Hermetically Sealed Rotary Type
	Model		5RS092XDH01	5RS092XDH01	5RS092XDH01
	Motor Output	W	650	650	650
Refrigerant Oil	Type		RB68A	RB68A	RB68A
	Charge	L	0.320	0.320	0.320
Refrigerant	Type		R-410A	R-410A	R-410A
	Charge	kg	0.79	0.79	1.01
Air Flow Rate	m ³ /min (cfm)	H	29 (1,025)	29 (1,025)	27.5 (972)
		L	—	—	—
Fan	Type		Propeller	Propeller	Propeller
	Motor Output	W	25	25	25
Running Current (Rated)		A	3.12	3.52	4.72
Power Consumption (Rated)		W	580	660	1,005
Power Factor		%	80.8	81.5	92.6
Starting Current		A	3.3	3.7	4.9
Dimensions (HxWxD)		mm	560x695x265	560x695x265	560x695x265
Packaged Dimensions (HxWxD)		mm	599x824x337	599x824x337	599x824x337
Weight		kg	31	31	33
Gross Weight		kg	36	36	38
Operation Sound	H/L	dB(A)	46 / —	46 / —	48 / —
Sound Power	H	dB(A)	61	61	63
Drawing No.			3D048319	3D048320	3D048321

- Note:**
- MAX. interunit piping length: 15m
 - MAX. interunit height difference: 15m
 - Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
 - The data are based on the conditions shown in the table below.

Cooling	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	7.5m

Conversion Formulae

kcal/h=kW×860
Btu/h=kW×3414
cfm=m³/min×35.3

1.2 Heat Pump

1.2.1 High Grade Models

50Hz 230V

Models	Indoor Units		ATXS20DVMB		ATXS25DVMB	
	Outdoor Units		ARXS20CVMB(9)		ARXS25CVMB(9)	
			Cooling	Heating	Cooling	Heating
Capacity Rated (Min.-Max.)		kW	2.0 (1.3~2.6)	2.7 (1.3~4.0)	2.5 (1.3~3.0)	3.4 (1.3~4.5)
		Btu/h	6,800 (4,450~10,250)	9,200 (4,450~15,350)	8,550 (4,450~10,250)	11,600 (4,450~15,350)
		kcal/h	1,720 (1,120~2,580)	2,320 (1,120~3,870)	2,150 (1,120~2,580)	2,920 (1,120~3,870)
Moisture Removal		L/h	0.9	—	1.2	—
Running Current (Rated)		A	2.8	3.5	3.9	4.4
Power Consumption Rated (Min.-Max.)		W	500 (300~880)	675 (290~1,300)	695 (300~980)	935 (290~1,460)
Power Factor		%	79.6	82.1	79.3	93.7
COP (Rated)		W/W	4.00	4.00	3.60	3.64
Piping Connections	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ18.0		φ18.0	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Indoor Units		ATXS20DVMB		ATXS25DVMB		
Front Panel Color		White		White		
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	7.8 (275)	7.7 (272)	7.8 (275)
		M	5.9 (208)	6.5 (230)	5.9 (208)	6.5 (230)
		L	4.2 (148)	5.3 (187)	4.2 (148)	5.3 (187)
		SL	3.6 (127)	4.6 (162)	3.6 (127)	4.6 (162)
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output	W	18		18	
	Speed	Steps	5 Steps, Silent, Auto		5 Steps, Silent, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)		A	0.18	0.18	0.18	0.18
Power Consumption (Rated)		W	40	40	40	40
Power Factor		%	96.6	96.6	96.6	96.6
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	273x784x195		273x784x195	
Packaged Dimensions (HxWxD)		mm	258x834x325		258x834x325	
Weight		kg	7.5		7.5	
Gross Weight		kg	11		11	
Operation Sound	H/M/L/SL	dBA	38 / 32 / 25 / 22	38 / 33 / 28 / 25	38 / 32 / 25 / 22	38 / 33 / 28 / 25
Sound Power	H	dBA	56	56	56	56
Outdoor Units		ARXS20CVMB(9)		ARXS25CVMB(9)		
Casing Color		Ivory White		Ivory White		
Compressor	Type	Hermetically Sealed Swing Type		Hermetically Sealed Swing Type		
	Model	1YC23NXD#A		1YC23NXD#A		
	Motor Output	W	600		600	
Refrigerant Oil	Type	FVC50K		FVC50K		
	Charge	L	0.375		0.375	
Refrigerant	Type	R-410A		R-410A		
	Charge	kg	0.80		0.80	
Air Flow Rate	m³/min (cfm)	H	34 (1,201)	30.6 (1,080)	34 (1,201)	30.6 (1,080)
		L	24.8 (876)	24.7 (872)	24.8 (876)	24.7 (872)
Fan	Type	Propeller		Propeller		
	Motor Output	W	31		31	
Running Current (Rated)		A	2.62	3.32	3.72	4.22
Power Consumption (Rated)		W	460	635	655	895
Power Factor		%	76.3	83.2	76.6	92.2
Starting Current		A	3.5		4.4	
Dimensions (HxWxD)		mm	550x765x285		550x765x285	
Packaged Dimensions (HxWxD)		mm	589x882x363		589x882x363	
Weight		kg	30		30	
Gross Weight		kg	35		35	
Operation Sound	H/L	dBA	46 / 43	47 / 44	46 / 43	47 / 44
Sound Power	H	dBA	61	62	61	62
Drawing No.			3D048474		3D048475	

- Note:**
- MAX. interunit piping length: 20m
 - MAX. interunit height difference: 15m
 - Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
 - The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

50Hz 230V

Models	Indoor Units		ATXS35DVMB	
	Outdoor Units		ARXS35CVMB(9)	
			Cooling	Heating
Capacity Rated (Min.~Max.)	kW		3.4 (1.4~3.8)	4.0 (1.4~5.0)
	Btu/h		11,600 (4,750~12,950)	13,650 (4,750~17,050)
	kcal/h		2,920 (1,200~3,270)	3,440 (1,200~4,300)
Moisture Removal	L/h		1.9	—
Running Current (Rated)	A		4.9	5.4
Power Consumption Rated (Min.~Max.)	W		1,060 (300~1,300)	1,170 (310~1,590)
Power Factor	%		94.3	95.4
COP (Rated)	W/W		3.21	3.42
Piping Connections	Liquid	mm	φ 6.4	
	Gas	mm	φ 9.5	
	Drain	mm	φ18.0	
Heat Insulation	Both Liquid and Gas Pipes			
Indoor Units		ATXS35DVMB		
Front Panel Color		White		
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	8.1 (286)
		M	6.0 (212)	6.7 (237)
		L	4.4 (155)	5.3 (187)
		SL	3.8 (134)	4.6 (162)
Fan	Type	Cross Flow Fan		
	Motor Output	W		
	Speed	Steps		
Air Direction Control		Right, Left, Horizontal, Downward		
Air Filter		Removable / Washable / Mildew Proof		
Running Current (Rated)	A	0.18	0.18	
Power Consumption (Rated)	W	40	40	
Power Factor	%	96.6	96.6	
Temperature Control		Microcomputer Control		
Dimensions (HxWxD)		mm		
Packaged Dimensions (HxWxD)		mm		
Weight		kg		
Gross Weight		kg		
Operation Sound	H/M/L/SL	dBA	39 / 33 / 26 / 23	39 / 34 / 29 / 26
Sound Power	H	dBA	57	57
Outdoor Units		ARXS35CVMB(9)		
Casing Color		Ivory White		
Compressor	Type	Hermetically Sealed Swing Type		
	Model	1YC23NXD#A		
	Motor Output	W		
Refrigerant Oil	Type	FVC50K		
	Charge	L		
Refrigerant	Type	R-410A		
	Charge	kg		
Air Flow Rate	m³/min (cfm)	H	31.3 (1,105)	28.1 (992)
		L	22.4 (791)	22.4 (791)
Fan	Type	Propeller		
	Motor Output	W		
Running Current (Rated)	A	4.72	5.22	
Power Consumption (Rated)	W	1,020	1,130	
Power Factor	%	94.0	94.1	
Starting Current	A	5.4		
Dimensions (HxWxD)		mm		
Packaged Dimensions (HxWxD)		mm		
Weight		kg		
Gross Weight		kg		
Operation Sound	H/L	dBA	47 / 44	48 / 45
Sound Power	H	dBA	62	63
Drawing No.		3D048476		

Note:

- MAX. interunit piping length: 20m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae

kcal/h=kWx860
Btu/h=kWx3414
cfm=m³/minx35.3

50Hz 230V

Models	Indoor Units		ATXS20DAVMB		ATXS25DAVMB	
	Outdoor Units		ARXS20C2VMB		ARXS25C2VMB	
			Cooling	Heating	Cooling	Heating
Capacity Rated (Min.~Max.)	kW		2.0 (1.3~2.6)	2.7 (1.3~4.0)	2.5 (1.3~3.0)	3.4 (1.3~4.5)
	Btu/h		6,800 (4,450~10,250)	9,200 (4,450~15,350)	8,550 (4,450~10,250)	11,600 (4,450~15,350)
	kcal/h		1,720 (1,120~2,580)	2,320 (1,120~3,870)	2,150 (1,120~2,580)	2,920 (1,120~3,870)
Moisture Removal	L/h		0.9	—	1.2	—
Running Current (Rated)	A		2.8	3.5	3.9	4.4
Power Consumption Rated (Min.~Max.)	W		500 (300~880)	675 (290~1,300)	695 (300~980)	935 (290~1,460)
Power Factor	%		79.6	82.1	79.3	93.7
COP (Rated)	W/W		4.00	4.00	3.60	3.64
Piping Connections	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ18.0		φ18.0	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Indoor Units		ATXS20DAVMB		ATXS25DAVMB		
Front Panel Color		White		White		
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	7.8 (275)	7.7 (272)	7.8 (275)
		M	5.9 (208)	6.5 (230)	5.9 (208)	6.5 (230)
		L	4.2 (148)	5.3 (187)	4.2 (148)	5.3 (187)
		SL	3.6 (127)	4.6 (162)	3.6 (127)	4.6 (162)
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output	W	18		18	
	Speed	Steps	5 Steps, Silent, Auto		5 Steps, Silent, Auto	
Air Direction Control		Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward		
Air Filter		Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof		
Running Current (Rated)	A	0.18	0.18	0.18	0.18	
Power Consumption (Rated)	W	40	40	40	40	
Power Factor	%	96.6	96.6	96.6	96.6	
Temperature Control		Microcomputer Control		Microcomputer Control		
Dimensions (HxWxD)	mm	273x784x195		273x784x195		
Packaged Dimensions (HxWxD)	mm	258x834x325		258x834x325		
Weight	kg	7.5		7.5		
Gross Weight	kg	11		11		
Operation Sound	H/M/L/SL	dBA	38 / 32 / 25 / 22	38 / 33 / 28 / 25	38 / 32 / 25 / 22	38 / 33 / 28 / 25
Sound Power	H	dBA	56	56	56	56
Outdoor Units		ARXS20C2VMB		ARXS25C2VMB		
Casing Color		Ivory White		Ivory White		
Compressor	Type	Hermetically Sealed Swing Type		Hermetically Sealed Swing Type		
	Model	1YC23NXD#A		1YC23NXD#A		
	Motor Output	W	600	600	600	
Refrigerant Oil	Type	FVC50K		FVC50K		
	Charge	L	0.375	0.375	0.375	
Refrigerant	Type	R-410A		R-410A		
	Charge	kg	0.80	0.80	0.80	
Air Flow Rate	m³/min (cfm)	H	34 (1,201)	30.6 (1,080)	34 (1,201)	30.6 (1,080)
		L	24.8 (876)	24.7 (872)	24.8 (876)	24.7 (872)
Fan	Type	Propeller		Propeller		
	Motor Output	W	31		31	
Running Current (Rated)	A	2.62	3.32	3.72	4.22	
Power Consumption (Rated)	W	460	635	655	895	
Power Factor	%	76.3	83.2	76.6	92.2	
Starting Current	A	3.5		4.4		
Dimensions (HxWxD)	mm	550x765x285		550x765x285		
Packaged Dimensions (HxWxD)	mm	589x882x363		589x882x363		
Weight	kg	30		30		
Gross Weight	kg	35		35		
Operation Sound	H/L	dBA	46 / 43	47 / 44	46 / 43	47 / 44
Sound Power	H	dBA	61	62	61	62
Drawing No.			3D050953		3D050955	

Note:

- MAX. interunit piping length: 20m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

50Hz 230V

Models	Indoor Units		ATXS35DAVMB	
	Outdoor Units		ARXS35C2VMB	
			Cooling	Heating
Capacity Rated (Min.~Max.)		kW	3.4 (1.4~3.8)	4.0 (1.4~5.0)
		Btu/h	11,600 (4,750~12,950)	13,650 (4,750~17,050)
		kcal/h	2,920 (1,200~3,270)	3,440 (1,200~4,300)
Moisture Removal		L/h	1.9	—
Running Current (Rated)		A	4.9	5.4
Power Consumption Rated (Min.~Max.)		W	1,060 (300~1,300)	1,170 (310~1,590)
Power Factor		%	94.3	95.4
COP (Rated)		W/W	3.21	3.42
Piping Connections	Liquid	mm	φ 6.4	
	Gas	mm	φ 9.5	
	Drain	mm	φ18.0	
Heat Insulation	Both Liquid and Gas Pipes			
Indoor Units		ATXS35DAVMB		
Front Panel Color	White			
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	8.1 (286)
		M	6.0 (212)	6.7 (237)
		L	4.4 (155)	5.3 (187)
		SL	3.8 (134)	4.6 (162)
Fan	Type	Cross Flow Fan		
	Motor Output	W	18	
	Speed	Steps	5 Steps, Silent, Auto	
Air Direction Control	Right, Left, Horizontal, Downward			
Air Filter	Removable / Washable / Mildew Proof			
Running Current (Rated)		A	0.18	0.18
Power Consumption (Rated)		W	40	40
Power Factor		%	96.6	96.6
Temperature Control	Microcomputer Control			
Dimensions (HxWxD)		mm	273x784x195	
Packaged Dimensions (HxWxD)		mm	258x834x325	
Weight		kg	7.5	
Gross Weight		kg	11	
Operation Sound	H/M/L/SL	dBA	39 / 33 / 26 / 23	39 / 34 / 29 / 26
Sound Power	H	dBA	57	57
Outdoor Units		ARXS35C2VMB		
Casing Color	Ivory White			
Compressor	Type	Hermetically Sealed Swing Type		
	Model	1YC23NXD#A		
	Motor Output	W	600	
Refrigerant Oil	Type	FVC50K		
	Charge	L	0.375	
Refrigerant	Type	R-410A		
	Charge	kg	1.00	
Air Flow Rate	m³/min (cfm)	H	31.3 (1,105)	28.1 (992)
		L	22.4 (791)	22.4 (791)
Fan	Type	Propeller		
	Motor Output	W	35	
Running Current (Rated)		A	4.72	5.22
Power Consumption (Rated)		W	1,020	1,130
Power Factor		%	94.0	94.1
Starting Current		A	5.4	
Dimensions (HxWxD)		mm	550x765x285	
Packaged Dimensions (HxWxD)		mm	589x882x363	
Weight		kg	32	
Gross Weight		kg	38	
Operation Sound	H/L	dBA	47 / 44	48 / 45
Sound Power	H	dBA	62	63
Drawing No.	3D050957			

Note:

- MAX. interunit piping length: 20m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae

kcal/h=kWx860
Btu/h=kWx3414
cfm=m³/minx35.3

1.2.2 Standard Grade Models

50Hz 230V

Models	Indoor Units		FTXS20CVMB(9)		FTXS25CVMB(9)(8)		
	Outdoor Units		RXH20CVMB7		RXH25CVMB7		
			Cooling	Heating	Cooling	Heating	
Capacity Rated (Min.-Max.)	kW		2.0 (1.3-2.6)	2.6 (1.3-4.0)	2.25 (1.3-3.0)	2.85(1.3-4.5)	
	Btu/h		6,800 (4,450-8,850)	8,850 (4,450-13,650)	7,650 (4,450-10,250)	9,700 (4,450-15,350)	
	kcal/h		1,720 (1,120-2,240)	2,240 (1,120-3,440)	1,940 (1,120-2,580)	2,450 (1,120-3,870)	
Moisture Removal	L/h		0.9	—	1.2	—	
Running Current (Rated)	A		3.3	4.0	3.7	4.4	
Power Consumption Rated (Min.-Max.)	W		620 (430-945)	760 (350-1,310)	700 (430-1,200)	835 (350-1,610)	
Power Factor	%		81.7	82.6	82.3	82.5	
COP (Rated)	W/W		3.23	3.42	3.21	3.41	
Piping Connections	Liquid	mm	φ 6.4		φ 6.4		
	Gas	mm	φ 9.5		φ 9.5		
	Drain	mm	φ18.0		φ 18.0		
Heat Insulation	Both Liquid and Gas Pipes				Both Liquid and Gas Pipes		
Indoor Units	FTXS20CVMB(9)				FTXS25CVMB(9)(8)		
Front Panel Color	White				White		
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	7.8 (275)	7.7 (272)	7.8 (275)	
		M	5.9 (208)	6.5 (230)	5.9 (208)	6.5 (230)	
		L	4.2 (148)	5.3 (187)	4.2 (148)	5.3 (187)	
		SL	3.6 (127)	4.6 (162)	3.6 (127)	4.6 (162)	
Fan	Type	Cross Flow Fan				Cross Flow Fan	
	Motor Output	W	18		18		
	Speed	Steps	5 Steps, Silent, Auto		5 Steps, Silent, Auto		
Air Direction Control	Right, Left, Horizontal, Downward				Right, Left, Horizontal, Downward		
Air Filter	Removable / Washable / Mildew Proof				Removable / Washable / Mildew Proof		
Running Current (Rated)	A		0.18	0.18	0.18	0.18	
Power Consumption (Rated)	W		40	40	40	40	
Power Factor	%		96.6	96.6	96.6	96.6	
Temperature Control	Microcomputer Control				Microcomputer Control		
Dimensions (HxWxD)	mm		273x784x195		273x784x195		
Packaged Dimensions (HxWxD)	mm		258x834x325		258x834x325		
Weight	kg		7.5		7.5		
Gross Weight	kg		11		11		
Operation Sound	H/M/L/SL	dBA	38 / 32 / 25 / 22	38 / 33 / 28 / 25	38 / 32 / 25 / 22	38 / 33 / 28 / 25	
Sound Power	H	dBA	56	56	56	56	
Outdoor Units	RXH20CVMB7				RXH25CVMB7		
Casing Color	Ivory White				Ivory White		
Compressor	Type	Hermetically Sealed Rotary Type				Hermetically Sealed Rotary Type	
	Model	5RS092XDH01				5RS092XDH01	
	Motor Output	W	650		650		
Refrigerant Oil	Type	RB68A				RB68A	
	Charge	L	0.320		0.320		
Refrigerant	Type	R-410A				R-410A	
	Charge	kg	0.79		0.79		
Air Flow Rate	m³/min (cfm)	H	29 (1,025)	25.5 (901)	29 (1,025)	25.5 (901)	
		L	—	—	—	—	
Fan	Type	Propeller				Propeller	
	Motor Output	W	25		25		
Running Current (Rated)	A		3.12	3.82	3.52	4.22	
Power Consumption (Rated)	W		580	720	660	795	
Power Factor	%		80.8	81.9	81.5	81.9	
Starting Current	A		4.0		4.4		
Dimensions (HxWxD)	mm		560x695x265		560x695x265		
Packaged Dimensions (HxWxD)	mm		599x824x337		599x824x337		
Weight	kg		31		31		
Gross Weight	kg		36		36		
Operation Sound	H/L	dBA	46 / —	47 / —	46 / —	47 / —	
Sound Power	H	dBA	61	62	61	62	
Drawing No.	3D048304				3D048305		

- Note:**
- MAX. interunit piping length: 15m
 - MAX. interunit height difference: 15m
 - Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
 - The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

50Hz 230V

Models	Indoor Units		FTXS35CVMB(9)(8)	
	Outdoor Units		RXH35CVMB7	
			Cooling	Heating
Capacity Rated (Min.~Max.)	kW		3.15 (1.4~3.8)	
	Btu/h		10,750 (4,750~12,950)	
	kcal/h		2,710 (1,200~3,270)	
Moisture Removal	L/h		1.7	
Running Current (Rated)	A		4.9	
Power Consumption Rated (Min.~Max.)	W		1,045 (460~1,425)	
Power Factor	%		92.7	
COP (Rated)	W/W		3.01	
Piping Connections	Liquid	mm	φ 6.4	
	Gas	mm	φ 9.5	
	Drain	mm	φ 18.0	
Heat Insulation	Both Liquid and Gas Pipes			
Indoor Units		FTXS35CVMB(9)(8)		
Front Panel Color		White		
Air Flow Rate	m ³ /min (cfm)	H	7.7 (272)	
		M	6.0 (212)	
		L	4.4 (155)	
		SL	3.8 (134)	
Fan	Type	Cross Flow Fan		
	Motor Output	W		
	Speed	Steps		
Air Direction Control		Right, Left, Horizontal, Downward		
Air Filter		Removable / Washable / Mildew Proof		
Running Current (Rated)	A		0.18	
Power Consumption (Rated)	W		40	
Power Factor	%		96.6	
Temperature Control		Microcomputer Control		
Dimensions (HxWxD)		mm		
Packaged Dimensions (HxWxD)		mm		
Weight		kg		
Gross Weight		kg		
Operation Sound	H/M/L/SL	dBA		39 / 33 / 26 / 23
Sound Power	H	dBA		57
Outdoor Units		RXH35CVMB7		
Casing Color		Ivory White		
Compressor	Type	Hermetically Sealed Rotary Type		
	Model	5RS092XDH01		
	Motor Output	W		
Refrigerant Oil	Type	RB68A		
	Charge	L		
Refrigerant	Type	R-410A		
	Charge	kg		
Air Flow Rate	m ³ /min (cfm)	H	27.5 (972)	
		L	—	
Fan	Type	Propeller		
	Motor Output	W		
Running Current (Rated)	A		4.72	
Power Consumption (Rated)	W		1,005	
Power Factor	%		92.6	
Starting Current	A		4.9	
Dimensions (HxWxD)		mm		
Packaged Dimensions (HxWxD)		mm		
Weight		kg		
Gross Weight		kg		
Operation Sound	H/L	dBA		48 / —
Sound Power	dBA		63	
Drawing No.		3D048306		

Note:

- MAX. interunit piping length: 15m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae

kcal/h=kWx860
Btu/h=kWx3414
cfm=m³/minx35.3

50Hz 230V

Models	Indoor Units		ATXS20CVMB(9)		ATXS25CVMB(9)	
	Outdoor Units		ARXH20CVMB7		ARXH25CVMB7	
			Cooling	Heating	Cooling	Heating
Capacity Rated (Min.~Max.)	kW		2.0 (1.3~2.6)	2.6 (1.3~4.0)	2.25 (1.3~3.0)	2.85 (1.3~4.5)
	Btu/h		6,800 (4,450~8,850)	8,850 (4,450~13,650)	7,650 (4,450~10,250)	9,700 (4,450~15,350)
	kcal/h		1,720 (1,120~2,240)	2,240 (1,120~3,440)	1,940 (1,120~2,580)	2,450 (1,120~3,870)
Moisture Removal	L/h		0.9	—	1.2	—
Running Current (Rated)	A		3.3	4.0	3.7	4.4
Power Consumption Rated (Min.~Max.)	W		620 (430~945)	760 (350~1,310)	700 (430~1,200)	835 (350~1,610)
Power Factor	%		81.7	82.6	83.2	82.5
COP (Rated)	W/W		3.23	3.42	3.21	3.41
Piping Connections	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ18.0		φ18.0	
Heat Insulation	Both Liquid and Gas Pipes					Both Liquid and Gas Pipes
Indoor Units		ATXS20CVMB(9)		ATXS25CVMB(9)		
Front Panel Color		White				White
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	7.8 (275)	7.7 (272)	7.8 (275)
		M	5.9 (208)	6.5 (230)	5.9 (208)	6.5 (230)
		L	4.2 (148)	5.3 (187)	4.2 (148)	5.3 (187)
		SL	3.6 (127)	4.6 (162)	3.6 (127)	4.6 (162)
Fan	Type	Cross Flow Fan				Cross Flow Fan
	Motor Output	W	18		18	
	Speed	Steps	5 Steps, Silent, Auto		5 Steps, Silent, Auto	
Air Direction Control		Right, Left, Horizontal, Downward				Right, Left, Horizontal, Downward
Air Filter		Removable / Washable / Mildew Proof				Removable / Washable / Mildew Proof
Running Current (Rated)	A	0.18	0.18	0.18	0.18	
Power Consumption (Rated)	W	40	40	40	40	
Power Factor	%	96.6	96.6	96.6	96.6	
Temperature Control		Microcomputer Control				Microcomputer Control
Dimensions (HxWxD)	mm	273x784x185		273x784x185		
Packaged Dimensions (HxWxD)	mm	258x834x325		258x834x325		
Weight	kg	7.5		7.5		
Gross Weight	kg	11		11		
Operation Sound	H/M/L/SL	dBA	38 / 32 / 25 / 22	38 / 33 / 28 / 25	38 / 32 / 25 / 22	38 / 33 / 28 / 25
Sound Power	H	dBA	56	56	56	56
Outdoor Units		ARXH20CVMB7		ARXH25CVMB7		
Casing Color		Ivory White				Ivory White
Compressor	Type	Hermetically Sealed Rotary Type				Hermetically Sealed Rotary Type
	Model	5RS092XDH01				5RS092XDH01
	Motor Output	W	650		650	
Refrigerant Oil	Type	RB68A				RB68A
	Charge	L	0.320		0.320	
Refrigerant	Type	R-410A				R-410A
	Charge	kg	0.79		0.79	
Air Flow Rate	m³/min (cfm)	H	29 (1,025)	25.5 (901)	29 (1,025)	25.5 (901)
		L	—	—	—	—
Fan	Type	Propeller				Propeller
	Motor Output	W	25		25	
Running Current (Rated)	A	3.12	3.82	3.52	4.22	
Power Consumption (Rated)	W	580	720	660	795	
Power Factor	%	80.8	81.9	81.5	81.9	
Starting Current	A	4.0		4.4		
Dimensions (HxWxD)	mm	560x695x265		560x695x265		
Packaged Dimensions (HxWxD)	mm	599x824x337		599x824x337		
Weight	kg	31		31		
Gross Weight	kg	36		36		
Operation Sound	H/L	dBA	46 / —	47 / —	46 / —	47 / —
Sound Power	H	dBA	61	62	61	62
Drawing No.			3D048307		3D048308	

Note:

- MAX. interunit piping length: 15m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

50Hz 230V

Models	Indoor Units		ATXS35CVMB(9)	
	Outdoor Units		ARXH35CVMB7	
			Cooling	Heating
Capacity Rated (Min.~Max.)	kW		3.15 (1.4~3.8)	
	Btu/h		10,750 (4,750~12,950)	
	kcal/h		2,710 (1,200~3,270)	
Moisture Removal	L/h	1.7		
Running Current (Rated)	A	4.9		
Power Consumption Rated (Min.~Max.)	W	1,045 (460~1,425)		
Power Factor	%	92.7		
COP (Rated)	W/W	3.01		
Piping Connections	Liquid	mm	φ 6.4	
	Gas	mm	φ 9.5	
	Drain	mm	φ18.0	
Heat Insulation	Both Liquid and Gas Pipes			
Indoor Units		ATXS35CVMB(9)		
Front Panel Color		White		
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	
		M	6.1 (215)	
		L	4.4 (155)	
		SL	3.8 (134)	
Fan	Type	Cross Flow Fan		
	Motor Output	W		
	Speed	Steps		
Air Direction Control		Right, Left, Horizontal, Downward		
Air Filter		Removable / Washable / Mildew Proof		
Running Current (Rated)	A	0.18		
Power Consumption (Rated)	W	40		
Power Factor	%	96.6		
Temperature Control		Microcomputer Control		
Dimensions (HxWxD)		mm		
Packaged Dimensions (HxWxD)		mm		
Weight		kg		
Gross Weight		kg		
Operation Sound	H/M/L/SL	dBA	39 / 33 / 26 / 23	
Sound Power	H	dBA	57	
Outdoor Units		ARXH35CVMB7		
Casing Color		Ivory White		
Compressor	Type	Hermetically Sealed Rotary Type		
	Model	5RS092XDH01		
	Motor Output	W		
Refrigerant Oil	Type	RB68A		
	Charge	L		
Refrigerant	Type	R-410A		
	Charge	kg		
Air Flow Rate	m³/min (cfm)	H	27.5 (972)	
		L	—	
Fan	Type	Propeller		
	Motor Output	W		
Running Current (Rated)	A	4.72		
Power Consumption (Rated)	W	1,005		
Power Factor	%	92.6		
Starting Current	A	4.9		
Dimensions (HxWxD)		mm		
Packaged Dimensions (HxWxD)		mm		
Weight		kg		
Gross Weight		kg		
Operation Sound	H/L	dBA	48 / —	
Sound Power	H	dBA	63	
Drawing No.		3D048309		

Note:

- MAX. interunit piping length: 15m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae

kcal/h=kWx860
Btu/h=kWx3414
cfm=m³/minx35.3

50Hz 230V

Models	Indoor Units		ATXS20DVMB		ATXS25DVMB	
	Outdoor Units		ARXH20CVMB7		ARXH25CVMB7	
			Cooling	Heating	Cooling	Heating
Capacity Rated (Min.~Max.)	kW		2.0 (1.3~2.6)	2.6 (1.3~4.0)	2.25 (1.3~3.0)	2.85 (1.3~4.5)
	Btu/h		6,800 (4,450~8,850)	8,850 (4,450~13,650)	7,650 (4,450~10,250)	9,700 (4,450~15,350)
	kcal/h		1,720 (1,120~2,240)	2,240 (1,120~3,440)	1,940 (1,120~2,580)	2,450 (1,120~3,870)
Moisture Removal	L/h		0.9	—	1.2	—
Running Current (Rated)	A		3.3	4.0	3.7	4.4
Power Consumption Rated (Min.~Max.)	W		620 (430~945)	760 (350~1,310)	700 (430~1,200)	835 (350~1,610)
Power Factor	%		81.7	82.6	82.3	82.5
COP (Rated)	W/W		3.23	3.42	3.21	3.41
Piping Connections	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ18.0		φ18.0	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Indoor Units		ATXS20DVMB		ATXS25DVMB		
Front Panel Color		White		White		
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	7.8 (275)	7.7 (272)	7.8 (275)
		M	5.9 (208)	6.5 (230)	5.9 (208)	6.5 (230)
		L	4.2 (148)	5.3 (187)	4.2 (148)	5.3 (187)
		SL	3.6 (127)	4.6 (162)	3.6 (127)	4.6 (162)
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output	W	18		18	
	Speed	Steps	5 Steps, Silent, Auto		5 Steps, Silent, Auto	
Air Direction Control		Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward		
Air Filter		Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof		
Running Current (Rated)	A	0.18	0.18	0.18	0.18	
Power Consumption (Rated)	W	40	40	40	40	
Power Factor	%	96.6	96.6	96.6	96.6	
Temperature Control		Microcomputer Control		Microcomputer Control		
Dimensions (HxWxD)	mm	273x784x195		273x784x195		
Packaged Dimensions (HxWxD)	mm	258x834x325		258x834x325		
Weight	kg	7.5		7.5		
Gross Weight	kg	11		11		
Operation Sound	H/M/L/SL	dBA	38 / 32 / 25 / 22	38 / 33 / 28 / 25	38 / 32 / 25 / 22	38 / 33 / 28 / 25
Sound Power	H	dBA	56	56	56	56
Outdoor Units		ARXH20CVMB7		ARXH25CVMB7		
Casing Color		Ivory White		Ivory White		
Compressor	Type	Hermetically Sealed Rotary Type		Hermetically Sealed Rotary Type		
	Model	5RS092XDH01		5RS092XDH01		
	Motor Output	W	650		650	
Refrigerant Oil	Type	RB68A		RB68A		
	Charge	L	0.320		0.320	
Refrigerant	Type	R-410A		R-410A		
	Charge	kg	0.79		0.79	
Air Flow Rate	m³/min (cfm)	H	29 (1,025)	25.5 (901)	29 (1,025)	25.5 (901)
		L	—	—	—	—
Fan	Type	Propeller		Propeller		
	Motor Output	W	25		25	
Running Current (Rated)	A	3.12	3.82	3.52	4.22	
Power Consumption (Rated)	W	580	720	660	795	
Power Factor	%	80.8	81.9	81.5	81.9	
Starting Current	A	4.0		4.4		
Dimensions (HxWxD)	mm	560x695x265		560x695x265		
Packaged Dimensions (HxWxD)	mm	599x824x337		599x824x337		
Weight	kg	31		31		
Gross Weight	kg	36		36		
Operation Sound	H/L	dBA	46 / —	47 / —	46 / —	47 / —
Sound Power	H	dBA	61	62	61	62
Drawing No.			3D048477A		3D048478A	

- Note:**
- MAX. interunit piping length: 15m
 - MAX. interunit height difference: 10m
 - Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
 - The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

50Hz 230V

Models	Indoor Units		ATXS35DVMB	
	Outdoor Units		ARXH35CVMB7	
			Cooling	Heating
Capacity Rated (Min.~Max.)	kW		3.15 (1.4~3.8)	
	Btu/h		10,750 (4,750~12,950)	
	kcal/h		2,710 (1,200~3,270)	
Moisture Removal	L/h	1.7		
Running Current (Rated)	A	4.9		
Power Consumption Rated (Min.~Max.)	W	1,045 (460~1,425)		
Power Factor	%	92.7		
COP (Rated)	W/W	3.01		
Piping Connections	Liquid	mm	φ 6.4	
	Gas	mm	φ 9.5	
	Drain	mm	φ 18.0	
Heat Insulation	Both Liquid and Gas Pipes			
Indoor Units		ATXS35DVMB		
Front Panel Color		White		
Air Flow Rate	m ³ /min (cfm)	H	7.7 (272)	
		M	6.0 (212)	
		L	4.4 (155)	
		SL	3.8 (134)	
Fan	Type	Cross Flow Fan		
	Motor Output	W	18	
	Speed	Steps	5 Steps, Silent, Auto	
Air Direction Control		Right, Left, Horizontal, Downward		
Air Filter		Removable / Washable / Mildew Proof		
Running Current (Rated)	A	0.18		0.18
Power Consumption (Rated)	W	40		40
Power Factor	%	96.6		96.6
Temperature Control		Microcomputer Control		
Dimensions (HxWxD)		mm	273x784x195	
Packaged Dimensions (HxWxD)		mm	258x834x325	
Weight		kg	7.5	
Gross Weight		kg	11	
Operation Sound	H/M/L/SL	dBA	39 / 33 / 26 / 23	
Sound Power	H	dBA	57	
Outdoor Units		ARXH35CVMB7		
Casing Color		Ivory White		
Compressor	Type	Hermetically Sealed Rotary Type		
	Model	5RS092XDH01		
	Motor Output	W	650	
Refrigerant Oil	Type	RB68A		
	Charge	L	0.320	
Refrigerant	Type	R-410A		
	Charge	kg	1.01	
Air Flow Rate	m ³ /min (cfm)	H	27.5 (972)	
		L	—	
Fan	Type	Propeller		
	Motor Output	W	25	
Running Current (Rated)	A	4.72		4.72
Power Consumption (Rated)	W	1,005		1,015
Power Factor	%	92.6		93.5
Starting Current	A	4.9		
Dimensions (HxWxD)		mm	560x695x265	
Packaged Dimensions (HxWxD)		mm	599x824x337	
Weight		kg	33	
Gross Weight		kg	38	
Operation Sound	H/L	dBA	48 / —	
Sound Power	H	dBA	63	
Drawing No.		3D048479A		

- Note:**
- MAX. interunit piping length: 15m
 - MAX. interunit height difference: 10m
 - Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
 - The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m ³ /minx35.3

1.2.3 Non-Inverter Models

50Hz 230V

Models	Indoor Units		FTYN20CVMB9		FTYN25CVMB9	
	Outdoor Units		RYN20CVMB7		RYN25CVMB7	
			Cooling	Heating	Cooling	Heating
Capacity Rated (Min.-Max.)	kW		2.0	2.6	2.25	2.85
	Btu/h		6,800	8,850	7,650	9,700
	kcal/h		1,720	2,240	1,940	2,450
Moisture Removal	L/h		0.9	—	1.2	—
Running Current (Rated)	A		3.3	4.0	3.7	4.4
Power Consumption Rated (Min.-Max.)	W		620	760	700	835
Power Factor	%		81.7	82.6	82.3	82.5
COP (Rated)	W/W		3.23	3.42	3.21	3.41
Piping Connections	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ 18.0		φ 18.0	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Indoor Units		FTYN20CVMB9		FTYN25CVMB9		
Front Panel Color		White		White		
Air Flow Rate	m³/min (cfm)	H	7.7 (272)	7.8 (275)	7.7 (272)	7.8 (275)
		M	5.9 (208)	6.5 (230)	5.9 (208)	6.5 (230)
		L	4.2 (148)	5.3 (187)	4.2 (148)	5.3 (187)
		SL	—	—	—	—
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output	W	18		18	
	Speed	Steps	5 Steps, Auto		5 Steps, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable / Washable / Mildew Proof		Removable / Washable / Mildew Proof	
Running Current (Rated)	A		0.18	0.18	0.18	0.18
Power Consumption (Rated)	W		40	40	40	40
Power Factor	%		96.6	96.6	96.6	96.6
Temperature Control		Microcomputer Control		Microcomputer Control		
Dimensions (HxWxD)	mm	273x784x185		273x784x185		
Packaged Dimensions (HxWxD)	mm	258x834x325		258x834x325		
Weight	kg	7.5		7.5		
Gross Weight	kg	11		11		
Operation Sound	H/M/L/SL	dBA	38 / 32 / 26 / —	38 / 33 / 28 / —	38 / 32 / 26 / —	38 / 33 / 28 / —
Sound Power	H	dBA	56	56	56	56
Outdoor Units		RYN20CVMB7		RYN25CVMB7		
Casing Color		Ivory White		Ivory White		
Compressor	Type	Hermetically Sealed Rotary Type		Hermetically Sealed Rotary Type		
	Model	5RS092XDH01		5RS092XDH01		
	Motor Output	W	650		650	
Refrigerant Oil	Type	RB68A		RB68A		
	Charge	L	0.320		0.320	
Refrigerant	Type	R-410A		R-410A		
	Charge	kg	0.79		0.79	
Air Flow Rate	m³/min (cfm)	H	29 (1,025)	25.5 (901)	29 (1,025)	25.5 (901)
		L	—	—	—	—
Fan	Type	Propeller		Propeller		
	Motor Output	W	25		25	
Running Current (Rated)	A		3.12	3.82	3.52	4.22
Power Consumption (Rated)	W		580	720	660	795
Power Factor	%		80.8	81.9	81.5	81.9
Starting Current	A		4.0		4.4	
Dimensions (HxWxD)	mm	560x695x265		560x695x265		
Packaged Dimensions (HxWxD)	mm	599x824x337		599x824x337		
Weight	kg	31		31		
Gross Weight	kg	36		36		
Operation Sound	H/L	dBA	46 / —	47 / —	46 / —	47 / —
Sound Power	H	dBA	61	62	61	62
Drawing No.			3D048310		3D048311	

- Note:**
- MAX. interunit piping length: 15m
 - MAX. interunit height difference: 15m
 - Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
 - The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae
kcal/h=kWx860 Btu/h=kWx3414 cfm=m³/minx35.3

50Hz 230V

Models	Indoor Units		FTYN35CVMB9	
	Outdoor Units		RYN35CVMB7	
			Cooling	Heating
Capacity Rated (Min.~Max.)		kW	3.15	3.6
		Btu/h	10,750	12,300
		kcal/h	2,710	3,100
Moisture Removal		L/h	1.7	—
Running Current (Rated)		A	4.9	4.9
Power Consumption Rated (Min.~Max.)		W	1,045	1,055
Power Factor		%	92.7	93.6
COP (Rated)		W/W	3.01	3.41
Piping Connections	Liquid	mm	φ 6.4	
	Gas	mm	φ 9.5	
	Drain	mm	φ18.0	
Heat Insulation	Both Liquid and Gas Pipes			
Indoor Units		FTYN35CVMB9		
Front Panel Color		White		
Air Flow Rate	m ³ /min (cfm)	H	7.7 (272)	8.1 (286)
		M	6.1 (215)	6.7 (237)
		L	4.4 (155)	5.3 (187)
		SL	—	—
Fan	Type	Cross Flow Fan		
	Motor Output	W		
	Speed	Steps		
Air Direction Control		Right, Left, Horizontal, Downward		
Air Filter		Removable / Washable / Mildew Proof		
Running Current (Rated)		A	0.18	0.18
Power Consumption (Rated)		W	40	40
Power Factor		%	96.6	96.6
Temperature Control		Microcomputer Control		
Dimensions (HxWxD)		mm		
Packaged Dimensions (HxWxD)		mm		
Weight		kg		
Gross Weight		kg		
Operation Sound	H/M/L/SL	dBA	39 / 33 / 26 / —	39 / 34 / 29 / —
Sound Power	H	dBA	57	57
Outdoor Units		RYN35CVMB7		
Casing Color		Ivory White		
Compressor	Type	Hermetically Sealed Rotary Type		
	Model	5RS092XDH01		
	Motor Output	W		
Refrigerant Oil	Type	RB68A		
	Charge	L		
Refrigerant	Type	R-410A		
	Charge	kg		
Air Flow Rate	m ³ /min (cfm)	H	27.5 (972)	23.5 (830)
		L	—	—
Fan	Type	Propeller		
	Motor Output	W		
Running Current (Rated)		A	4.72	4.72
Power Consumption (Rated)		W	1,005	1,015
Power Factor		%	92.6	93.5
Starting Current		A	4.9	
Dimensions (HxWxD)		mm		
Packaged Dimensions (HxWxD)		mm		
Weight		kg		
Gross Weight		kg		
Operation Sound	H/L	dBA	48 / —	48 / —
Sound Power	H	dBA	63	63
Drawing No.		3D048312		

Note:

- MAX. interunit piping length: 15m
- MAX. interunit height difference: 15m
- Amount of additional charge of refrigerant 20g/m for piping length exceeding 10m
- The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB/24°CWB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	7.5m

Conversion Formulae

kcal/h=kWx860
Btu/h=kWx3414
cfm=m³/minx35.3

Part 3

Printed Circuit Board

Connector Wiring Diagram

1. Printed Circuit Board Connector Wiring Diagram.....	30
1.1 Indoor Unit.....	30
1.2 Outdoor Unit / ARK(X)S-C.....	32
1.3 Outdoor Unit / RK(X)H-C, ARK(X)H-C, R(Y)N-C	34

1. Printed Circuit Board Connector Wiring Diagram

1.1 Indoor Unit

Connectors

1) S1	Connector for fan motor
2) S6	Connector for swing motor (horizontal blades)
3) S7	Connector for fan motor (Hall IC)
4) S21	Connector for centralized control (HA)
5) S26	Connector for signal receiver PCB
6) S27, S36	Connector for control PCB
7) S32	Connector for heat exchanger thermistor
8) S35	Connector for INTELLIGENT EYE sensor PCB (Inverter models only)




Note: Other designations

1) V1	Varistor
2) JA	Address setting jumper
JB	Fan speed setting when compressor is OFF on thermostat
JC	Power failure recovery function (auto-restart)
	* Refer to page 219 for detail.
3) SW7	Forced operation ON / OFF switch
4) LED1	LED for operation (green)
5) LED2	LED for timer (yellow)
6) LED3	LED for HOME LEAVE operation (red) (Inverter models only)
7) LED A	LED for service monitor (green)
8) FU1	Fuse (3.15A)
9) RTH1	Room temperature thermistor

PCB Detail


PCB(1): Control PCB

PCB(2): Signal Receiver PCB



(R4011)

PCB(3): INTELLIGENT EYE sensor PCB (Inverter models only)



(R3321)

1.2 Outdoor Unit / ARK(X)S-C

Connectors

- | | |
|-----------------------|--|
| 1) S10 | Connector for filter PCB |
| 2) S11 | Connector for control PCB |
| 3) S20 | Connector for electronic expansion valve coil |
| 4) S30 | Connector for compressor motor |
| 5) S40 | Connector for overload protector |
| 6) S70 | Connector for fan motor |
| 7) S80 | Connector for four way valve coil |
| 8) S90 | Connector for thermistors
(outdoor air, heat exchanger, discharge pipe) |
| 9) HC3, HC4, HL3, HN3 | Connector for filter PCB |




Note: Other designations


- | | |
|---------------|--|
| 1) FU1, FU2 | Fuse (3.15A) |
| 2) FU3 | Fuse (20A) |
| 3) LED A | Service monitor LED |
| 4) V1, V2, V3 | Varistor |
| 5) J8 | Facility setting jumper
*Refer to page 63 for detail. |

PCB Detail

PCB(1): Control PCB (outdoor unit)



PCB(2): Filter PCB



1.3 Outdoor Unit / RK(X)H-C, ARK(X)H-C, R(Y)N-C

Connectors

- 1) S20 Connector for electronic expansion valve
- 2) S70 Connector for fan motor
- 3) S80 Connector for four way valve
- 4) S90 Connector for thermistors (outdoor air, heat exchanger, discharge pipe)




Note: Other designations

- 1) FU1 Fuse (3.15A)
- 2) FU3 Fuse (20A)
- 3) LED A Service monitor LED
- 4) V1, V2, V3 Varistor

PCB Detail

Control PCB (outdoor unit)



Part 4

Function and Control

1. Main Functions.....	36
1.1 Frequency Principle.....	36
1.2 Power-Airflow Dual Flaps, Wide-Angle Louvres and Auto-Swing	38
1.3 Fan Speed Control for Indoor Units.....	39
1.4 Programme Dry Function	40
1.5 Automatic Operation.....	41
1.6 NIGHT SET Mode	42
1.7 INTELLIGENT EYE	43
1.8 HOME LEAVE Operation	45
1.9 Inverter POWERFUL Operation	46
1.10 Other Functions.....	47
2. Function of Thermistor	48
2.1 Heat Pump Model.....	48
2.2 Cooling Only Model	49
3. Control Specification	50
3.1 Mode Hierarchy	50
3.2 Frequency Control.....	51
3.3 Controls at Mode Changing / Start-up.....	53
3.4 Discharge Pipe Control	54
3.5 Input Current Control.....	55
3.6 Freeze-up Protection Control	55
3.7 Heating Peak-cut Control	56
3.8 Fan Control.....	56
3.9 Liquid Compression Protection Function 2.....	56
3.10 Defrost Control	57
3.11 Electronic Expansion Valve Control	58
3.12 Malfunctions	61
3.13 Forced Operation Mode	62
3.14 Additional Function.....	62
3.15 Facility Setting Jumper (cooling at low outdoor temperature)	63

1. Main Functions

i Note: See the list of functions for the functions applicable to different models.

1.1 Frequency Principle

Main Control Parameters

The compressor is frequency-controlled during normal operation. The target frequency is set by the following 2 parameters coming from the operating indoor unit:

- The load condition of the operating indoor unit
- The difference between the room temperature and the set temperature

Additional Control Parameters

The target frequency is adapted by additional parameters in the following cases:

- Frequency restrictions
- Initial settings
- Forced cooling operation


Inverter Principle

To regulate the capacity, a frequency control is needed. The inverter makes it possible to vary the rotation speed of the compressor. The following table explains the conversion principle:

Phase	Description
1	The supplied AC power source is converted into the DC power source for the present.
2	The DC power source is reconverted into the three phase AC power source with variable frequency. <ul style="list-style-type: none"> ■ When the frequency increases, the rotation speed of the compressor increases resulting in an increased refrigerant circulation. This leads to a higher amount of the heat exchange per unit. ■ When the frequency decreases, the rotation speed of the compressor decreases resulting in a decreased refrigerant circulation. This leads to a lower amount of the heat exchange per unit.

Drawing of Inverter


The following drawing shows a schematic view of the inverter principle:



Inverter Features

The inverter provides the following features:

- The regulating capacity can be changed according to the changes in the outdoor air temperature and cooling / heating load.
- Quick heating and quick cooling
The compressor rotational speed is increased when starting the heating (or cooling). This enables a quick set temperature.



- Even during extreme cold weather, the high capacity is achieved. It is maintained even when the outdoor air temperature is 2°C.
- Comfortable air conditioning
A detailed adjustment is integrated to ensure a fixed room temperature. It is possible to air condition with a small room temperature variation.
- Energy saving heating and cooling
Once the set temperature is reached, the energy saving operation enables to maintain the room temperature at low power.

Frequency Limits

The following table shows the functions that define the minimum and maximum frequency:

Frequency limits	Limited during the activation of following functions
Low	<ul style="list-style-type: none"> ■ Four way valve operation compensation. Refer to page 53.
High	<ul style="list-style-type: none"> ■ Input current control. Refer to page 55. ■ Compressor protection function. Refer to page 54. ■ Heating peak-cut control. Refer to page 56. ■ Freeze-up protection control. Refer to page 55. ■ Defrost control. Refer to page 57.

Forced Cooling Operation

For more information, refer to "Forced operation mode" on page 62.

1.2 Power-Airflow Dual Flaps, Wide-Angle Louvres and Auto-Swing

Power-Airflow Dual Flaps

The large flaps send a large volume of air downwards to the floor. The flap provides an optimum control area in cooling, heating and dry mode.

Heating Mode

During heating mode, the large flap enables direct warm air straight downwards. The flap presses the warm air above the floor to reach the entire room.

Cooling Mode

During cooling mode, the flap retracts into the indoor unit. Then, cool air can be blown far and pervaded all over the room.

Wide-Angle Louvres

The louvres, made of elastic synthetic resin, provide a wide range of airflow that guarantees a comfortable air distribution.

Auto-Swing

The following table explains the auto swing process for heating, cooling, dry and fan :

Vertical Swing (up and down)		Horizontal Swing (right and left: manual)
Cooling / Dry / Fan	Heating	Heating, Cooling
<p>(R2946)</p>	<p>(R4013)</p>	<p>(R2817)</p>

1.3 Fan Speed Control for Indoor Units

Control Mode

The airflow rate can be automatically controlled depending on the difference between the set temperature and the room temperature. This is done through phase control and Hall IC control.



For more information about Hall IC, refer to trouble shooting for fan motor on page 105.

Phase Steps

Phase control and fan speed control contains 9 steps: LLL, LL, SL, L, ML, M, MH, H and HH.

Step	Cooling	Heating	Dry mode
LLL (Heating thermostat OFF)	 (R4085)	 (R4085)	25 · 35kW class : 500 - 860 rpm (During powerful operation : 850 - 910 rpm)
LL (Cooling thermostat OFF)			
SL (Silent)			
L			
ML			
M			
MH			
H			
HH (Powerful)			

= Within this range the airflow rate is automatically controlled when the FAN setting button is set to automatic.




Note:

1. During powerful operation, fan operate H tap + 50 - 90 rpm.
2. Fan stops during defrost operation.


Automatic Air Flow Control for Heating

The following drawing explains the principle for fan speed control for heating:



Automatic Air Flow Control for Cooling

The following drawing explains the principle of fan speed control for cooling:



1.4 Programme Dry Function


Programme dry function removes humidity while preventing the room temperature from lowering.

Since the microcomputer controls both the temperature and air flow volume, the temperature adjustment and fan adjustment buttons are inoperable in this mode.

In Case of Inverter Units

The microcomputer automatically sets the temperature and fan settings. The difference between the room temperature at startup and the temperature set by the microcomputer is divided into two zones. Then, the unit operates in the dry mode with an appropriate capacity for each zone to maintain the temperature and humidity at a comfortable level.

Room temperature at startup	Temperature (ON point) at which operation starts	Frequency switching point	Temperature difference for operation stop
24°C	Room temperature at startup	0.5°C	1.5°C
18°C	18°C		1.0°C
17°C		—	



LHz indicates low frequency. Item marked with varies depending on models.

(R1359)

1.5 Automatic Operation


Automatic Cooling / Heating Function (Heat Pump Only)

When the AUTO mode is selected with the remote control, the microcomputer automatically determines the operation mode from cooling and heating according to the room temperature and setting temperature at the time of the operation startup, and automatically operates in that mode.

The unit automatically switches the operation mode to cooling or heating to maintain the room temperature at the main unit setting temperature.

Detailed Explanation of the Function

1. Remote control setting temperature is set as automatic cooling / heating setting temperature (18 to 30°C).
2. Main unit setting temperature equals remote control setting temperature plus correction value (correction value / cooling: 0 deg, heating: 2 deg.).
3. Operation ON / OFF point and mode switching point are as follows.
 - ① Heating → Cooling switching point:
Room temperature \geq Main unit setting temperature +2.5 deg.
 - ② Cooling → Heating switching point:
Room temperature $<$ Main unit setting temperature -2.5 deg.
 - ③ Thermostat ON / OFF point is the same as the ON / OFF point of cooling or heating operation.
4. During initial operation
 Room temperature \geq Remote control setting temperature: Cooling operation
 Room temperature $<$ Remote control setting temperature: Heating operation



(R1360)


1.6 NIGHT SET Mode

When the OFF timer is set, the NIGHT SET circuit automatically activates. The NIGHT SET circuit maintains the airflow setting made by users.


The NIGHT SET Circuit

The NIGHT SET circuit continues heating or cooling the room at the set temperature for the first one hour, then automatically raises the temperature setting slightly in the case of cooling, or lowers it slightly in the case of heating, for economical operations. This prevents excessive heating in winter and excessive cooling in summer to ensure comfortable sleeping conditions, and also conserves electricity.

Cooling Operation



Heating Operation




1.7 INTELLIGENT EYE

This is the function that detects existence of humans in the room by a human motion sensor (INTELLIGENT EYE) and reduces the capacity when there is no human in the room in order to save electricity.


Processing

1. Detection method by Intelligent Eye



- This sensor detects human motion by receiving infrared rays and displays the pulse wave output.
- A microcomputer in an indoor unit carries out a sampling every 20 msec. and if it detects 10 cycles of the wave in one second in total (corresponding to $20\text{msec.} \times 10 = 100\text{msec.}$), it judges human is in the room as the motion signal is ON.

2. The motions (for example: in cooling)



- When a microcomputer doesn't have a signal from the sensor in 20 minutes, it judges that nobody is in the room and operates the unit in temperature sifted 2°C from the set temperature. (Cooling : 2°C higher, Dry : 1°C higher and Auto : according to the operation mode at that time.)
- ★1 In case of Fan mode, the fan speed reduces by 50 rpm.

- Since the set temperature is shifted by 2°C higher for 40 minutes, compressor speed becomes low and can realize energy saving operation. But as thermostat is prone to be off by the fact that the set temperature has been shifted, the thermostat-off action is prohibited in 40 minutes so as to prevent this phenomena.
After this 40 minutes, the prohibition of the thermostat-off is cancelled and it can realize the conditions to conduct thermostat-off depending on the room temperature. In or after this forty minutes, if the sensor detects human motion detection signal, it let the set temperature and the fan speed return to the original set point, keeping a normal operation.

Others

- The dry operation can't command the setting temperature with a remote control, but internally the set temperature is shifted by 1°C.

1.8 HOME LEAVE Operation

Outline

In order to respond to the customer's need for immediate heating and cooling of the room after returning home or for house care, a measure to switch the temperature and air volume from that for normal time over to outing time by one touch is provided. (This function responds also to the need for keeping up with weak cooling or heating.)

This time, we seek for simplicity of operation by providing the special temperature and air volume control for outing to be set by the exclusive button.

Detail of the Control

1. Start of Function

The function starts when the [HOME LEAVE] button is pressed in cooling mode or heating mode (including stopping and powerful operation). If this button is pressed while the operation is stopped, the function becomes effective when the operation is started. If this button is pressed in powerful operation, the powerful operation is reset and this function becomes effective.

- The [HOME LEAVE] button is ineffective in dry mode and fan mode.



2. Details of Function

A mark representing [HOME LEAVE] is indicated on the liquid crystal display of the remote control. The indoor unit is operated according to the set temperature and air volume for HOME LEAVE which were pre-set in the memory of the remote control.

The LED (Red) of indoor unit representing [HOME LEAVE] lights up. (It goes out when the operation is stopped.)

3. End of Function

The function ends when the [HOME LEAVE] button is pressed again during [HOME LEAVE] operation or when the powerful operation button is pressed.



Others

The set temperature and set air volume are memorized in the remote control. When the remote control is reset due to replacement of battery, it is necessary to set the temperature and air volume again for [HOME LEAVE].


1.9 Inverter POWERFUL Operation

Outline In order to exploit the cooling and heating capacity to full extent, operate the air conditioner by increasing the indoor fan rotating speed and the compressor frequency.

Details of the Control When POWERFUL button is pushed in each operation mode, the fan speed / setting temperature will be converted to the following states in a period of twenty minutes.

Operation mode	Fan speed	Target set temperature
COOL	H tap + 90 rpm	18°C
DRY	Dry rotating speed + 50 rpm	Normally targeted temperature in dry operation; Approx. -2°C
HEAT	H tap + 90 rpm	30°C
FAN	H tap + 90 rpm	—
AUTO	Same as cooling / heating in Powerful operation	The target is kept unchanged

Ex.) : Powerful operation in cooling mode.



(R4976)

1.10 Other Functions

1.10.1 Hot Start Function

Heat Pump Only

In order to prevent the cold air blast that normally comes when heating is started, the temperature of the heat exchanger of the indoor unit is detected, and either the air flow is stopped or is made very weak thereby carrying out comfortable heating of the room.

*The cold air blast is also prevented using a similar control when the defrosting operation is started or when the thermostat gets turned ON.


1.10.2 Signal Receiving Sign

When the indoor unit receives a signal from the remote control, the unit emits a signal receiving sound.

1.10.3 ON/OFF Button on Indoor Unit

An ON/OFF switch is provided on the front panel of the unit. Use this switch when the remote control is missing or if its battery has run out.

Every press of the switch changes from Operation to Stop or from Stop to Operation



- Push this button once to start operation. Push once again to stop it.
- This button is useful when the remote control is missing.
- The operation mode refers to the following table.

	Mode	Temperature setting	Air flow rate
Cooling Only	COOL	22°C	AUTO
Heat Pump	AUTO	25°C	AUTO

- In the case of multi system operation, there are times when the unit does not activate with this button.

1.10.4 Air Purifying Filter with Photocatalytic Deodorizing Function

This filter incorporates the benefits the Air Purifying Filter and Photocatalytic Deodorizing Filter in a single unit. Combining the two filters in this way increases the active surface area of the new filter. This larger surface area allows the filter to effectively trap microscopic particles, decompose odours and deactivate bacteria and viruses even for the high volume of air required to air-condition large living rooms. The filter can be used for approximately 3 years if periodic maintenance is performed.

1.10.5 Mold Proof Air Filter

The air filter net is impregnated with a safe, odourless mould preventative to make the filter virtually immune to mould.

1.10.6 Self-Diagnosis Digital Display


The microcomputer continuously monitors main operating conditions of the indoor unit, outdoor unit and the entire system. When an abnormality occur, the LCD remote control displays error code. These indications allow prompt maintenance operations.

1.10.7 Auto-restart Function

Even if a power failure (including one for just a moment) occurs during the operation, the operation restarts in the condition before power failure automatically when power is restored. (Note) It takes 3 minutes to restart the operation because the 3-minutes standby function is activated.

2. Function of Thermistor

2.1 Heat Pump Model



A Outdoor Heat Exchanger Thermistor (DCB)

1. The outdoor heat exchanger thermistor is used for controlling target discharge temperature. The system sets a target discharge temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The outdoor heat exchanger thermistor is used for detecting disconnection of the discharge thermistor when cooling. When the discharge pipe temperature becomes lower than the outdoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.
3. The outdoor heat exchanger thermistor is used for high pressure protection during cooling operation.


B Discharge Pipe Thermistor (DOT)

1. The discharge pipe thermistor is used for controlling temperature of the discharge pipe. If the temperature of discharge pipe (used in place of the inner temperature of the compressor) rises abnormally, the operating frequency drops or the operation halts.
2. The discharge pipe thermistor is used for detecting disconnection of the discharge thermistor.

C Indoor Heat Exchanger Thermistor (DCN)

1. The indoor heat exchanger thermistor is used for controlling target discharge temperature. The system sets a target discharge temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The indoor heat exchanger thermistor is used for preventing freezing. During the cooling operation, if the temperature drops abnormally, the operating frequency becomes lower, then the operation halts.
3. The indoor heat exchanger thermistor is used for anti-icing control. During the cooling operation, if the heat exchanger temperature in the room where operation is halted becomes -1°C , it is assumed as icing.
4. During heating, the indoor heat exchanger thermistor is used for detecting disconnection of the discharge pipe thermistor. When the discharge pipe temperature becomes lower than the indoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.

2.2 Cooling Only Model



A Outdoor Heat Exchanger Thermistor (DCB)

1. The outdoor heat exchanger thermistor is used for controlling target discharge temperature. The system sets a target discharge temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The outdoor heat exchanger thermistor is used for detecting disconnection of the discharge thermistor when cooling.
When the discharge pipe temperature becomes lower than the outdoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.
3. The outdoor heat exchanger thermistor is used for high pressure protection during cooling operation.

B Discharge Pipe Thermistor (DOT)

1. The discharge pipe thermistor is used for controlling temperature of the discharge pipe. If the temperature of discharge pipe (used in place of the inner temperature of the compressor) rises abnormally, the operating frequency drops or the operation halts.
2. The discharge pipe thermistor is used for detecting disconnection of the discharge thermistor.

C Indoor Heat Exchanger Thermistor (DCN)

1. The indoor heat exchanger thermistor is used for controlling target discharge temperature. The system sets a target discharge temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The indoor heat exchanger thermistor is used for preventing freezing.
During the cooling operation, if the temperature drops abnormally, the operating frequency becomes lower, then the operation halts.
3. The indoor heat exchanger thermistor is used for anti-icing control.
During the cooling operation, if the heat exchanger temperature in the room where operation is halted becomes -1°C , it is assumed as icing.

3. Control Specification

3.1 Mode Hierarchy


Outline

There are two modes; the mode selected in user's place (normal air conditioning mode) and forced operation mode for installation and providing service.

Detail

1. For heat pump model


There are following modes; stop, cooling (includes drying), heating (include defrosting)



(R2829)

2. For cooling only model

There are following models; stop and cooling (including drying).



(R2830)




Note: Unless specified otherwise, an indoor dry operation command must be regarded as cooling operation.

3.2 Frequency Control

Outline

Frequency will be determined according to the difference between room and set temperature. The function is explained as follows.

1. How to determine frequency.
2. Frequency command from an indoor unit. (The difference between a room temperature and the temperature set by the remote control.)
3. Frequency command from an indoor unit.
4. Frequency initial setting.
5. PI control.



(R2831)

Detail

How to Determine Frequency

The compressor's frequency will finally be determined by taking the following steps.

For Heat Pump Model

1. Determine command frequency

- ◆ Command frequency will be determined in the following order of priority.
 - 1.1 Limiting frequency by drooping function
 - ◆ Input current, discharge pipes, peak cutting, freeze-up protection, dew prevention, fin thermistor temperature.
 - 1.2 Limiting defrost control time
 - 1.3 Forced cooling
 - 1.4 Indoor frequency command

2. Determine upper limit frequency

- ◆ Set a minimum value as an upper limit frequency among the frequency upper limits of the following functions:
Compressor protection, input current, discharge pipes, peak cutting, freeze-up protection, defrost.

3. Determine lower limit frequency

- ◆ Set a maximum value as a lower limit frequency among the frequency lower limits of the following functions:
Four way valve operating compensation, draft prevention, pressure difference upkeep.

4. Determine prohibited frequency

- ◆ There is a certain prohibited frequency such as a power supply frequency.

For Cooling Only Model

1. Determine command frequency

- ◆ Command frequency will be determined in the following order of priority.
 - 1.1 Limiting frequency by drooping function
Input current, discharge pipes, freeze-up protection, dew prevention, fin thermistor temperature.
 - 1.2 Indoor frequency command

2. Determine upper limit frequency

- ◆ Set a minimum value as an upper limit frequency among the frequency upper limits of the following functions:
Compressor protection, input current, discharge pipes, freeze-up protection, dew prevention, fin thermistor temperature.

3. Determine lower limit frequency

- ◆ Set a maximum value as an lower limit frequency among the frequency lower limits of the following functions:
Pressure difference upkeep.

4. Determine prohibited frequency

- ◆ There is a certain prohibited frequency such as a power supply frequency.

Indoor Frequency Command (ΔD signal)

The difference between a room temperature and the temperature set by the remote control will be taken as the " ΔD signal" and is used for frequency command.

Temperature difference	ΔD signal	Temperature difference	ΔD signal	Temperature difference	ΔD signal	Temperature difference	ΔD signal
0	*Th OFF	2.0	4	4.0	8	6.0	C
0.5	1	2.5	5	4.5	9	6.5	D
1.0	2	3.0	6	5.0	A	7.0	E
1.5	3	3.5	7	5.5	B	7.5	F

*Th OFF = Thermostat OFF

Frequency Initial Setting**<Outline>**

When starting the compressor, or when conditions are varied due to the change of the room, the frequency must be initialized according to the ΔD value of the indoor unit and the Q value of the indoor unit.

Q value: Indoor unit output determined from indoor unit volume, air flow rate and other factors.

PI Control (Determine Frequency Up / Down by ΔD Signal)**1. P control**

Calculate ΔD value in each sampling time (20 seconds), and adjust the frequency according to its difference from the frequency previously calculated.

2. I control

If the operating frequency is not change more than a certain fixed time, adjust the frequency up and down according to the ΔD value, obtaining the fixed ΔD value.

When the ΔD value is small...lower the frequency.

When the ΔD value is large...increase the frequency.

3. Frequency management when other controls are functioning

- ◆ When frequency is drooping;
Frequency management is carried out only when the frequency droops.
- ◆ For limiting lower limit
Frequency management is carried out only when the frequency rises.

4. Upper and lower limit of frequency by PI control

5. The frequency upper and lower limits are set depending on indoor unit.

When low noise commands come from the indoor unit or when outdoor unit low noise or quiet commands come from indoor unit, the upper limit frequency must be lowered than the usual setting.

3.3 Controls at Mode Changing / Start-up

3.3.1 Preheating Operation

Outline	Operate the inverter in the open phase operation with the conditions including the preheating command from the discharge pipe temperature.
----------------	--

Detail	<p>Preheating ON Condition</p> <ul style="list-style-type: none"> ◆ When the discharge pipe temperature is below 10°C, inverter in open phase operation starts. <p>OFF Condition</p> <ul style="list-style-type: none"> ◆ When the discharge pipe temperature is higher than 12°C, inverter in open phase operation stops.
---------------	--

3.3.2 Four Way Valve Switching

Outline of Heating Operation	<p>Heat Pump Only</p> <p>During the heating operation current must be conducted and during cooling and defrosting current must not be conducted. In order to eliminate the switching sound (as the four way valve coil switches from ON to OFF) when the heating is stopped, the delay switch of the four way valve must be carried out after the operation stopped.</p>
-------------------------------------	---

Detail	<p>The OFF delay of four way valve</p> <p>Energize the coil for 160 sec after unit operation is stopped.</p>
---------------	--

3.3.3 Four Way Valve Operation Compensation

Outline	<p>Heat Pump Only</p> <p>At the beginning of the operation as the four way valve is switched, acquire the differential pressure required for activating the four way valve by having output the operating frequency, which is more than a certain fixed frequency, for a certain fixed time.</p>
----------------	---

Detail	<p>Starting Conditions</p> <ol style="list-style-type: none"> 1. When starting compressor for heating. 2. When the operating mode changes to cooling from heating. 3. When starting compressor for rushing defrosting or resetting. 4. When starting compressor for the first time after the reset with the power is ON. 5. When starting compressor for heating next to the suspension of defrosting. 6. When starting compressor next to the fault of switching over cooling / heating. <p>Set the lower limit frequency to 68 (model by model) Hz for 45 seconds (50 seconds for (A)RK(X)H, R(Y)N models) with any conditions 1 through 4 above.</p>
---------------	--


3.3.4 3-minutes Standby

Prohibit to turn ON the compressor for 3 minutes after turning it off.
(Except when defrosting. (Only for Heat Pump Model).)

3.3.5 Compressor Protection Function

When turning the compressor from OFF to ON, the upper limit of frequency must be set as follows. (The function must not be used when defrosting (only for heat pump model).)

FCG 3	88
FCG 2	64
FCG 1	48
TCG 1	240
TCG 2	360
TCG 3	180




3.4 Discharge Pipe Control

Outline

The discharge pipe temperature is used as the compressor's internal temperature. If the discharge pipe temperature rises above a certain level, the operating frequency upper limit is set to keep this temperature from going up further.

Detail

Divide the Zone



Management within the Zones

Zone	Control contents
Stop zone	When the temperature reaches the stop zone, stop the compressor and correct abnormality.
Drooping zone	Start the timer, and the frequency will be drooping.
Keep zone	Keep the upper limit of frequency.
Return / Reset zone	Cancel the upper limit of frequency.


3.5 Input Current Control

Outline

Detect an input current by the CT during the compressor is running, and set the frequency upper limit from such input current.
 In case of heat pump model, this control is the upper limit control function of the frequency which takes priority of the lower limit of four way valve activating compensation.

Detail

The frequency control will be made within the following zones.



When a “stop current” continues for 2.5 seconds after rushing on the stop zone, the compressor operation stops.

If a “drooping current” is continues for 1.0 second after rushing on the drooping zone, the frequency will be 2 Hz drooping.

Repeating the above drooping continues until the current rushes on the drooping zone without change.

In the unchanged zone, the frequency limit will remain.

In the return / reset zone, the frequency limit will be cancelled.

Limitation of current drooping and stop value according to the outdoor air temperature

1. In case the operation mode is cooling
 - The current droops when outdoor air temperature becomes higher than a certain level (model by model).
2. In case the operation mode is heating (only for heat pump model)
 - The current droops when outdoor air temperature becomes higher than a certain level (model by model).

3.6 Freeze-up Protection Control

Outline


During cooling operation, the signals being sent from the indoor unit allow the operating frequency limitation and then prevent freezing of the indoor heat exchanger. (The signal from the indoor unit must be divided into the zones as the followings.

Detail

Conditions for Start Controlling

Judge the controlling start with the indoor heat exchanger temperature after 2 sec from operation start.

Control in Each Zone



3.7 Heating Peak-cut Control

Outline

Heat Pump Only

During heating operation, the signals being sent from the indoor unit allow the operating frequency limitation and prevent abnormal high pressure. (The signal from the indoor unit must be divided as follows.)


Detail

Conditions for Start Controlling

Judge the controlling start with the indoor heat exchanger temperature after 2 sec. from operation start.

Control in Each Zone

The heat exchange intermediate temperature of indoor unit controls the following.



3.8 Fan Control

Outline

Fan control is carried out according to the following priority.

1. Fan control when defrosting
2. Fan OFF delay when stopped
3. ON/OFF control when cooling operation
4. Tap control when drooping function is working
5. Fan control when forced operation
6. Fan control in low noise mode
7. Fan control during heating operation
8. Fan control in the quiet mode
9. Fan control in the powerful mode
10. Fan control for pressure difference upkeep

Detail

Fan OFF Control when Stopped

- Fan OFF delay for 60 seconds must be made when the compressor is stopped.

3.9 Liquid Compression Protection Function 2

Outline

In order to obtain the dependability of the compressor, the compressor must be stopped according to the conditions of the temperature of the outdoor air and outdoor heat exchanger.

Detail

- Operation stop depending on the outdoor air temperature

Compressor operation turns OFF under the conditions that the system is in cooling operation and outdoor air temperature is below -10°C (0°C for (A)RK(X)H, R(Y)N models).

3.10 Defrost Control

Outline

Heat Pump Only

Defrosting is carried out by the cooling cycle (reverse cycle). The defrosting time or outdoor heat exchanger temperature must be more than its fixed value when finishing.

Detail


Conditions for Starting Defrost

The starting conditions must be made with the outdoor air temperature and heat exchanger temperature. Under the conditions that the system is in heating operation, 6 minutes after the compressor is started and more than 28 minutes of accumulated time pass since the start of the operation or ending the defrosting.


Conditions for Canceling Defrost

The judgment must be made with heat exchanger temperature. (4°C~22°C)

ARK(X)S models



(A)RK(X)H, R(Y)N models



3.11 Electronic Expansion Valve Control

Outline

The following items are included in the electronic expansion valve control.

Electronic expansion valve is fully closed

1. Electronic expansion valve is fully closed when turning on the power.
2. Pressure equalizing control

Open Control

1. Electronic expansion valve control when starting operation
2. Control when frequency changed
3. Control for defrosting (only for heat pump model)
4. Control when a discharge pipe temperature is abnormally high
5. Control when the discharge pipe thermistor is disconnected

Feedback Control

1. Discharge pipe temperature control

Detail

The followings are the examples of control which function in each mode by the electronic expansion valve control.

Operation pattern	○ : function × : not function	Control when frequency changed	Control for abnormally high discharge pipe temperature
When power is turned ON	Fully closed when power is turned ON	×	×
↓			
Cooling operation	Open control when starting	×	○
↓			
(Control of target discharge pipe temperature)	(Control of target discharge pipe temperature)	○	○
↓			
Stop	Pressure equalizing control	×	×
↓			
Heating operation (only for heat pump model)	Open control when starting	×	○
↓			
(Control of target discharge pipe temperature)	(Control of target discharge pipe temperature)	○	○
↓			
(Defrost control FD=1) (only for heat pump model)	(Defrost control FD=1) (only for heat pump model)	×	×
↓			
Stop	Pressure equalizing control	×	×
↓			
Heating operation (only for heat pump model)	Open control when starting	×	○
↓			
Control of discharge pipe thermistor disconnection	Continue	×	×
↓			
Stop	Pressure equalizing control	×	×

(R2833)

3.11.1 Fully Closing with Power ON

Initialize the electronic expansion valve when turning on the power, set the opening position and develop pressure equalizing.

3.11.2 Pressure Equalization Control

When the compressor is stopped, open and close the electronic expansion valve and develop pressure equalization.

3.11.3 Opening Limit

Outline

Limit a maximum and minimum opening of the electronic expansion valve.

Detail

- A maximum electronic expansion valve opening : 450 pulses
 - A minimum electronic expansion valve opening : 52 pulses
- The electronic expansion valve is fully closed in the room where cooling is stopped and is opened with fixed opening during defrosting.

3.11.4 Starting Operation Control

Control the electronic expansion valve opening when the system is starting, and prevent the system to be super heated or moistened.

3.11.5 High Temperature of the Discharge Pipe

When the compressor is operating, if the discharge pipe temperature exceeds a certain value, open the electronic expansion valve and remove the refrigerant to the low pressure side and lower discharge temperature.

3.11.6 Disconnection of the Discharge Pipe Thermistor

Outline

Detect a disconnected discharge pipe thermistor by comparing the discharge pipe temperature with the condensation temperature. If any is disconnected, open the electronic expansion valve according to the outdoor air temperature and the operating frequency and operate for a specified time, and then stop.

After 3 minutes of waiting, restart the unit and check if any is disconnected. If any is disconnected stop the system after operating for a specified time. If the disconnection is detected 4 times in succession, then the system will be down.

Detail

Detect Disconnection

If the timer for open control (cooling : 12min., heating : 15min.) becomes over, and the 9-minute timer for the compressor operation continuation is not counting time, the following adjustment must be made.

1. When the operation mode is cooling
When the discharge pipe temperature is lower than the outdoor heat exchanger temperature, the discharge pipe thermistor disconnection must be ascertained.
2. When the operation mode is heating (only for heat pump model)
When the discharge pipe temperature is lower than the max temperature of indoor unit heat exchanger, the discharge pipe thermistor disconnection must be ascertained.

Adjustment when the thermistor is disconnected


When compressor stop repeats specified time, the system should be down.

3.11.7 Control when frequency is changed

When the target discharge pipe temperature control is active, if the target frequency is changed for a specified value in a certain time period, cancel the target discharge pipe temperature control and change the target opening of the electronic expansion valve according to the shift.

3.11.8 Target Discharge Pipe Temperature Control

Obtain the target discharge pipe temperature from the indoor and outdoor heat exchanger temperature, and adjust the electronic expansion valve opening so that the actual discharge pipe temperature become close to that temperature. (Indirect SH control using the discharge pipe temperature)



(R1389)

Determine a correction value of the electronic expansion valve compensation and drive it according to the deflection of the target discharge temperature and actual discharge temperature, and the discharge temperature variation by the 20 sec.

3.12 Malfunctions

3.12.1 Sensor Malfunction Detection

Sensor malfunction may occur in the thermistor.

Relating to Thermistor Malfunction

1. Outdoor heat exchanger thermistor
2. Discharge pipe thermistor
3. Fin thermistor
4. Outdoor air thermistor

3.12.2 Detection of Overload and Over Current

Outline

In order to protect the inverter, detect an excessive output current, and for protecting compressor, monitor the OL operation.

Detail

- If the OL (compressor head) temperature exceeds 120°C (depending on the model), the compressor gets interrupted.
- If the inverter current exceeds 22 A, the compressor gets interrupted too.

3.12.3 Insufficient Gas Control


Outline

There are three ways of control to detect insufficient gas.

I Detecting by power consumption


If the power consumption is below the specified value and the frequency is higher than the specified frequency, it is regarded as insufficient gas.

The power consumption is weak comparing with that in the normal operation when gas is insufficient, and gas insufficiency is detected by checking a power consumption.



II Detecting by discharge pipe temperature

If the discharge temperature is higher than the target discharge pipe temperature, and the electronic expansion valve is fully open (450 pulses) more than the specified time, it is regarded as insufficient gas.



III Detecting by the difference of temperature

If the difference between inhale and exhale temperature is smaller than the specified value, it is regarded as insufficient gas.

Detail**I Judgment by power consumption**

When an output frequency is exceeds 55 Hz and the input current is less than specified value, the adjustment is made for insufficient gas.

II Judgment by discharge pipe temperature

When discharge pipe temperature is 20°C higher than target value and the electronic expansion valve opening is 450 pulses (max.), the adjustment is made for insufficient gas.

III Judgment by the difference of temperature

When the difference of the temperature is smaller than Δ , it is regarded as insufficient gas.

		Δ
Cooling	room temperature – indoor heat exchanger temperature	4.0°C
	outdoor heat exchanger temperature – outdoor temperature	4.0°C
Heating	indoor heat exchanger temperature – room temperature	4.0°C
	outdoor temperature – outdoor heat exchanger temperature	3.0°C

3.13 Forced Operation Mode

Outline

Forced operating mode includes only forced cooling.

Detail**Forced Cooling**

Item	Forced Cooling
Forced operation allowing conditions	1) The outdoor unit is not abnormal and not in the 3-minute stand-by mode. 2) The operating mode of the outdoor unit is the stop mode. 3) The forced operation is ON. The forced operation is allowed when the above "and" conditions are met.
Starting/adjustment	If the forced operation switch is pressed as the above conditions are met.
1) Command frequency	68 Hz
2) Electronic expansion valve opening	Depending on the capacity of the indoor unit.
3) Outdoor unit adjustment	Compressor is in operation
4) Indoor unit adjustment	Transmit the command of forced draft to the indoor unit.
End	1) When the forced operation switch is pressed again. 2) The operation is to end automatically after 15 min.
Others	The protect functions are prior to all others in the forced operation.

3.14 Additional Function

3.14.1 POWERFUL Operation Mode

Compressor operating frequency is increased to PI Max. (Max. Hz of operating room) and outdoor unit airflow rate is increased.

3.14.2 Voltage Detection Function

Power supply voltage is detected each time equipment operation starts.


3.15 Facility Setting Jumper (cooling at low outdoor temperature)

Outline

This function is limited only for facilities (the target of air conditioning is equipment (such as computer)). Never use it in a residence or office (the space where there is a human).

Detail

You can expand the operation range to -15°C by cutting jumper 8 (J8) on the PCB. If the outdoor temperature falls to -20°C or lower, the operation will stop. If the outdoor temperature rises, the operation will start again.



Caution

1. If the outdoor unit is installed where the heat exchanger of the unit is exposed to direct wind, provide a windbreak wall.
2. Intermittent noises may be produced by the indoor unit due to the outdoor fan turning on and off when using facility settings.
3. Do not place humidifiers or other items which might raise the humidity in rooms where facility settings are being used.
A humidifier might cause dew jumping from the indoor unit outlet vent.
4. Cutting jumper 8 (J8) sets the indoor fan tap to the highest position. Notify the user about this.

Part 5

System Configuration

- 1. System Configuration.....66
- 2. Instruction.....67
 - 2.1 Safety precautions.....67
 - 2.2 Names of parts69
 - 2.3 Preparation before Operation.....72
 - 2.4 AUTO · DRY · COOL · HEAT · FAN Operation75
 - 2.5 Adjusting the Air Flow Direction77
 - 2.6 POWERFUL Operation79
 - 2.7 OUTDOOR UNIT SILENT Operation80
 - 2.8 HOME LEAVE Operation81
 - 2.9 INTELLIGENT EYE Operation83
 - 2.10 TIMER Operation85
 - 2.11 Care and Cleaning87
 - 2.12 Troubleshooting.....90

1. System Configuration

After the installation and test operation of the room air conditioner have been completed, it should be operated and handled as described below. Every user would like to know the correct method of operation of the room air conditioner, to check if it is capable of cooling (or heating) well, and to know a clever method of using it.

In order to meet this expectation of the users, giving sufficient explanations taking enough time can be said to reduce about 80% of the requests for servicing. However good the installation work is and however good the functions are, the customer may blame either the room air conditioner or its installation work because of improper handling. The installation work and handing over of the unit can only be considered to have been completed when its handling has been explained to the user without using technical terms but giving full knowledge of the equipment.



2. Instruction



Note: This instruction is appropriate for ATK(X)S-D models

2.1 Safety precautions



- Keep this manual where the operator can easily find them.
- Read this manual attentively before starting up the unit.
- For safety reason the operator must read the following cautions carefully.
- This manual classifies precautions into WARNING and CAUTION. Be sure to follow all precautions below: they are all important for ensuring safety.

 WARNING If you do not follow these instructions exactly, the unit may cause property damage, personal injury or loss of life.	 CAUTION If you do not follow these instructions exactly, the unit may cause minor or moderate property damage or personal injury.
---	---

- | | |
|---|---|
| <ul style="list-style-type: none">  Never do.  Be sure to earth the air conditioner.  Never touch the air conditioner (including the remote control) with a wet hand. | <ul style="list-style-type: none">  Be sure to follow the instructions.  Never cause the air conditioner (including the remote control) to get wet. |
|---|---|








WARNING

- In order to avoid fire, explosion or injury, do not operate the unit when harmful, among which flammable or corrosive gases, are detected near the unit. 
 - It is not good for health to expose your body to the air flow for a long time.
 - Do not put a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury.
 - Do not attempt to repair, relocate, modify or reinstall the air conditioner by yourself. Incorrect work will cause electric shocks, fire etc.
For repairs and reinstallation, consult your Daikin dealer for advice and information.
-
- The refrigerant used in the air conditioner is safe. Although leaks should not occur, if for some reason any refrigerant happens to leak into the room, make sure it does not come in contact with any flame as of gas heaters, kerosene heaters or gas range. 
 - If the air conditioner is not cooling (heating) properly, the refrigerant may be leaking, so call your dealer. When carrying out repairs accompanying adding refrigerant, check the content of the repairs with our service staff.
 - Do not attempt to install the air conditioner by your self. Incorrect work will result in water leakage, electric shocks or fire. For installation, consult the dealer or a qualified technician.
 - In order to avoid electric shock, fire or injury, if you detect any abnormally such as smell of fire, stop the operation and turn off the breaker. And call your dealer for instructions.



CAUTION

- The air conditioner must be earthed. Incomplete earthing may result in electric shocks. Do not connect the earth line to a gas pipe, water pipe, lightning rod, or a telephone earth line. 
- In order to avoid any quality deterioration, do not use the unit for cooling precision instruments, food, plants, animals or works of art. 
- Never expose little children, plants or animals directly to the air flow.
- Do not place appliances which produce open fire in places exposed to the air flow from the unit or under the indoor unit. It may cause incomplete combustion or deformation of the unit due to the heat.
- Do not block air inlets nor outlets. Impaired air flow may result in insufficient performance or trouble.

- Do not stand or sit on the outdoor unit. Do not place any object on the unit to avoid injury, do not remove the fan guard.
 - Do not place anything under the indoor or outdoor unit that must be kept away from moisture. In certain conditions, moisture in the air may condense and drip.
 - After a long use, check the unit stand and fittings for damage.
 - Do not touch the air inlet and aluminum fins of outdoor unit. It may cause injury.
 - The appliance is not intended for use by young children or infirm persons without supervision.
 - Young children should be supervised to ensure that they do not play with the appliance.
-
- To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the air conditioner. 
 - Before cleaning, be sure to stop the operation, turn the breaker off or pull out the supply cord.
 - Do not connect the air conditioner to a power supply different from the one as specified. It may cause trouble or fire.
 - Depending on the environment, an earth leakage breaker must be installed. Lack of an earth leakage breaker may result in electric shocks.
 - Arrange the drain hose to ensure smooth drainage. Incomplete draining may cause wetting of the building, furniture etc.
 - Do not place objects in direct proximity of the outdoor unit and do not let leaves and other debris accumulate around the unit.
Leaves are a hotbed for small animals which can enter the unit. Once in the unit, such animals can cause malfunctions, smoke or fire when making contact with electrical parts.
-
- Do not operate the air conditioner with wet hands. 
-
- Do not wash the indoor unit with excessive water, only use a slightly wet cloth.
 - Do not place things such as vessels containing water or anything else on top of the unit. Water may penetrate into the unit and degrade electrical insulations, resulting in an electric shock. 
-

Installation site

- To install the air conditioner in the following types of environments, consult the dealer.
 - Places with an oily ambient or where steam or soot occurs.
 - Salty environment such as coastal areas.
 - Places where sulfide gas occurs such as hot springs.
 - Places where snow may block the outdoor unit.

The drain from the outdoor unit must be discharged to a place of good drainage.

Consider nuisance to your neighbours from noises

- For installation, choose a place as described below.
 - A place solid enough to bear the weight of the unit which does not amplify the operation noise or vibration.
 - A place from where the air discharged from the outdoor unit or the operation noise will not annoy your neighbours.

Electrical work


- For power supply, be sure to use a separate power circuit dedicated to the air conditioner.

System relocation


- Relocating the air conditioner requires specialized knowledge and skills. Please consult the dealer if relocation is necessary for moving or remodeling

2.2 Names of Parts

■ Indoor Unit



Outdoor Unit



Indoor Unit

1. Air filter
2. Airpurifying filter with photocatalytic deodorizing function:
 - These filters are attached to the inside of the air filters.
3. Air inlet
4. Front panel
5. Panel tab
6. Room temperature sensor:
 - It senses the air temperature around the unit.
7. INTELLIGENT EYE sensor:
 - It detects the movements of people and automatically switches between normal operation and energy saving operation. (page18.)
8. Display
9. Air outlet
10. Flaps (horizontal blades): (page 12.)
11. Louvers (vertical blades):
 - The louvers are inside of the air outlet. (Page 13.)

12. Indoor Unit ON/OFF switch:

- Push this switch once to start operation. Push once again to stop it.
- the operation mode refers to the following table..

	Mode	Temperature setting	Air flow rate
ATKS	COOL	22°C	AUTO
ATXS	AUTO	25°C	AUTO

- This switch is useful when the remote control is missing.

13. Operation lamp (green)

14. TIMER lamp (yellow): (page 20.)

15. HOME LEAVE lamp (red): (page 16.)

16. Signal receiver:


- It receives signals from the remote control.
- When the unit receives a signal, you will hear a short beep.
 - Operation start beep-beep
 - Settings changes beep
 - Operation stop beeeeeeep

Outdoor Unit

17. Air inlet: (Back and side)
18. Air outlet
19. Refrigerant piping and inter-unit cable
20. Drain hose
21. Earth terminal:
 - It is inside of this cover.
22. Outside air temperature sensor:
 - It senses the ambient temperature around the unit.

Appearance of the outdoor unit may differ from some models.


■ Remote control




- | | |
|--|--|
| <p>1. Signal transmitter:</p> <ul style="list-style-type: none"> • It sends signals to the indoor unit. <p>2. Display:</p> <ul style="list-style-type: none"> • It displays the current settings.
(In this illustration, each section is shown with all its displays ON for the purpose of explanation) <p>3. HOME LEAVE button:
HOME LEAVE operation (page 16.)</p> <p>4. POWERFUL button:
POWERFUL operation (page 14.)</p> <p>5. TEMPERATURE adjustment buttons:</p> <ul style="list-style-type: none"> • It changes the temperature setting. <p>6. ON/OFF button:</p> <ul style="list-style-type: none"> • Press this button once to start operation.
Press once again to stop it. | <p>7. MODE selector button:</p> <ul style="list-style-type: none"> • It selects the operation mode.
(AUTO/DRY/COOL/HEAT/FAN)(page 10.) <p>8. SILENT button: OUTDOOR UNIT
SILENT operation (page 15.)</p> <p>9. FAN setting button:</p> <ul style="list-style-type: none"> • It selects the air flow rate setting. <p>10. SWING button: (page 12.)</p> <p>11. SENSOR button: INTELLIGENT EYE
operation (p18.)</p> <p>12. ON TIMER button: (page 21.)</p> <p>13. OFF TIMER button: (page 20.)</p> <p>14. TIMER Setting button:</p> <ul style="list-style-type: none"> • It changes the timer setting. <p>15. TIMER CANCEL button:</p> <ul style="list-style-type: none"> • It cancels the timer setting. <p>16. CLOCK button: (page 9)</p> |
|--|--|

2.3 Preparation Before Operation

■ To set the batteries

1. Press “” with a finger and slide the front cover to take it off.
2. Set two dry batteries (AAA).
3. Set the front cover as before.




ATTENTION

■ About batteries

- When replacing the batteries, use batteries of the same type, and replace the two old batteries together.
- When the system is not used for a long time, take the batteries out.
- We recommend replacing once a year, although if the remote control display begins to fade or if reception deteriorates, please replace with new alkali batteries. Do not use manganese batteries.
- The attached batteries are provided for the initial use of the system. The usable period of the batteries may be short depending on the manufactured date of the air conditioner.


■ To operate the remote control

- To use the remote control, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote control, such as a curtain, the unit will not operate.
- Do not drop the remote control. Do not get it wet.
- The maximum distance for communication is about 7m.



■ To fix the remote control holder on the wall

1. Choose a place from where the signals reach the unit.
2. Fix the holder to a wall, a pillar, etc. with the screws supplied with the holder.
3. Place the remote control in the remote control holder.



- To remove, pull it upwards.

ATTENTION


- About remote control
 - Never expose the remote control to direct sunlight.
 - Dust on the signal transmitter or receiver will reduce the sensitivity. Wipe off dust with soft cloth.
 - Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
 - If the remote control signals happen to operate another appliance, move that appliance to some-where else, or consult the shop.

■ To set the clock

1. Press "CLOCK button".
0:00 is displayed.
⌚ blinks.
2. Press "TIMER setting button" to set the clock to the present time.
Holding down "▲" or "▼" button rapidly increases or decreases the time display.
3. Press "CLOCK button".
:blinks.

■ Turn the breaker ON

- Turning ON the breaker opens the flap, then closes it again. (This is a normal procedure.)



NOTE

■ Tips for saving energy

- Be careful not to cool (heat) the room too much. Keeping the temperature setting at a moderate level helps save energy.
- Cover windows with a blind or a curtain. Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every two weeks.

Recommended temperature setting
For cooling: 26°C – 28°C
For heating: 20°C – 24°C

■ Please note

- The air conditioner always consumes 15-35 watts of electricity even while it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker OFF.
- Use the air conditioner in the following conditions.

Mode	Initial setting	Selectable range
COOL	Outdoor temperature: 2/3AMK(X)S 10 to 46°C ARK(X)S -10 to 46°C ARK(X)H 10 to 46°C Indoor temperature: 18 to 32°C Indoor humidity: 80% max.	<ul style="list-style-type: none"> • A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the out-door unit only.) • Condensation may occur on the indoor unit and drip.
HEAT	Outdoor temperature: 2/3AMXS -10 to 46°C ARXS -15 to 21°C ARXH -10 to 21°C Indoor temperature: 10 to 30°C	<ul style="list-style-type: none"> • A safety device may work to stop the operation.
DRY	Outdoor temperature: 2/3AMK(X)S 10 to 46°C ARK(X)S -10 to 46°C ARK(X)H 10 to 46°C Indoor temperature: 18 to 32°C Indoor humidity: 80% max.	<ul style="list-style-type: none"> • A safety device may work to stop the operation. • Condensation may occur on the indoor unit and drip.

- Operation outside this humidity or temperature range may cause a safety device to disable the system.

2.4 Auto·Dry·Cool·Heat·Fan·Operation

The air conditioner operates with the operation mode of your choice. From the next time on, the air conditioner will operate with the same operation mode.

■ To start operation

1. Press "MODE selector button" and select a operation mode.

- Each pressing of the button advances the mode setting in sequence.


Ⓐ : AUTO

☐ : DRY

❄ : COOL

☀ : HEAT

🌀 : FAN



2. Press "ON/OFF button" .

- The OPERATION lamp lights up.




■ To stop operation

3. Press "ON/OFF button" again.

- Then OPERATION lamp goes off.

■ To change the temperature setting


4. Press "TEMPERATURE adjustment button".



DRY or FAN mode	AUTO or COOL or HEAT mode
The temperature setting is not variable.	Press "▲" to raise the temperature and press "▼" to lower the temperature.
	Set to the temperature you like

■ To change the air flow rate setting

5. Press "FAN setting button".

DRY mode	AUTO or COOL or HEAT or FAN mode
The air flow rate setting is not variable	Five levels of air flow rate setting from " " to " " plus " " " " " are available.
	

- Indoor unit quiet operation

When the air flow is set to " ", the noise from the indoor unit will become quieter.

Use this when making the noise quieter.

The unit might lose capacity when the air flow rate is set to a weak level.

NOTE

■ Note on heat operation

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.
- The heat pump system heats the room by circulating hot air around all parts of the room. After the start of heating operation, it takes some time before the room gets warmer.
- In heating operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.

■ Note on DRY operation

- The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and fan strength, so manual adjustment of these functions is unavailable.

■ Note on AUTO operation

- In AUTO operation, the system selects an appropriate operation mode (COOL or HEAT) based on the room temperature at the start of the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.
- If you do not like AUTO operation, you can manually select the operation mode and setting you like.


■ Note on air flow rate setting


- At smaller air flow rates, the cooling (heating) effect is also smaller.

2.5 Adjusting the Air Flow Direction

You can adjust the air flow direction to increase your comfort.


■ To adjust the horizontal blades (flaps)

1. Press “SWING button”.
 - “” is displayed on the LCD.
1. When the flaps have reached the desired position, press “SWING button” once more.
 - The flaps will stop moving.



■ To adjust the vertical blades (louvers)

Hold the knob and move the louvers.
(You will find a knob on the left side and the right-side blades.)




Notes on flaps and louvers angles

- When “**SWING button**” is selected, the flaps swinging range depends on the operation mode. (See the figure.)

■ ATTENTION

- Always use a remote control to adjust the flaps angle. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Be careful when adjusting the louvers. Inside the air outlet, a fan is rotating at a high speed.



2.6 POWERFUL Operation


POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity

■ To start POWERFUL operation

1. Press "POWERFUL button".
 - POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the settings which were used before POWERFUL operation.
 - When using POWERFUL operation, there are some functions which are not available.
 - "☞☜" is displayed on the LCD.

■ To cancel POWERFUL operation

2. Press "POWERFUL button" again.
 - "☞☜" disappears from the LCD.



NOTE

■ Notes on POWERFUL operation

- **In COOL and HEAT mode**
To maximize the cooling (heating) effect, the capacity of outdoor unit must be increased and the air flow rate be fixed to the maximum setting. The temperature and air flow settings are not variable.
- **In DRY mode**
The temperature setting is lowered by 2.5°C and the air flow rate is slightly increased.
- **In FAN mode**
The air flow rate is fixed to the maximum setting.

2.7 OUTDOOR UNIT SILENT Operation


OUTDOOR UNIT SILENT operation lowers the noise level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during night.

■ To start OUTDOOR UNIT SILENT operation

1. Press "SILENT button".
 - "🔇" is displayed on the LCD.

■ To cancel OUTDOOR UNIT SILENT operation

2. Press "SILENT button" again.
 - "🔇" disappears from the LCD.



NOTE

■ Note on OUTDOOR UNIT SILENT operation

- This function is available in COOL, HEAT, and AUTO modes. (This is not available in FAN and DRY mode.)
- POWERFUL operation and OUTDOOR UNIT SILENT operation cannot be used at the same time. Priority is given to POWERFUL operation.
- If operation is stopped using the remote control or the main unit ON/OFF switch when using OUTDOOR UNIT SILENT operation, "🔇" remain on the remote control display.
- **This function does not work when connected to the ARX(K)H20, 25 or 35CVMB.**

2.8 HOME LEAVE Operation

HOME LEAVE operation is a function which allows you to record your preferred temperature and air flow rate settings.


■ To start HOME LEAVE operation

1. Press "HOME LEAVE button".
 - "🏠" is displayed on the LCD.
 - The HOME LEAVE lamp lights up.



■ To cancel HOME LEAVE operation

2. Press "HOME LEAVE button" again.
 - The HOME LEAVE lamp goes off.
 - "🏠" disappears from the LCD.



Before using HOME LEAVE operation

■ To set the temperature and air flow rate for HOME LEAVE operation

When using HOME LEAVE operation for the first time, please set the temperature and air flow rate for HOME LEAVE operation. Record your preferred temperature and air flow rate.

	Initial setting		Selectable range	
	temperature	Air flow rate	temperature	Air flow rate
Cooling	25°	AUTO	18-32°C	5 step, AUTO and SILENT
Heating	25°	AUTO	10-30°C	5 step, AUTO and SILENT

1. Press "HOME LEAVE button". Make sure "🏠" is displayed in the remote control display.
2. Adjust the set temperature with "▲" or "▼" as you like.
3. Adjust the air flow rate with "FAN" setting button as you like.

Home leave operation will run with these settings the next time you use the unit. To change the recorded information, repeat steps 1 – 3.

■ What's the HOME LEAVE operation


Is there a set temperature and air flow rate which is most comfortable, a set temperature and air flow rate which you use the most? HOME LEAVE operation is a function that allows you to record your favorite set temperature and air flow rate. You can start your favorite operation mode simply by pressing the HOME LEAVE button on the remote control. This function is convenient in the following situations.

■ Useful in these cases.

1. Use as an energy-saving mode

Set the temperature 2-3°C higher (cooling) or lower (heating) than normal. Setting the fan strength to the lowest setting allows the unit to be used in energy-saving mode. Also convenient for use while you are out or sleeping.


• Every day before you leave the house...



When you go out, push the "HOME LEAVE Operation" button, and the air conditioner will adjust capacity to reach the preset temperature for HOME LEAVE Operation.




When you return, you will be welcomed by a comfortably air conditioned room.




Push the "HOME LEAVE Operation" button again, and the air conditioner will adjust capacity to the set temperature for normal operation.


• Before bed...



Set the unit to HOME LEAVE Operation before leaving the living room when going to bed.



The unit will maintain the temperature in the room at a comfortable level while you sleep.



When you enter the living room in the morning, the temperature will be just right. Disengaging HOME LEAVE Operation will return the temperature to that set for normal operation. Even the coldest winters will pose no problem!

2. Use as a favorite mode

Once you record the temperature and air flow rate settings you most often use, you can retrieve them by pressing HOME LEAVE button. You do not have to go through troublesome remote control operations.

NOTE

- Once the temperature and air flow rate for HOME LEAVE operation are set, those settings will be used whenever HOME LEAVE operation is used in the future. To change these settings, please refer to the "Before using HOME LEAVE operation" section above.
- HOME LEAVE operation is only available in COOL and HEAT mode. Cannot be used in AUTO, DRY, and FAN mode.
- HOME LEAVE operation runs in accordance with the previous operation mode (COOL or HEAT) before using HOME LEAVE operation.
- HOME LEAVE operation and POWERFUL operation cannot be used at the same time. Last button that was pressed has priority.
- The operation mode cannot be changed while HOME LEAVE operation is being used.
- When operation is shut off during HOME LEAVE operation, using the remote control or the indoor unit ON/OFF switch, "🏠" will remain on the remote control display.

2.9 INTELLIGENT EYE Operation



“INTELLIGENT EYE” is the infrared sensor which detects the human movement.

■ To start INTELLIGENT EYE operation

1. Press “SENSOR button”.
 - “ 👤 ” is displayed on the LCD.


■ To cancel the INTELLIGENT EYE operation

2. Press “SENSOR button” again.
 - “ 👤 ” disappears from the LCD.




■ To adjust the angle of the INTELLIGENT EYE sensor

- You can adjust the angle of the INTELLIGENT EYE sensor to increase the detection area. (Adjustable angle: 15° to right and left of centre)



- Gently push and slide the sensor to adjust the angle.
- After adjusting the angle, wipe the sensor gently with a clean cloth, being careful not to scratch the sensor.




“INTELLIGENT EYE” is useful for Energy Saving

■ Energy saving operation

- Change the temperature -2°C in heating / $+2^{\circ}\text{C}$ in cooling / $+2^{\circ}\text{C}$ in dry mode from set temperature.
- Decrease the air flow rate slightly in fan operation. (In FAN mode only)

Notes on “INTELLIGENT EYE”

- Application range is as follows.



- Sensor may not detect moving objects further than 5m away. (Check the application range)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during powerful operation.
- Night set mode will not go on during you use INTELLIGENT EYE operation.

⚠ CAUTION


- Do not place large objects near the sensor. Also keep heating units or humidifiers outside the sensor’s detection area. This sensor can detect objects it shouldn’t as well as not detect objects it should.
- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

2.10 TIMER Operation

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

■ To use OFF TIMER operation

- Check that the clock is correct. If not, set the clock to the present time.
1. Press **“OFF TIMER button”**.
0:00 is displayed.
⊖-○ blinks.
 2. Press **“TIMER Setting button”** until the time setting reaches the point you like.
 - Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.
 3. Press **“OFF TIMER button”** again.
 - The TIMER lamp lights up.



■ To cancel the OFF TIMER operation

4. Press **“CANCEL button”**.
 - The TIMER lamp goes off.


NOTE


- When TIMER is set, the present time is not displayed.
- Once you set ON, OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote control batteries are replaced.)
- When operating the unit via the ON/OFF Timer, the actual length of operation may vary from the time entered by the user.

■ NIGHT SET MODE

When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

■ To use ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time.
- 1. Press “ON TIMER button”.
 - 5:00 is displayed.
 - “” blinks.
- 2. Press “TIMER Setting button” until the time setting reaches the point you like.
 - Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.
- 3. Press “ON TIMER button” again.
 - The TIMER lamp lights up..




■ To cancel the ON TIMER operation

- 4. Press “CANCEL button”.
 - The TIMER lamp goes off.

■ To combine ON TIMER and OFF TIMER

- A sample setting for combining the two timers is shown below



ATTENTION

- In the following cases, set the timer again.
 - After a breaker has turned OFF.
 - After a power failure.
 - After replacing batteries in the remote control.

2.11 Care and Cleaning

⚠ CAUTION Before cleaning, be sure to stop the operation and turn the breaker OFF.




UNITS

■ Indoor unit, Outdoor unit and Remote control

1. Wipe them with dry soft cloth.

■ Front panel

1. **Open the front panel.**
 - Hold the panel by the tabs on the two sides and lift it until it stops with a click.
2. **Remove the front panel.**
 - Supporting the front panel with one hand, release the lock by sliding down the knob with the other hand.
 - To remove the front panel, pull it toward yourself with both hands.
3. **Clean the front panel.**
 - Wipe it with a soft cloth soaked in water.
 - Only neutral detergent may be used.
 - In case of washing the panel with water, dry it with cloth, dry it up in the shade after washing.
4. **Attach the front panel.**
 - Set the 3 keys of the front panel into the slots and push them in all the way.
 - Close the front panel slowly and push the panel at the 3 points. (1 on each side and 1 in the middle).
 - Check to see if the rotating axis in the upper center section is moving.




⚠ CAUTION


- Don't touch the metal parts of the indoor unit. If you touch those parts, this may cause an injury.
- When removing or attaching the front panel, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front panel, support the panel securely with hand to prevent it from falling.
- For cleaning, do not use hot water above 40 °C, benzine, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.
- After cleaning, make sure that the front panel is securely fixed.

FILTERS


1. **Open the front panel.**
2. **Pull out the air filters.**
 - Push a little upwards the tab at the center of each air filter, then pull it down.



3. **Take off the air purifying filter with photocatalytic deodorizing function.**
 - Hold the recessed parts of the frame and unhook the four claws.
4. **Clean or replace each filter.**
 - See figure.





5. **Set the air filter and the air purifying filter with photocatalytic deodorizing function as they were and close the front panel.**
 - Insert claws of the filters into slots of the front panel. Close the front panel slowly and push the panel at the 3 points. (1 on each side and 1 in the middle.)



■ Air Filter

1. **Wash the air filters with water or clean them with vacuum cleaner.**
 - If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.
 - It is recommended to clean the air filters every two weeks.



■ Air-purifying Filter with photocatalytic deodorizing function. (gray)

The air-purifying filter with photocatalytic deodorizing function can be renewed by washing it with water once every 6 months. We recommend replacing it once every 3 years.

[Maintenance]

1. **Remove dust with a vacuum cleaner and wash lightly with water.**
2. **If it is very dirty, soak it for 10 to 15 minutes in water mixed with a neutral cleaning agent.**
3. **Do not remove filter from frame when washing with water.**
4. **After washing, shake off remaining water and dry in the shade.**
5. **Since the material is made out of paper, do not wring out the filter when removing water from it.**

[Replacement]

1. **Remove the tabs on the filter frame and replace with a new filter.**
 - Dispose of the old filter as flammable waste.

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.
Check that the drain comes smoothly out of the drain hose during COOL or DRY operation. • If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

■ Before a long idle period

1. **Operate the “FAN only” for several hours on a fine day to dry out the inside.**
 - Press “MODE” button and select “FAN” operation.
 - Press “ON/OFF” button and start operation.
2. **After operation stops, turn off the breaker for the room air conditioner.**
3. **Clean the air filters and set them again.**
4. **Take out batteries from the remote control.**

NOTE

- Operation with dirty filters:
 - (1) cannot deodorize the air.
 - (2) cannot clean the air.
 - (3) results in poor heating or cooling.
 - (4) may cause odour.
- To order air-purifying filter with photocatalytic deodorizing function contact the service shop where you bought the air conditioner.
- Dispose of old filters as non-flammable waste.

Item	Part No.
Air purifying filter with photocatalytic deodorizing function. (without frame) 1 set	KAF918A43
Air purifying filter with photocatalytic deodorizing function. (without frame) 1 set	KAF918A44

2.12 Troubleshooting

These cases are not troubles.

The following cases are not air conditioner troubles but have some reasons. You may just continue using it.

Case	Explanation
Operation does not start soon. <ul style="list-style-type: none"> • When ON/OFF button was pressed soon after operation was stopped. • When the mode was reselected. 	<ul style="list-style-type: none"> • This is to protect the air conditioner. You should wait for about 3 minutes.
Hot air does not flow out soon after the start of heating operation.	<ul style="list-style-type: none"> • The air conditioner is warming up. You should wait for 1 to 4 minutes. (The system is designed to start discharging air only after it has reached a certain temperature.)
The heating operation stops suddenly and a flowing sound is heard.	<ul style="list-style-type: none"> • The system is taking away the frost on the outdoor unit. You should wait for about 3 to 8 minutes.
The outdoor unit emits water or steam.	<ul style="list-style-type: none"> ■ In HEAT mode <ul style="list-style-type: none"> • The frost on the outdoor unit melts into water or steam when the air conditioner is in defrost operation. ■ In COOL or DRY mode <ul style="list-style-type: none"> • Moisture in the air condenses into water on the cool surface of outdoor unit piping and drips.
Mists come out of the indoor unit.	<ul style="list-style-type: none"> ■ This happens when the air in the room is cooled into mist by the cold air flow during cooling operation.
The indoor unit gives out odour	<ul style="list-style-type: none"> ■ This happens when smells of the room, furniture, or cigarettes are absorbed into the unit and discharged with the air flow. (If this happens, we recommend you to have the indoor unit washed by a technician. Consult the service shop where you bought the air conditioner.)
The outdoor fan rotates while the air conditioner is not in operation.	<ul style="list-style-type: none"> ■ After operation is stopped: <ul style="list-style-type: none"> • The outdoor fan continues rotating for another 60 seconds for system protection. ■ While the air conditioner is not in operation: <ul style="list-style-type: none"> • When the outdoor temperature is very high, the outdoor fan starts rotating for system protection.
The operation stopped suddenly. (OPERATION lamp is on)	<ul style="list-style-type: none"> ■ For system protection, the air conditioner may stop operating on a sudden large voltage fluctuation. It automatically resumes operation in about 3 minutes.

Check again.

Please check again before calling a repair person.

Case	Check
The air conditioner does not operate. (OPERATION lamp is off)	<ul style="list-style-type: none"> • Hasn't a breaker turned OFF or a fuse blown? • Isn't it a power failure? • Are batteries set in the remote control? • Is the timer setting correct?
Cooling (Heating) effect is poor	<ul style="list-style-type: none"> • Are the air filters clean? • Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? • Is the temperature setting appropriate? • Are the windows and doors closed? • Are the air flow rate and the air direction set appropriately? • Is the unit set to the INTELLIGENT EYE mode?
Operation stops suddenly. (OPERATION lamp flashes.)	<ul style="list-style-type: none"> • Are the air filters clean? • Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? Clean the air filters or take all obstacles away and turn the breaker OFF. Then turn it ON again and try operating the air conditioner with the remote control. If the lamp still flashes, call the service shop where you bought the air conditioner.
An abnormal functioning happens during operation.	<ul style="list-style-type: none"> • The air conditioner may malfunction with lightning or radio waves. Turn the breaker OFF, turn it ON again and try operating the air conditioner with the remote control.

Call the service shop immediately.

 **WARNING**

- When an abnormality (such as a burning smell) occurs, stop operation and turn the breaker OFF. Continued operation in an abnormal condition may result in troubles, electric shocks or fire. Consult the service shop where you bought the air conditioner.
- Do not attempt to repair or modify the air conditioner by yourself. Incorrect work may result in electric shocks or fire. Consult the service shop where you bought the air conditioner.

If one of the following symptoms takes place, call the service shop immediately.

- **The power cord is abnormally hot or damaged.**
- **An abnormal sound is heard during operation.**
- **The safety breaker, a fuse, or the earth leakage breaker cuts off the operation frequently.**
- **A switch or a button often fails to work properly.**
- **There is a burning smell.**
- **Water leaks from the indoor unit.**



Turn the breaker OFF and call the service shop.

- **After a power failure**
The air conditioner automatically resumes operation in about 3 minutes. You should just wait for a while.

- **Lightning**
If lightning may strike the neighbouring area, stop operation and turn the breaker OFF for system protection.

Disposal requirements



Your air conditioning product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the air conditioning system, treatment of the refrigerant, of oil and of other parts must be done by a qualified installer in accordance with relevant local and national legislation.

Air conditioners must be treated at a specialized treatment facility for re-use, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. Please contact the installer or local authority for more information.

Batteries must be removed from the remote control and disposed of separately in accordance with relevant local and national legislation.

We recommend periodical maintenance

In certain operating conditions, the inside of the air conditioner may get foul after several seasons of use, resulting in poor performance. It is recommended to have periodical maintenance by a specialist aside from regular cleaning by the user. For specialist maintenance, contact the service shop where you bought the air conditioner.


The maintenance cost must be born by the user.

Call the service shop immediately.

FAULT DIAGNOSIS BY REMOTE CONTROL

In the ARC433A series, the temperature display sections on the main unit indicate corresponding codes.

1. When the **TIMER CANCEL** button is held down for 5 seconds, a “00” indication flashes on the temperature display section.



2. Press the **TIMER CANCEL** button repeatedly until a continuous beep is produced.

- The code indication changes as shown below, and notifies with a long beep.

	CODE	MEANING
SYSTEM	00	NORMAL
	U0	REFRIGERANT SHOTAGE
	U2	DROP VOLTAGE OR MAIN CIRCUIT OVERVOLTAGE
	U4	FAILURE OF TRANSMISSION (BETWEEN INDOOR UNIT AND OUTDOOR UNIT)
INDOOR UNIT	R1	INDOOR PCB DEFECTIVENESS
	R5	HIGH PRESSURE CONTROL OR FREEZE-UP PROTECTOR
	R6	FAN MOTOR FAULT
	L4	FAULTY HEAT EXCHANGER TEMPERATURE SENSOR
	L9	FAULTY SUCTION AIR TEMPERATURE SENSOR
OUTDOOR UNIT	E1	COOLING-HEATING SWITCHING ERROR
	E5	OL STARTED
	E6	FAULTY COMPRESSOR START UP
	E7	DC FAN MOTOR FAULT
	E8	OPERATION HALT DUE TO DETECTION OF INPUT OVER CURRENT
	F3	HIGH TEMPERATURE DISCHARGE PIPE CONTROL
	F6	HIGH PRESSURE CONTROL (IN COOLING)
	H6	OPERATION HALT DUE TO FAULTY POSITION DETECTION SENSOR
	H8	CT ABNORMALITY
	H9	FAULTY SUCTION AIR TEMPERATURE SENSOR
	J3	FAULTY DISCHARGE PIPE TEMPERATURE SENSOR
	J6	FAULTY HEAT EXCHANGER TEMPERATURE SENSOR
	L4	HIGH TEMPERATURE AT INVERTER CIRCUIT HEATSINK
	L5	OUTPUT OVERCURRENT
	P4	FAULTY INVERTER CIRCUIT HEATSINK TEMPERATURE SENSOR

NOTE

1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the **TIMER CANCEL** button down for 5 seconds. The code display also cancel itself if the button is not pressed for 1 minute.

Part 6

Service Diagnosis


1. Caution for Diagnosis.....	96
2. Problem Symptoms and Measures	97
3. Service Check Function	98
4. Troubleshooting	101
4.1 Error Codes and Description	101
4.2 Indoor Unit PCB Abnormality	102
4.3 Freeze-up Protection Control or High Pressure Control.....	103
4.4 Fan Motor (AC Motor) or Related Abnormality.....	105
4.5 Thermistor or Related Abnormality (Indoor Unit).....	106
4.6 Signal Transmission Error (between Indoor and Outdoor Unit)	107
4.7 OL Activation (Compressor Overload)	108
4.8 Compressor Lock	109
4.9 DC Fan Lock	110
4.10 Input Over Current Detection	111
4.11 Four Way Valve Abnormality.....	112
4.12 Discharge Pipe Temperature Control.....	114
4.13 High Pressure Control in Cooling	115
4.14 Position Sensor Abnormality	117
4.15 DC Voltage / Current Sensor Abnormality.....	118
4.16 Thermistor or Related Abnormality (Outdoor Unit).....	119
4.17 Electrical Box Temperature Rise.....	121
4.18 Radiation Fin Temperature Rise	123
4.19 Output Over Current Detection.....	125
4.20 Insufficient Gas.....	127
4.21 Over-voltage Detection.....	129
5. Check	130
5.1 How to Check.....	130

1. Caution for Diagnosis

The operation lamp flashes when any of the following errors is detected.

1. When a protection device of the indoor or outdoor unit is activated or when the thermistor malfunctions, disabling equipment operation.
 2. When a signal transmission error occurs between the indoor and outdoor units.
- In either case, conduct the diagnostic procedure described in the following pages.

Location of Operation Lamp



Troubleshooting with LED Indication

The outdoor unit has one green LED (LEDA) on the PCB. The flashing green LED indicates normal condition of microcomputer operation.

2. Problem Symptoms and Measures

Symptom	Check Item	Details of Measure	Reference Page
None of the Units Operates.	Check the power supply.	Check to make sure that the rated voltage is supplied.	—
	Check the type of the indoor units.	Check to make sure that the indoor unit type is compatible with the outdoor unit.	—
	Check the outdoor air temperature.	Heating operation cannot be used when the outdoor air temperature is 21°C or higher (only for heat pump model), and cooling operation cannot be used when the outdoor air temperature is below 10°C. (Note)	—
	Diagnosis with remote control indication	—	101
	Check the remote control addresses.	Check to make sure that address settings for the remote control and indoor unit are correct.	—
Operation Sometimes Stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation. (Operation lamp OFF)	—
	Check the outdoor air temperature.	Heating operation cannot be used when the outdoor air temperature is 24°C or higher (only for heat pump model), and cooling operation cannot be used when the outdoor air temperature is below 10°C. (Note)	—
	Diagnosis with remote control indication	—	101
Equipment operates but does not cool, or does not heat (only for heat pump model).	Check for wiring and piping errors in the indoor and outdoor units connection wires and pipes.	Conduct the wiring/piping error check described on the product diagnosis nameplate.	—
	Check for thermistor detection errors.	Check to make sure that the main unit's thermistor has not dismantled from the pipe holder.	—
	Check for faulty operation of the electronic expansion valve.	Set the units to cooling operation, and compare the temperatures of the liquid side connection pipes of the connection section among rooms to check the opening and closing operation of the electronic expansion valves of the individual units.	—
	Diagnosis with remote control indication	—	101
	Diagnosis by service port pressure and operating current	Check for insufficient gas.	135
Large Operating Noise and Vibrations	Check the output voltage of the power transistor.	—	136
	Check the power transistor.	—	—
	Check the installation condition.	Check to make sure that the required spaces for installation (specified in the Technical Guide, etc.) are provided.	—




Note: ARK(X)S series ; -10°C

3. Service Check Function

In the ARC433A series remote control, the temperature display sections on the main unit indicate corresponding codes.

Check Method 1

1. When the timer cancel button is held down for 5 seconds, a “00” indication flashes on the temperature display section.



<ARC433A1, A2 >

(R3038)

2. Press the timer cancel button repeatedly until a continuous beep is produced.
 - The code indication changes in the sequence shown below, and notifies with a long beep.

No.	Code	No.	Code	No.	Code
1	00	12	C7	23	H0
2	U4	13	H8	24	E1
3	F3	14	J3	25	P4
4	E6	15	R3	26	L3
5	L5	16	R1	27	L4
6	R6	17	C4	28	H6
7	E5	18	C5	29	H7
8	F6	19	H9	30	U2
9	C9	20	J6	31	UH
10	U0	21	UR	32	ER
11	E7	22	R5	33	RH




Note:

1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.


Check Method 2

1. Enter the diagnosis mode.
Press the 3 buttons (TEMP▲,TEMP▼, MODE) simultaneously.




The digit of the number of tens blinks.

★Try again from the start when the digit does not blink.




2. Press the TEMP button.
Press TEMP▲ or TEMP▼ and change the digit until you hear the sound of “beep” or “pi pi”.




3. Diagnose by the sound.
 - ★“ pi ” : The number of tens does not accord with the error code.
 - ★“ pi pi ” : The number of tens accords with the error code.
 - ★“ beep ” : The both numbers of tens and units accord with the error code. (→See 7.)


4. Enter the diagnosis mode again.
Press the MODE button.



The digit of the number of units blinks.




5. Press the TEMP button.
Press TEMP▲ or TEMP▼ and change the digit until you hear the sound of “beep”.



(R4277)

6. Diagnose by the sound.
 - ★“ pi ” : The both numbers of tens and units do not accord with the error code.
 - ★“ pi pi ” : The number of tens accords with the error code.
 - ★“ beep ” : The both numbers of tens and units accord with the error code.
7. Determine the error code.
The digits indicated when you hear the “beep” sound are error code.
(Error codes and description → Refer to page 101.)
8. Exit from the diagnosis mode.
Press the MODE button.



(R4278)

4. Troubleshooting

4.1 Error Codes and Description

	Code Indication	Description	Reference Page
System	<i>00</i>	Normal	—
	<i>U0</i> ★	Insufficient gas	127
	<i>U2</i>	Over-voltage detection	129
	<i>U4</i>	Signal transmission error (between indoor and outdoor unit)	107
Indoor Unit	<i>R1</i>	Indoor unit PCB abnormality	102
	<i>R5</i>	Freeze-up protection control or high pressure control	103
	<i>R6</i>	Fan motor or related abnormality	105
	<i>C4</i>	Heat exchanger temperature thermistor abnormality	106
	<i>C9</i>	Room temperature thermistor abnormality	106
Outdoor Unit	<i>E5</i> ★	OL activation (compressor overload)	108
	<i>E6</i> ★	Compressor lock	109
	<i>E7</i>	DC fan lock	110
	<i>E8</i>	Input over current detection	111
	<i>ER</i>	Four way valve abnormality	112
	<i>F3</i>	Discharge pipe temperature control	114
	<i>F6</i>	High pressure control in cooling	115
	<i>H5</i>	Position sensor abnormality	117
	<i>H8</i>	DC voltage/current sensor abnormality	118
	<i>H9</i>	Outdoor air thermistor or related abnormality	119
	<i>J3</i>	Discharge pipe temperature thermistor or related abnormality	119
	<i>J5</i>	Heat exchanger temperature thermistor or related abnormality	119
	<i>L3</i>	Electrical box temperature rise	121
	<i>L4</i>	Radiation fin temperature rise	123
	<i>L5</i>	Output over current detection	125
	<i>P4</i>	Heat radiation fin thermistor or related abnormality	119

★: Displayed only when system-down occurs.

4.2 Indoor Unit PCB Abnormality


Remote Control Display *R1*

Method of Malfunction Detection Evaluation of zero-cross detection of power supply by indoor unit.


Malfunction Decision Conditions When there is no zero-cross detection in approximately 10 continuous seconds.

- Supposed Causes**
- Faulty indoor unit PCB
 - Faulty connector connection

Troubleshooting



(R1400)

 **Note:** Connector Nos. vary depending on models.

Model Type	Connector No.
Wall Mounted Type 20 / 25 / 35 class	Terminal strip~Control PCB

4.3 Freeze-up Protection Control or High Pressure Control

Remote Control
Display

RS

**Method of
Malfunction
Detection**

- High pressure control (heat pump model only)
During heating operations, the temperature detected by the indoor heat exchanger thermistor is used for the high pressure control (stop, outdoor fan stop, etc.)
- Freeze-up protection control (operation halt) is activated during cooling operation according to the temperature detected by the indoor unit heat exchanger thermistor.

**Malfunction
Decision
Conditions**

- High pressure control
During heating operations, the temperature detected by the indoor heat exchanger thermistor is above 65°C
- Freeze-up protection
When the indoor unit heat exchanger temperature is below 0°C during cooling operation.

**Supposed
Causes**

- Operation halt due to clogged air filter of the indoor unit.
- Operation halt due to dust accumulation on the indoor unit heat exchanger.
- Operation halt due to short-circuit.
- Detection error due to faulty indoor unit heat exchanger thermistor.
- Detection error due to faulty indoor unit PCB.

Troubleshooting




Check No.6
Refer to P.132



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



4.4 Fan Motor (AC Motor) or Related Abnormality

Remote Control Display *AB*

Method of Malfunction Detection
The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor operation.

Malfunction Decision Conditions
When the detected rotation speed is less than 50% of the HH tap under maximum fan motor rotation demand.

- Supposed Causes**
- Operation halt due to short circuit inside the fan motor winding.
 - Operation halt due to breaking of wire inside the fan motor.
 - Operation halt due to breaking of the fan motor lead wires.
 - Operation halt due to faulty capacitor of the fan motor.
 - Detection error due to faulty indoor unit PCB.

Troubleshooting




Check No.16
Refer to P.137



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R4096)

4.5 Thermistor or Related Abnormality (Indoor Unit)

Remote Control Display **Ⓒ4,Ⓒ9**

Method of Malfunction Detection

The temperatures detected by the thermistors are used to determine thermistor errors.

Malfunction Decision Conditions

When the thermistor input is more than 4.96 V or less than 0.04 V during compressor operation*.
 * (reference)
 When above about 212°C (less than 120 ohms) or below about -50°C (more than 1,860 kohms).


Note: The values vary slightly in some models.

Supposed Causes

- Faulty connector connection
- Faulty thermistor
- Faulty PCB

Troubleshooting

Check No.6
 Refer to P.132



Ⓒ : Heat exchanger thermistor
 Ⓒ9 : Room temperature thermistor

4.6 Signal Transmission Error (between Indoor and Outdoor Unit)

Remote Control
Display

U4

Method of
Malfunction
Detection

The data received from the outdoor unit in indoor unit-outdoor unit signal transmission is checked whether it is normal.

Malfunction
Decision
Conditions

When the data sent from the outdoor unit cannot be received normally, or when the content of the data is abnormal.


Supposed
Causes

- Faulty outdoor unit PCB.
- Faulty indoor unit PCB.
- Indoor unit-outdoor unit signal transmission error due to wiring error.
- Indoor unit-outdoor unit signal transmission error due to disturbed power supply waveform.
- Indoor unit-outdoor unit signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units (wire No. 2).

Troubleshooting



Check No.10
Refer to P.135



4.7 OL Activation (Compressor Overload)

Remote Control Display *ES*

Method of Malfunction Detection
A compressor overload is detected through compressor OL.

Malfunction Decision Conditions

- If the compressor OL is activated twice, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

* The operating temperature condition is not specified.

Supposed Causes

- Refrigerant shortage
- Four way valve malfunctioning
- Outdoor unit PCB defective
- Water mixed in the local piping
- Electronic expansion valve defective
- Stop valve defective


Troubleshooting


Check No.4
Refer to P.130


Check No.5
Refer to P.131


Check No.6
Refer to P.132


Check No.11
Refer to P.135



4.8 Compressor Lock

Remote Control
Display

EE

Method of
Malfunction
Detection

A compressor lock is detected by checking the compressor running condition through the position detection circuit.


Malfunction
Decision
Conditions

- The system judges the compressor lock, and stops due to over current.
- The system judges the compressor lock, and cannot operation with position detection within 15 seconds after start up.
- The system will be shut down if the error occurs 16 times.
- Clearing condition: Continuous run for about 10 minutes (normal)

Supposed
Causes

- Compressor locked
- Compressor harness disconnected

Troubleshooting



(R2842)



Note: If the model doesn't have SPM, replace the outdoor unit PCB.

4.9 DC Fan Lock

Remote Control Display *E7*


Method of Malfunction Detection A fan motor or related error is detected by checking the high-voltage fan motor rpm being detected by the Hall IC.

- Malfunction Decision Conditions**
- The fan does not start in 30 seconds even when the fan motor is running.
 - The system will be shut down if the error occurs 16 times.
 - Clearing condition: Continuous run for about 5 minutes (normal)

- Supposed Causes**
- Fan motor breakdown
 - Harness or connector disconnected between fan motor and PCB or in poor contact
 - Foreign matters stuck in the fan

Troubleshooting


Check No.15
 Refer to P.136



4.10 Input Over Current Detection

Remote Control
Display

EE

Method of
Malfunction
Detection

An input over-current is detected by checking the input current value with the compressor running.

Malfunction
Decision
Conditions

- The following current with the compressor running continues for 2.5 seconds.
Cooling / Heating: Above 12A

Supposed
Causes

- Over-current due to compressor failure
- Over-current due to defective power transistor
- Over-current due to defective outdoor unit PCB
- Error detection due to outdoor unit PCB
- Over-current due to short-circuit

Troubleshooting



Check No.7
Refer to P.133




Check No.8
Refer to P.133



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

* An input over-current may result from wrong internal wiring. If the wires have been disconnected and reconnected for part replacement, for example, and the system is interrupted by an input over-current, take the following procedure.



(R2952)



Note: If the model doesn't have SPM, replace the outdoor unit PCB.

4.11 Four Way Valve Abnormality

Remote Control
Display

ER

**Method of
Malfunction
Detection**

The indoor air temperature thermistor, the indoor unit heat exchanger thermistor, the outdoor temperature thermistor and the outdoor unit heat exchanger thermistor are checked to see if they function within their normal ranges in the operating mode.

**Malfunction
Decision
Conditions**

A following condition continues over 10 minute after operating 5 minutes.

- Cooling / dry operation
(room temp. – indoor heat exchanger temp.) < –5°C
 - Heating
(indoor unit heat exchanger temp. – room temp.) < –5°C
-

**Supposed
Causes**

- Connector in poor contact
- Thermistor defective
- Outdoor unit PCB defective
- Four way valve coil or harness defective
- Four way valve defective
- Foreign substance mixed in refrigerant
- Insufficient gas

Troubleshooting



Check No.5
Refer to P.131




Check No.6
Refer to P.132



Check No.11
Refer to P.135



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R3040)

4.12 Discharge Pipe Temperature Control

Remote Control Display **F3**

Method of Malfunction Detection The discharge pipe temperature control (stop, frequency drooping, etc.) is checked with the temperature being detected by the discharge pipe thermistor.




- Malfunction Decision Conditions**
- If a stop takes place 4 times successively due to abnormal discharge pipe temperature, the system will be shut down.
 - If the temperature being detected by the discharge pipe thermistor rises above $\text{A } ^\circ\text{C}$, the compressor will stop. (The error is cleared when the temperature has dropped below $\text{B } ^\circ\text{C}$.)


Stop temperatures	A	B	
		ARK(X)S	(A)RK(X)H, R(Y)N
(1) above 45Hz (rising), above 40Hz (dropping)	110	97	85
(2) 30~45Hz (rising), 25~40Hz (dropping)	105	92	80
(3) below 30Hz (rising), below 25Hz (dropping)	99	86	74

- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

- Supposed Causes**
- Refrigerant shortage
 - Four way valve malfunctioning
 - Discharge pipe thermistor defective (heat exchanger or outdoor air temperature thermistor defective)
 - Outdoor unit PCB defective
 - Water mixed in the local piping
 - Electronic expansion valve defective
 - Stop valve defective

Troubleshooting

-  **Check No.4**
Refer to P.130
-  **Check No.6**
Refer to P.132
-  **Check No.11**
Refer to P.135



4.13 High Pressure Control in Cooling

Remote Control
Display

FB

Method of
Malfunction
Detection

High-pressure control (stop, frequency drop, etc.) is activated in the cooling mode if the temperature being sensed by the heat exchanger thermistor exceeds the limit.

Malfunction
Decision
Conditions

Activated when the temperature being sensed by the heat exchanger thermistor rises above 65°C. (The error is cleared when the temperature drops below 54°C.)

Supposed
Causes

- The installation space is not large enough.
- Faulty outdoor unit fan
- Faulty electronic expansion valve
- Faulty defrost thermistor
- Faulty outdoor unit PCB
- Faulty stop valve
- Dirty heat exchanger

Troubleshooting



Check No.4
Refer to P.130



Check No.6
Refer to P.132



Check No.7
Refer to P.133




Check No.9
Refer to P.134



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.




(R2855)

4.14 Position Sensor Abnormality

<p>Remote Control Display</p>	<p><i>HE</i></p>
<p>Method of Malfunction Detection</p>	<p>A compressor startup failure is detected by checking the compressor running condition through the position detection circuit.</p>
<p>Malfunction Decision Conditions</p>	<ul style="list-style-type: none"> ■ The compressor fails to start in about 15 seconds after the compressor run command signal is sent. ■ Clearing condition: Continuous run for about 10 minutes (normal) ■ The system will be shut down if the error occurs 16 times.
<p>Supposed Causes</p>	<ul style="list-style-type: none"> ■ Compressor relay cable disconnected ■ Compressor itself defective ■ Outdoor unit PCB defective ■ Stop valve closed ■ Input voltage out of specification

Troubleshooting

 **Check No.13**
Refer to P.136



4.15 DC Voltage / Current Sensor Abnormality

Remote Control
Display

H8

**Method of
Malfunction
Detection**

Detecting abnormality of the DC sensor by the running frequency of compressor and by the input current multiplied DC voltage and current.

**Malfunction
Decision
Conditions**

The compressor running frequency is below 52 Hz.
(The input current is also below 0.5 A.)

- If this error repeats 4 times, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

**Supposed
Causes**

- Outdoor unit PCB defective

Troubleshooting



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Replace the outdoor unit PCB.

4.16 Thermistor or Related Abnormality (Outdoor Unit)

Remote Control
Display

P4, J3, J6, H9

**Method of
Malfunction
Detection**

This type of error is detected by checking the thermistor input voltage to the microcomputer.
[A thermistor error is detected by checking the temperature.]

**Malfunction
Decision
Conditions**

The thermistor input is above 4.96 V or below 0.04 V with the power on.
Error *J3* is judged if the discharge pipe thermistor temperature is smaller than the condenser thermistor temperature.


**Supposed
Causes**

- Connector in poor contact
- Thermistor defective
- Outdoor unit PCB defective
- Indoor unit PCB defective
- Condenser thermistor defective in the case of *J3* error (outdoor unit heat exchanger thermistor in the cooling mode, or indoor unit heat exchanger thermistor in the heating mode)

Troubleshooting



Check No.6
Refer to P.132



(R4097)

- P4 : Radiation fin thermistor
- J3 : Discharge pipe thermistor
- J5 : Outdoor heat exchanger thermistor
- H9 : Outdoor air temperature thermistor

4.17 Electrical Box Temperature Rise

Remote Control
Display

L3

Method of
Malfunction
Detection

An electrical box temperature rise is detected by checking the radiation fin thermistor with the compressor off.

Malfunction
Decision
Conditions

With the compressor off, the radiation fin temperature is above 80°C(90°C★). Reset is made when the temperature drops below 70°C(80°C★).

★: value for (A)RK(X)H, R(Y)N models

Supposed
Causes

- Fin temperature rise due to defective outdoor unit fan
- Fin temperature rise due to short-circuit
- Fin thermistor defective
- Connector in poor contact
- Outdoor unit PCB defective

Troubleshooting




Check No.6
Refer to P.132



Check No.7
Refer to P.133



Check No.9
Refer to P.134



★: value for (A)RK(X)H, R(Y)N models

(R4016)

4.18 Radiation Fin Temperature Rise

Remote Control
Display

L4

**Method of
Malfunction
Detection**

A radiation fin temperature rise is detected by checking the radiation fin thermistor with the compressor on.

**Malfunction
Decision
Conditions**

If the radiation fin temperature with the compressor on is above 90°C (100°C for (A)RK(X)H, R(Y)N models).

- If a radiation fin temperature rise takes place 4 times successively, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

**Supposed
Causes**

- Fin temperature rise due to defective outdoor unit fan
- Fin temperature rise due to short-circuit
- Fin thermistor defective
- Connector in poor contact
- Outdoor unit PCB defective

Troubleshooting



Check No.6
Refer to P.132



Check No.7
Refer to P.133




Check No.9
Refer to P.134



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Turn off the power and turn it on again to get the system started.



★: value for (A)RK(X)H, R(Y)N models

(R4017)

4.19 Output Over Current Detection

Remote Control
Display

L5

**Method of
Malfunction
Detection**

An output over-current is detected by checking the current that flows in the inverter DC section.

**Malfunction
Decision
Conditions**

- A position signal error occurs while the compressor is running.
 - A speed error occurs while the compressor is running.
 - An output over-current input is fed from the output over-current detection circuit to the microcomputer.
 - The system will be shut down if the error occurs 255 times.
 - Clearing condition: Continuous run for about 10 minutes (normal)
-

**Supposed
Causes**

- Over-current due to defective power transistor
- Over-current due to wrong internal wiring
- Over-current due to abnormal supply voltage
- Over-current due to defective PCB
- Error detection due to defective PCB
- Over-current due to closed stop valve
- Over-current due to compressor failure
- Over-current due to poor installation condition

Troubleshooting



Check No.7
Refer to P.133



Check No.8
Refer to P.133




Check No.13
Refer to P.136



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

* An output over-current may result from wrong internal wiring. If the wires have been disconnected and reconnected for part replacement, for example, and the system is interrupted by an output over-current, take the following procedure.



Note: If the model doesn't have SPM, replace the outdoor unit PCB.

(R2852)

4.20 Insufficient Gas

Remote Control
Display

U0

Method of
Malfunction
Detection

Gas shortage detection I : A gas shortage is detected by checking the compressor running frequency.

Gas shortage detection II : A gas shortage is detected by checking the difference between indoor unit heat exchanger temperature and room temperature as well as the difference between outdoor unit heat exchanger temperature and room temperature.

Gas shortage detection III : A gas shortage is detected by checking the difference between inhale and exhale temperature.

Malfunction
Decision
Conditions

Gas shortage detection I :

DC current × DC voltage < A (A/Hz) × Compressor running frequency + B

However, when the status of running frequency > C (Hz) is kept on for a certain time.

Note : The values are different from model to model.

	A	B	C
ARK(X)S models	640 / 256	0	55
(A)RK(X)H, R(Y)N models	640 / 256	50	55

Gas shortage detection II :

If a gas shortage error takes place 4 times successively, the system will be shut down. The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Gas shortage detection III :

When the difference of the temperature is smaller than A , it is regarded as insufficient gas.

		A
Cooling	room temperature – indoor heat exchanger temperature	4.0°C
	outdoor heat exchanger temperature – outdoor temperature	4.0°C
Heating	indoor heat exchanger temperature – room temperature	4.0°C
	outdoor temperature – outdoor heat exchanger temperature	3.0°C

Supposed
Causes

- Refrigerant shortage (refrigerant leakage)
- Poor compression performance of compressor
- Discharge pipe thermistor disconnected, or indoor unit or outdoor unit heat exchanger thermistor disconnected, room or outdoor air temperature thermistor disconnected
- Stop valve closed
- Electronic expansion valve defective

Troubleshooting




Check No.4
Refer to P.130



Check No.6
Refer to P.132



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R3318)

4.21 Over-voltage Detection

Remote Control
Display

U2

Method of
Malfunction
Detection

An abnormal voltage rise is detected by checking the specified over-voltage detection circuit.


Malfunction
Decision
Conditions

- An over-voltage signal is fed from the over-voltage detection circuit to the microcomputer (The voltage is over 400V).
- The system will be shut down if the error occurs 255 times.
- Clearing condition: Continuous run for about 10 minutes (normal)

Supposed
Causes

- Supply voltage not as specified
- Over-voltage detection circuit defective
- PAM control part(s) defective

Troubleshooting



(R2957)



Note: If the model doesn't have SPM, replace the outdoor unit PCB.

5. Check


5.1 How to Check

5.1.1 Electronic Expansion Valve Check

Check No.4

Conduct the followings to check the electronic expansion valve (EV).

1. Check to see if the EV connector is correctly inserted in the PCB. Compare the EV unit and the connector number.
2. Turn the power off and back on again, and check to see if all the EVs generate latching sound.
3. If any of the EVs does not generate latching noise in the above step 2, disconnect that connector and check the conductivity using a tester.
Check the conductivity between pins 1, 3 and 6, and between pins 2, 4 and 5. If there is no conductivity between the pins, the EV coil is faulty.





4. If no EV generates latching sound in the above step 2, the outdoor unit PCB is faulty.
5. If the conductivity is confirmed in the above step 2, mount a good coil (which generated latching sound) in the EV unit that did not generate latching sound, and check to see if that EV generates latching sound.
 - *If latching sound is generated, the outdoor unit PCB is faulty.
 - *If latching sound is not generated, the EV unit is faulty.



Note: Please note that the latching sound varies depending on the valve type.

5.1.2 Four Way Valve Performance Check

Check No.5



(R3047)


5.1.3 Thermistor Resistance Check

Check No.6


Remove the connectors of the thermistors on the PCB, and measure the resistance of each thermistor using tester.

The relationship between normal temperature and resistance is shown in the graph and the table below.

Temperature (°C)	Thermistor R25°C=20kΩ B=3950
-20	211.0 (kΩ)
-15	150
-10	116.5
-5	88
0	67.2
5	51.9
10	40
15	31.8
20	25
25	20
30	16
35	13
40	10.6
45	8.7
50	7.2




(R25 = 20kΩ, B = 3950)



(R1437)


5.1.4 Installation Condition Check

Check No.7



5.1.5 Discharge Pressure Check


Check No.8



5.1.6 Outdoor Unit Fan System Check


Check No.9

DC motor — ARK(X)S models



(R2857)

AC motor — (A)RK(X)H, R(Y)N models



(R2670)

5.1.7 Power Supply Waveforms Check



Check No.10

Measure the power supply waveform between pins 1 and 3 on the terminal board, and check the waveform disturbance.

- Check to see if the power supply waveform is a sine wave (Fig.1).
- Check to see if there is waveform disturbance near the zero cross (sections circled in Fig.2)

[Fig.1]

[Fig.2]




(R1736)

(R1444)

5.1.8 Inverter Units Refrigerant System Check

Check No.11



(R1445)

5.1.9 Power Transistor Check

Check No.13



Note: Check to make sure that the voltage between the terminal of Power transistor (+) and (-) is approx. 0 volt before checking power transistor.

< Measuring method >

Disconnect the compressor harness connector from the outdoor unit PCB. To disengage the connector, press the protrusion on the connector.

Then, follow the procedure below to measure resistance between power transistor (+) and (-) and the U, V and W terminals of the compressor connector with a multi-tester. Evaluate the measurement results for a pass/fail judgment.

<Power transistor check>

Negative (-) terminal of tester (positive terminal (+) for digital tester)	Power transistor (+)	UVW	Power transistor (-)	UVW
Positive (+) terminal of tester (negative terminal (-) for digital tester)	UVW	Power transistor (+)	UVW	Power transistor (-)
Normal resistance	Several kΩ to several MΩ (*)			
Unacceptable resistance	Short (0 Ω) or open			

5.1.10 Turning Speed Pulse Input on the Outdoor Unit PCB Check

Check No.15

<Propeller fan motor>


Make sure the voltage of 270±30V is being applied.

- (1) Stop the operation first and then the power off, and disconnect the connector S70.
- (2) Make sure there is about DC 270 V between pins 4 and 7.
- (3) With the system and the power still off, reconnect the connector S70.
- (4) Make a turn of the fan motor with a hand, and make sure the pulse (0-15 V) appears twice at pins 1 and 4.

If the fuse is blown out, the outdoor-unit fan may also be in trouble. Check the fan too.

If the voltage in Step (2) is not applied, it means the PCB is defective. Replace the PCB.

If the pulse in Step (4) is not available, it means the Hall IC is defective. Replace the DC fan motor. If there are both the voltage (2) and the pulse (4), replace the PCB.



(R2859)

* Propeller fan motor : S70

5.1.11 Hall IC Check


Check No.16

1. Check the connector connection.
2. With the power ON, operation OFF, and the connector connected, check the following.
 - *Output voltage of about 5 V between pins 1 and 3.
 - *Generation of 3 pulses between pins 2 and 3 when the fan motor is operating.

Failure of (1) → faulty PCB → Replace the PCB.

Failure of (2) → faulty Hall IC → Replace the fan motor.

Both (1) and (2) result → Replace the PCB.



(R1968)

Part 7

Removal Procedure

1. Indoor Unit.....	140
1.1 Removal of Air Filter	140
1.2 Removal of Front Grille	143
1.3 Removal of Horizontal Blade and Vertical Blade.....	146
1.4 Removal of Switch Box, PC Board and Swing Motor	148
1.5 Removal of Heat Exchanger	154
1.6 Install of Drain Plug	157
1.7 Removal of Fan Rotor and Fan Motor.....	158
2. Outdoor Unit / ARK(X)S-C	162
2.1 Removal of Panels and Fan Motor	162
2.2 Removal of Electrical Box	169
2.3 Removal of Reactor and Partition Plate	171
2.4 Removal of Sound Blanket.....	173
2.5 Removal of Four Way Valve.....	175
2.6 Removal of Compressor.....	177
2.7 Removal of PCB.....	179
3. Outdoor Unit / RK(X)H-C, ARK(X)H-C, R(Y)N-C	182
3.1 Removal of External Panels	182
3.2 Removal of Bell Mouth	185
3.3 Removal of PCB.....	186
3.4 Removal of Electrical Box	194
3.5 Removal of Propeller Fan and Fan Motor	197
3.6 Removal of Compressor Sound Insulation Pad	200
3.7 Removal of Compressor.....	209
3.8 Removal of Four Way Valve.....	212
3.9 Removal of Electronic Expansion Valve.....	215

1. Indoor Unit

1.1 Removal of Air Filter



Procedure




Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. External features		<ul style="list-style-type: none"> ■ If ON/OFF button is kept pushing for 5 seconds, a forced cooling operation will be carried out for approx. 15 minutes.
2. Removing air filters	<p>1 Pull protrusions on left and right sides of panel with fingers and open front grille all the way.</p>	
<p>2 Lift center section of air filter and disengage hooks. Remove air filter by pulling forward.</p>		<ul style="list-style-type: none"> ■ Left and right filters are interchangeable. ■ To re-install, insert air filter along the guide.

Step	Procedure	Points
<p>3. Opening and shutting front panel</p>		
<p>1</p>	<p>Hook a finger onto the projection part provided on the both sides of the unit's panel and open up the panel to the position higher than it will stop.</p>  <p>Rotation axis</p>	<p>Support the front panel by one hand, while remove the rotation axis at the upper center by the other hand.</p> <ul style="list-style-type: none"> ■ And pull out the front panel forward to remove.
<p>2</p>	<p>Remove front panel from the unit.</p>  <p>Slide the center rotary axis the left and remove it out.</p>	<p>(R2512)</p> <p>(R2513)</p>

Step	Procedure	Points
3	<p>When restoring the air filter, make sure that the projection parts on the panel are in the guide groove, and then shut the panel.</p> 	



1.2 Removal of Front Grille




Procedure





Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Opening and closing of service cover	 <p style="text-align: right;">(R2515)</p>  <p style="text-align: right;">(R2516)</p>	<ul style="list-style-type: none"> ■ A switch for field setting is not provided in particular.

Step	Procedure	Points
<p>2. Removal of front grille assembly.</p> <p>1</p> <p>Remove the two screws, in the right and the left, which fix the main body with the front grille.</p> <p>2</p> <p>Disengage the two hooks on the upper part. In case that the hooks are not pressed from above, remove the front panel and then remove the grille while pushing the hook through a clearance between the front grille and the heat exchanger.</p>	 <p>(R2517)</p>  <p>(R2518)</p>  <p>Front grille</p> <p>Hook</p> <p>(R2519)</p>	<ul style="list-style-type: none"> ■ Screw stoppers inside the flap which were equipped in the existing models are not provided. ■ At the upper part there are two hooks in the left and the right. ■ Disengage the hooks by pressing knobs with a screwdriver.

Step	Procedure	Points
3	The front grille can be removed in a manner to pull out the upper part forward and lift up the lower part.	■ When restoring the grille, Make sure whether each hook is set as it was.






1.3 Removal of Horizontal Blade and Vertical Blade




Procedure



Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points	
1. Remove horizontal blade.			
1	Lift horizontal blade to open position.  (R2522)	<ul style="list-style-type: none"> ■ Screw stoppers inside the flap which were equipped in the existing models are not provided. 	
2	Disengage horizontal blade from blade retaining section.  (R2523)		
3	Bend blade slightly and remove it from the unit.  (R2524)		

Step	Procedure	Points
	 <p style="text-align: right;">(R2525)</p>	<ul style="list-style-type: none"> ■ For restoring. 1. Since the key pattern hook is provided on the left side, insert the edge of the blade to the tip while rotating it. 2. Restore the two fixed parts of the horizontal blade onto the hook.
<p>2. Removal of vertical blade</p> <p>1</p> <p>2</p>	<p>Disengage the vertical blade's joint from the fixed plate.</p>  <p style="text-align: right;">(R2526)</p> <p>Fixed plate</p>  <p style="text-align: right;">(R2527)</p>	<ul style="list-style-type: none"> ■ Five vertical blades are integrated with the joint rod. (so, only one blade can't be exchanged.)

1.4 Removal of Switch Box, PC Board and Swing Motor



Procedure




Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.




Step	Procedure	Points
<p>■ Remove front grill.</p>		
<p>1. Remove switch box.</p> <p>1 Disconnect the connection wires.</p> <p>2 Disconnect connectors (S1 and S7) of fan motor.</p> <p>3 Disconnect one connector (S6) of swing motor.</p> <p>4 Remove heat exchanger thermistor.</p>		<p>■ Pay attention to the direction of the retainer of the thermistor so that the retainer will not touch the harness (same as the existing models.)</p>




Step	Procedure	Procedure	Points
5	Remove a screw on the terminal strip.	 <p>(R2531)</p>	<ul style="list-style-type: none">■ The switch box can be removed instead of disengaging the terminal strip.
6	Remove a screw on the switch box.	 <p>(R2532)</p>	

Step	Procedure	Points
7	Pull up the switch box forward to remove.	<ul style="list-style-type: none"> ■ A hook is provided on the behind.



(R2533)

Step	Procedure	Points
2. Removal of PCB		
1 Remove the shelter.		
2 Disengage the front plate of the switch box. Disengage the knobs by pushing the two hooks at the top and the bottom.		
3 Sliding to the left, the front part of the switch box can be removed.		

Step	Procedure	Points
4	<p>Disengage the four knobs on the back of the display PCB.</p>  <p>PC Board</p> <p>(R2538)</p>	
5	<p>Display PCB.</p>  <p>Knob</p> <p>(R2539)</p>  <p>SW7 ON/OFF button</p> <p>LED1 (Green)</p> <p>LED2 (Yellow)</p> <p>LED3 (Red)</p> <p>S26</p> <p>S27</p> <p>Thermistor</p> <p>S35</p> <p>S36</p> <p>Intelligent eye sensor PCB (R2540)</p>	<ul style="list-style-type: none"> LED3 and Intelligent eye sensor PCB are only for inverter models.

Step	Procedure	Points
6	<p>Control PCB.</p> <p>Glass tabu fuse 3.15A 250V</p> <p>S21 (HA terminal)</p> <p>S7(Fan motor)</p> <p>S6(Swing motor)</p> <p>JA (Address)</p> <p>JB</p> <p>JC</p> <p>S32 (Heat exchanger thermistor)</p> <p>(R2541)</p>	<ul style="list-style-type: none"> The control PCB is integrated with the power supply PCB.
3.	<p>Remove swing motor assembly.</p>	
1	<p>To remove swing motor assembly, remove two screws. (Manual adjusting for the vertical blades.)</p> <p>(R2542)</p> <p>Swing motor (R2543)</p>	<ul style="list-style-type: none"> Provide a supporter so that the joint link will not drop off, in case the horizontal blade assembly is removed.



1.5 Removal of Heat Exchanger






Procedure




Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none"> ■ Conduct pump-down operation. ■ Remove the installation frame from the mounting plate. 		
<p>1 Remove the drain hose. Make curing so that the residual drain water will not leak out.</p>	 <p style="text-align: right;">(R2544)</p>	<p>Warning If gas leaks, repair the leak location, then connect all refrigerant from the unit. Conduct vacuum drying, and charge proper amount of refrigerant.</p> <p>Warning Do not mix any gas (including air) other than the specified refrigerant (R-410A) into refrigerating cycle. (Mixing of air or other gas causes abnormal temperature rise in refrigerating cycle, and this results in pipe rupture or personal injuries.)</p> <ul style="list-style-type: none"> ■ Pay attention so that the residual drain will not make a floor dirty. ■ In case that a drain hose is buried inside a wall, remove it after the drain hose in the wall is pulled out.
<p>2 Disengage the insulation tube and disconnect the flare nuts for the gas line and the liquid line.</p> <p>3 Disengage the indoor unit from the installation plate.</p>	 <p style="text-align: right;">(R2545)</p>	<ul style="list-style-type: none"> ■ Use two wrenches to disconnect pipe. ■ After pipes are disconnected, close all pipe openings with caps to prevent dust and moisture from entering pipes.

Step		Procedure	Points
4	Disengage the hooks of the pipe retainer on the back.	 <p>(R2546)</p>  <p>Pipe retainer (R2547)</p>	
5	Pull auxiliary pipe forward to an angle of 10 to 20 degrees.	 <p>(R2548)</p>	<ul style="list-style-type: none"> ■ Be careful to prevent pipe deformation.
6	Disengage hooks located right and left side, and pull heat exchanger forward. The hooks are symmetrically placed in the right and the left.	<p>This hook is located both side of heat exchanger. Press this hook to remove heat exchanger easily.</p>  <p>(R2549)</p>  <p>(R2550)</p>	<ul style="list-style-type: none"> ■ Lifting the heat-exchanger slightly upward to the right, the left hook comes to be disengaged easily.

Step	Procedure	Points
7	Lift and remove heat exchanger.	 <p data-bbox="1098 226 1465 477">Caution When removing or re-installing heat exchanger, be sure to wear protective gloves or wrap heat exchanger with cloths. (Fins can cut fingers.)</p>

1.6 Install of Drain Plug

Procedure



Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Procedure	Points
1	Disconnect drain hose.	<p>(R2552)</p>	<ul style="list-style-type: none"> ■ The drain pan is integrated with the bottom plate.
2	Pull out the drain plug in the left on the drain pan by hand.	<p>Drain plug</p> <p>(R2553)</p>	
3	Insert the drain hose,	<p>(R2554)</p>	<ul style="list-style-type: none"> ■ Push it into the inner part firmly.
4	Push the drain plug into the right by Allen wrench.	<p>Allen wrench (4 mm)</p> <p>(R2555)</p>	<ul style="list-style-type: none"> ■ Push it into the inner part firmly.

1.7 Removal of Fan Rotor and Fan Motor




Procedure





Warning




Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<p>■ Remove heat exchanger.</p>	<p>(R2556)</p>	
<p>1 To remove right side panel, remove three screws.</p>	<p>Right-side plate</p> <p>(R2557)</p>	

Step		Procedure	Points
2	Disengage hook.	 <p>(R2558)</p>  <p>(R2559)</p>	
3	Loosen the hexagon head set screw on the fan rotor.	 <p>(R2560)</p>	

Step	Procedure	Points
4	Remove the motor and fan rotor.	
5	Remove a screw on the left side panel.	



Step	Procedure	Points
6	Disengage a hook from the backward.	
	 <p>(R2563)</p>	
	 <p>Left-side plate</p> <p>(R2564)</p>	
7	Since the fan bearing is made of rubber, push it strongly off from the inside. The bearing can be removed just as the left-side plate is attached with.	
	 <p>Bearing</p> <p>(R2565)</p>	

2. Outdoor Unit / ARK(X)S-C





2.1 Removal of Panels and Fan Motor




Procedure










Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.




Step	Procedure	Points
<p>1. Features</p> <p>1 Loosen the screw of the stop valve cover. Pull down the stop valve cover and remove it.</p>	<p>(R3235)</p> <p>Outdoor air thermistor</p> <p>(R3236)</p> <p>Stop valve cover</p> <p>(R3237)</p> <p>Shelter</p> <p>Hooks</p> <p>(R3238)</p>	<ul style="list-style-type: none"> ■ Take care not to cut your finger by the fins of the heat exchanger. ■ The stop valve cover is united with the shelter. ■ When reassembling, make sure to fit the 5 hooks.



Step	Procedure	Points
2. Remove the panels.		
1 Loosen the 3 screws (front, right, left) and lift the top panel.	 <p>Top panel</p> <p>(R3239)</p>	
2 Remove the drip proof plate.	 <p>Drip proof plate</p> <p>(R3240)</p>	
3 Disconnect the connector for fan motor (S70).	 <p>S70</p> <p>(R3241)</p>	<p>■ The fan motor is united with the front panel.</p>
4 Loosen the 5 screws of the front panel.	 <p>Front panel</p> <p>(R3242)</p>	

Step	Procedure	Points
5	<p data-bbox="199 212 430 309">Undo the hooks. Pull and remove the front panel.</p> 	<ul style="list-style-type: none"> ■ The front panel has 4 hooks. ■ The fan motor is united with the front panel.
3.	<p data-bbox="135 840 430 869">Remove the fan motor.</p> <p data-bbox="151 878 443 1003">1 Unscrew the washer-fitted nut (M10) of the propeller fan with a spanner.</p>  <p data-bbox="151 1303 443 1361">2 Remove the propeller fan.</p> 	<ul style="list-style-type: none"> ■ The screw has reverse winding. ■ Align ▼ mark of the propeller fan with D-cut section of the motor shaft when reassembling.

Step	Procedure	Points
<p>3</p> <p>Loosen the 2 screws and lift the bell mouth to undo the hooks. Remove the bell mouth.</p>	 <p>Bell mouth</p> <p>Hooks</p> <p>(R3246)</p>  <p>(R3247)</p>	
<p>4</p> <p>Loosen the fixing hooks and release the lead wire.</p>	 <p>(R3248)</p>	<ul style="list-style-type: none"> Put the lead wire through the back of the motor when reassembling. (so as not to be entangled with the propeller fan)  <p>Lead wire</p> <p>Propeller fan</p> <p>(R3249)</p>

Step	Procedure	Points
5	<p>Loosen the 4 screws to remove the fan motor.</p>  <p>Fan motor (R3250)</p>	<ul style="list-style-type: none"> ■ M4x16 ■ DC fan motor
6	<p>Loosen the 2 screws to remove the fan motor fixing frame.</p>  <p>Fan motor fixing frame (R3251)</p>  <p>(R3252)</p>	

Step	Procedure	Points
4. Remove the right side panel.	 <p>(R3253)</p>	
1 Loosen the 2 screws on the rear side.	 <p>Right side panel</p> <p>(R3254)</p>	
2 Loosen the 3 screws on the right side.	 <p>(R3255)</p>	
3 Loosen the screw and lift the connection port to remove.		

Step	Procedure	Points
	 <p>(R3256)</p>  <p>Hook</p> <p>(R3257)</p>	<ul style="list-style-type: none"> ■ When reassembling, make sure to fit the hook.






2.2 Removal of Electrical Box

Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none"> ■ Remove the top panel. ■ Disconnect the connector for fan motor. 	<p style="text-align: right;">(R3258)</p>	
<p>1. Remove the electrical box.</p>		
<p>1 Disconnect the 2 reactor harnesses.</p>	<p style="text-align: right;">(R3259)</p>	
<p>2 Disconnect the relay connector for compressor lead wire.</p>	<p style="text-align: right;">(R3260)</p>	
<p>3 Disconnect the connector for four way valve (S80).</p>	<p style="text-align: right;">(R3260)</p>	<ul style="list-style-type: none"> ■ When reassembling, coil the excessive lead wire and hang off the hook.




Step		Procedure	Points
4	Release the discharge pipe thermistor.	 <p>Discharge pipe thermistor (R3261)</p>	<ul style="list-style-type: none"> ■ Pay attention so as not to lose the clip for thermistor.  <p>Thermistor Piping Clip (R3262)</p>
5	Release the heat exchanger thermistor.	 <p>Heat exchanger thermistor (R3263)</p>	<ul style="list-style-type: none"> ■ Pay attention so as not to lose the clip.  <p>Clip (R3264)</p>
6	Lift and remove the electrical box.	 <p>Electrical box (R3265)</p>	



2.3 Removal of Reactor and Partition Plate

Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none"> ■ Remove the outer panels. ■ Remove the electrical box. 		
<p>1. Remove the reactor.</p>		
<p>1 Loosen the screw. Lift and remove the reactor.</p>	 <p style="text-align: right;">(R3266)</p>  <p style="text-align: right;">(R3267)</p>	
<p>2. Remove the partition plate.</p>		
<p>1 Loosen the 2 screws.</p>	 <p style="text-align: right;">(R3268)</p>	




Step	Procedure	Points
<p>2</p>	<p>The partition plate has a hook on the lower side. Lift and pull the partition plate to remove.</p>  <p>(R3269)</p>  <p>(R3270)</p>	<ul style="list-style-type: none"> ■ When reassembling, fit the lower hook into the bottom frame.

2.4 Removal of Sound Blanket


Procedure




Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<ul style="list-style-type: none"> ■ Remove the outer panels. ■ Remove the electrical box. 		
<p>1. Remove the sound blanket.</p>		
<p>1 Untie the strings and open the sound blanket.</p>	 <p style="text-align: center;">Sound blanket (R3271)</p>	
<p>2 Lift and remove the sound blanket (body) as it is opened.</p>	 <p style="text-align: center;">(R3272)</p>	<ul style="list-style-type: none"> ■ Since the piping ports on the sound blanket are torn easily, remove the blanket carefully.
<p>3 Lift and remove the sound blanket (top).</p>	 <p style="text-align: center;">(R3273)</p>	

Step	Procedure	Points
4	Pull the sound blanket (inner) out.	<ul style="list-style-type: none"> ■ Since the piping ports on the sound blanket are torn easily, remove the blanket carefully.
5	Pull the sound blanket (bottom) out.	



(R3274)






(R3275)




2.5 Removal of Four Way Valve

Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<p>1. Remove the peripheries.</p> <p>1 Remove the terminal cover.</p> <p>2 Loosen the screw of the four way valve coil.</p>	 <p>Terminal cover</p> <p>(R3276)</p>  <p>Red (U)</p> <p>Yellow (V)</p> <p>Blue (W)</p> <p>(R3277)</p>  <p>(R3278)</p>	<ul style="list-style-type: none"> Be careful so as not to burn the compressor terminals or the name plate. <p>Make a note.</p>



Step	Procedure	Procedure	Points
3	Remove the sheets of putty. Cut the pipe with a tube cutter.	 <p>(R3279)</p>  <p>(R3280)</p>	
4	Heat up the brazed part and withdraw the piping with pliers.	 <p>(R3281)</p>	<ul style="list-style-type: none"> ■ Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries. ■ Be careful so as not to break the pipes by pressing it excessively by pliers when withdrawing it.



2.6 Removal of Compressor

Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the compressor.		
1	<p>Unscrew the nut of the compressor.</p> <ul style="list-style-type: none"> ■ Before working, make sure that the refrigerant is empty in the circuit. ■ Be sure to apply nitrogen replacement when heating up the brazed part. 	 <p>(R3284)</p> <p>Warning Ventilate when refrigerant leaks during the work. (If refrigerant contacts fire, it will cause to arise toxic gas.)</p> <ul style="list-style-type: none"> ■ Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries. ■ Be careful so as not to burn the compressor terminals or the name plate. ■ Be careful so as not to burn the heat exchanger fin. <p>Warning Since it may happen that refrigeration oil in the compressor will catch fire, prepare wet cloth so as to extinguish fire immediately.</p>
2	<p>Heat up the brazed part of the discharge side and disconnect.</p>	<p>In case of the difficulty with gas brazing machine</p> <ol style="list-style-type: none"> 1. Disconnect the brazed part where is easy to disconnect and restore. 2. Cut pipes on the main unit by a miniature copper tube cutter in order to make it easy to disconnect. <p>Cautions for restoration</p> <ol style="list-style-type: none"> 1. Restore the piping by non-oxidation brazing. 2. It is required to prevent the carbonization of the oil inside the four way valve and the deterioration of the gaskets affected by heat. For the sake of this, wrap the four way valve with wet cloth and provide water so that the cloth will not be dried and avoid excessive heating. (Keep below 120°C) <p>i Note: Do not use a metal saw for cutting pipes by all means because the sawdust come into the circuit.</p>
	 <p>(R3285)</p>	




Step	Procedure	Points
3	Heat up the brazed part of the suction side and disconnect.	
 <p>(R3282)</p>		
4	Lift the compressor up and remove it.	
 <p>(R3283)</p>		




2.7 Removal of PCB


Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the PCB.		
1 Feature of the PCB	 <p style="text-align: right;">(R3286)</p>	<ul style="list-style-type: none"> ■ You can remove the PCB when you disconnect the read wires on the terminal board without removing the electrical box. ■ PbF (Pb free brazing) is adopted.
2 Loosen the screw on the terminal board.	 <p style="text-align: right;">(R3287)</p>	
3 Release the earth terminal.	 <p style="text-align: right;">(R3288)</p>	

Step	Procedure	Procedure	Points
4	Loosen the 4 screws.	 <p>(R3289)</p>	
5	Undo the 3 hooks on the upper side.	 <p>Hooks</p> <p>(R3290)</p>	
6	Lift and pull out the PCB.	 <p>(R3291)</p>	

Step	Procedure	Points
7	<p>Feature of the PCB S70: fan motor S80: four way valve S90: thermistor (outdoor air, heat exchanger, discharge pipe)</p>  <p>(R3292)</p>	

3. Outdoor Unit / RK(X)H-C, ARK(X)H-C, R(Y)N-C




3.1 Removal of External Panels

Procedure




Warning


Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1. Remove the external panels.	  	<p>■ The top panel is integrated with the front panel.</p> <p>■ The cover has hooks at the right and left. Detach the cover by sliding it downward.</p>
1	<p>The stop valve cover can be detached by removing the screw.</p>	


Step	Procedure	Points
2	Remove the 2 screws at the front and the 3 screws at the right side.	<ul style="list-style-type: none"> When mounting the panel, be sure to fasten the hooks (at 7 positions).
3	Remove the screw at the back and the 3 screws at the left side.	<ul style="list-style-type: none"> The left side panel and the bell mouth can be removed all at once. The top panel can be mounted easily if you move it horizontally and put it down.







(R4427)



(R4428)



(R4429)

Step	Procedure	Points
<p>4</p> <p>Once bring up the front panel and remove it toward the front.</p>	 <p>(R4430)</p>  <p>(R4431)</p>	<ul style="list-style-type: none"> ■ The left side panel and the bell mouth can be removed all at once. ■ The top panel can be mounted easily if you move it horizontally and put it down.
<p>5</p> <p>Dismount the left side panel by removing the screw.</p>	 <p>(R4432)</p>	<ul style="list-style-type: none"> ■ Sectional view at the front  <p>Top panel</p> <p>Left side panel</p> <p>The edge of the top panel gets into this groove.</p> <p>(R1737)</p>




3.2 Removal of Bell Mouth

Procedure



Warning

Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1	<p>The bell mouth is attached to the front panel with 2 screws and 4 hooks.</p> 	<ul style="list-style-type: none"> ■ Dismount the bell mouth from the front panel after removing the 2 screws at the lower side.
2	<p>Remove the 2 screws and unfasten the 4 hooks, and remove the bell mouth by pulling it toward yourself.</p>  	<ul style="list-style-type: none"> ■ Unfasten the hook B by sliding the bell mouth in the arrow direction.



3.3 Removal of PCB

Procedure










Warning




Be sure to turn off all power supplies at least 10 min. before disassembling work.




Step	Procedure	Points
1	<p>To remove the drip proof plate, unfasten the hooks at 2 positions.</p>  <p style="text-align: right;">(R4436)</p>	
2	<p>The other hooks are unfastened when the drip proof plate is lifted by holding its right side.</p>  <p style="text-align: right;">(R4437)</p>	




Step	Procedure	Points
3	Peel off the adhesive tape at 2 positions of the insulation sheet.	<ul style="list-style-type: none"> ■ For prolonged durability, use filament-reinforced adhesive tape. (PVC tape can not be used.)
4	Remove the insulation sheet.	




Step	Procedure	Points
5	<p>Disconnect the fan motor connector [S70].</p>  <p>(R4440)</p>	
6	<p>The figure shows the wire harness connection around the hook.</p>  <p>(R4441)</p>	
7	<p>Remove the fan motor lead wire from the groove.</p>  <p>(R4442)</p>	
8	<p>Disconnect the four way valve connector [S80].</p>  <p>(R4444)</p>	

Step	Procedure	Procedure	Points
9	Disconnect the electronic expansion valve connector [S20].		
10	Disconnect the thermistor assembly connector (for outdoor air, heat exchanger, discharge pipe) [S90].		
11	Disconnect the compressor relay harness.		



Step	Procedure	Points	Points
12	Disconnect the faston terminal from the reactor.	 <p>(R4448)</p>	
13	Disconnect the ground wire.	 <p>(R4449)</p>	
14	Disconnect the black, white, red, and green connectors from the power supply terminal board.	 <p>(R4450)</p>	

Step		Procedure	Points
15	Dismount the PCB by removing the 2 screws.	 <p>(R4451)</p>	<ul style="list-style-type: none"> ■ For quality improvement, the PCB is placed upside down. ■ Lead-free solder (PbF) is used for PCB. When replacing the PCB, use the specific solder and soldering iron. ■ Check the LED A through the slit. It can also be checked through the slit on the terminal side of the electrical component box after detaching the stop valve cover.
16	Dismount the radiation fin by removing the 3 screws.	 <p>(R4452)</p>  <p>(R4453)</p>	<ul style="list-style-type: none"> ■ The PCB can not be dismantled unless the radiation fin is removed. ■ Remove the 5 screws. ■ Washers are attached to the screws for the radiation fin. ■ Hold the radiation fan, which is located at the lower part, by hand and remove the screws.


Step	Procedure	Points
17	Remove the radiation fin from the underneath.	<ul style="list-style-type: none"> Be sure to use silicone agent to make a tight contact with the radiation fin. Part No. of silicone agent: 1172698
18	Release the hooks of the PCB.	
19	Lift up the PCB and then unhook the wire harness.	
20	Pull the PCB toward yourself and lift it up.	





(R4454)



(R4455)



(R4456)

Step	Procedure	Points
<p>21 The figure shows the appearance of the PCB.</p>	 <p>(R4457)</p>	<p>[S20] Electronic expansion valve [S70] Fan motor [S80] Four way valve [S90] Thermistor assembly</p>
<p>22 The figure shows the appearance of the electrical box.</p>	 <p>(R4458)</p> <p>(R4459)</p>	




3.4 Removal of Electrical Box




Procedure





Warning

Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1	<p>The figure shows the electrical box.</p>  <p style="text-align: right;">(R4460)</p>	
2	<p>Disconnect the ground terminal.</p>  <p style="text-align: right;">(R4461)</p>	
3	<p>Dismount the terminal strip cover by removing the screw.</p>  <p style="text-align: right;">(R4462)</p>	

Step	Procedure	Points	Points
4	Disconnect the connection wires of the terminal block.	 <p>(R4463)</p>	
5	Remove the 2 screws at the electrical box front and right side.	 <p>(R4464)</p>	
6	Remove the electrical box by lifting it up.	 <p>(R4465)</p>	

Step	Procedure	Points
7	<p>Release the 2 wire harnesses from the hooks at the back.</p>  <p>(R4466)</p>	
8	<p>Remove the electrical box.</p>  <p>(R4467)</p>	




3.5 Removal of Propeller Fan and Fan Motor





Procedure








Warning

Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1. Remove the motor assembly.	 <p style="text-align: right;">(R4468)</p>	
1 Remove the 2 screws at the lower part of the fan motor assembly.	 <p style="text-align: right;">(R4469)</p>	
2 The assembly has the hooks at its bottom. Lift it up and pull it toward yourself to unhook.	 <p style="text-align: right;">(R4470)</p>	<ul style="list-style-type: none"> ■ When fitting the assembly, fasten the hooks (at 2 positions) of the lower part of the partition plate as they were.

Step	Procedure	Points
3	<p>Lift up the fan motor assembly and remove it.</p>  <p>(R4471)</p>	
2	<p>Remove the propeller fan.</p> <p>1 Dismount the propeller fan by removing the washer faced nut with use of an open-ended wrench.</p>  <p>(R4472)</p>  <p>(R4473)</p>	<ul style="list-style-type: none"> ■ Be careful of the fan fixing nut, which is of left-hand thread. ■ Mount the fan propeller to the fan motor so that the "●" mark should face upward.  <p>(R4474)</p>

Step	Procedure	Points
3. Remove the fan motor.	<p data-bbox="204 248 459 344">1 Pry up the hook which fixes the lead wire and draw out the lead wire.</p>  <p data-bbox="986 663 1050 685">(R4475)</p>	<p data-bbox="1098 212 1453 344">■ Pass the lead wire along the back of the motor. (Be careful not to get the wire caught by the propeller fan.)</p>  <p data-bbox="1342 651 1406 674">(R4476)</p>
2 Remove the 2 screws of the fan motor.	<p data-bbox="204 689 459 757">2 Remove the 2 screws of the fan motor.</p>  <p data-bbox="995 1104 1059 1126">(R4477)</p>	
3 Remove the fan motor.	<p data-bbox="204 1137 459 1171">3 Remove the fan motor.</p>  <p data-bbox="1002 1552 1066 1574">(R4478)</p>	
4 Dismount the propeller fan by removing the screw.	<p data-bbox="204 1597 459 1697">4 Dismount the propeller fan by removing the screw.</p>  <p data-bbox="1007 2074 1070 2096">(R4479)</p>	




3.6 Removal of Compressor Sound Insulation Pad




Procedure







Warning




Be sure to turn off all power supplies at least 10 min. before disassembling work.




Step	Procedure	Points
1. Remove the right side panel.	 <p>(R4480)</p>	<p>Preparation</p> <ul style="list-style-type: none"> Remove the electrical box according to the removal of electrical box.
1 Dismount the right side plate by removing the screw.		
2 Remove the outdoor air thermistor.	 <p>(R4481)</p>	<ul style="list-style-type: none"> The thermistor assembly is a set of the outdoor air thermistor, heat exchanger thermistor and discharge pipe thermistor.
3 Remove the 2 screws at the back of the right side panel.	 <p>(R4482)</p>	




Step	Procedure	Points
4	<p>Remove the right side panel by sliding it up along the 2 hooks at the lower side.</p>  <p>(R4483)</p>	
5	<p>Unfasten the hook at the top.</p>  <p>(R4484)</p>  <p>(R4485)</p>	<p>■ When mounting the right side panel, fasten the 3 hooks.</p>



Step	Procedure	Points
2. Remove the partition plate.	<p data-bbox="204 286 459 376">1 To dismount the partition plate, remove the 2 screws.</p>  <p data-bbox="983 1005 1043 1025">(R4486)</p> <p data-bbox="204 1055 459 1178">2 Unfasten the hook of the lower side of the partition plate from the bottom frame.</p>  <p data-bbox="995 1491 1056 1512">(R4487)</p>	<p data-bbox="1098 1055 1453 1144">■ When mounting the partition plate, fasten the hook of the bottom frame.</p>




Step	Procedure	Points
3. Remove the reactor.		
1	<p data-bbox="204 250 427 344">To dismount the reactor, remove the screw.</p>  <p data-bbox="975 831 1034 853">(R4488)</p>	
2	<p data-bbox="204 878 472 936">Slide up the reactor and remove it.</p>  <p data-bbox="959 1368 1023 1391">(R4061)</p>	

Step	Procedure	Points
4. Remove the thermistor assembly.		
1 Remove the discharge pipe thermistor.	 <p style="text-align: right;">(R4489)</p>  <p style="text-align: center;">Thermistor fixture Discharge-pipe thermistor</p> <p style="text-align: right;">(R4490)</p>	<ul style="list-style-type: none"> ■ Be careful not to lose the discharge pipe thermistor fixture. ■ Remove the discharge pipe thermistor while opening the thermistor fixture.
2 To remove the thermistor (for heat exchanger), cut off the clamp.	 <p style="text-align: right;">(R4491)</p>	<ul style="list-style-type: none"> ■ The thermistor (for heat exchanger) is fixed in position by a clamp. ■ When mounting the thermistor, fix it always at the same position. ■ The clamp is a standing part.

Step	Procedure	Points
3	<p>Remove the heat exchanger thermistor.</p>  <p>(R4492)</p>  <p>(R4493)</p>	<ul style="list-style-type: none"> ■ Be careful not to lose the thermistor retaining spring. ■ Align the thermistor with the end of the retaining spring.
4	<p>Disconnect the thermistor assembly (for outdoor air, heat exchanger, discharge pipe) connector [S90].</p>  <p>(R4494)</p>	

Step	Procedure	Points
5. Remove the sound insulation pad.	<div data-bbox="197 277 483 1182"> <p data-bbox="197 277 483 376">1 Untie the fixing strap of the sound insulation pad (outer shell).</p> </div> <div data-bbox="483 208 1090 1182">  <p data-bbox="938 309 1082 353">Sound insulation pad (outer shell)</p> <p data-bbox="995 636 1059 658">(R4495)</p>  <p data-bbox="995 1151 1059 1173">(R4496)</p> </div> <div data-bbox="197 1182 483 1650"> <p data-bbox="197 1182 483 1281">2 Pull out the sound insulation pad (outer shell).</p> </div> <div data-bbox="483 1182 1090 1650">  <p data-bbox="995 1603 1059 1626">(R4497)</p> </div>	<p data-bbox="1090 208 1457 241">Preparation</p> <ul data-bbox="1090 241 1457 824" style="list-style-type: none"> <li data-bbox="1090 241 1457 340">■ Remove the partition plate according to the removal of partition plate. <li data-bbox="1090 689 1457 824">■ The slits of the sound insulation pad for piping are apt to break off. Pay attention when removing.

Step		Procedure	Points
3	Remove the sound insulation pad (top).	 <p>(R4498)</p> <p>(R4499)</p>	
4	Remove the sound insulation pad (under).	 <p>Sound insulator (under)</p> <p>(R4500)</p>	

Step	Procedure	Points
<p>5</p>	<p>Open the sound insulation pad (inner shell) and pull it out.</p>  <p>(R4501)</p>  <p>(R4502)</p>  <p>Sound insulation pad (inner shell)</p> <p>(R4566)</p>	<ul style="list-style-type: none"> ■ The slits of the sound insulation pad for piping are apt to break off. Pay attention when removing.

3.7 Removal of Compressor





Procedure




Warning

Be sure to turn off all power supplies at least 10 min. before disassembling work.


Step	Procedure	Points
1. Remove the parts around the compressor.	<p style="text-align: right;">(R4504)</p>	<p>Preparation</p> <ul style="list-style-type: none"> ■ Remove the compressor sound insulation pad according to the removal of compressor sound insulation pad.
1	<p>Remove the terminal cover by removing the hexagonal nut.</p>	
	<p style="text-align: right;">(R4567)</p>	
2	<p>Disconnect the compressor lead wire.</p> <p style="text-align: right;">(R4506)</p>	

Step	Procedure	Points
3	<p>Remove the terminal cover gasket.</p> 	<p>Take a note.</p>  <p>U : Red V : Yellow W: Blue</p>
2. Remove the compressor.	<p>1 Remove the nut of the compressor.</p> 	<p>Warning If the refrigerant gas leaks during work, ventilate the room. (In case the refrigerant gas is exposed to fire, it will cause toxic gas.)</p>
<p>■ Before starting the work, make sure that the refrigerant gas has been completely removed out of the refrigerant circulating system.</p>		<p>■ Apply welding-work sheet or iron plate so that the flame of gas welding machine should not affect the nearby parts.</p> <p>■ Be careful not to burn the compressor terminal and the nameplate.</p> <p>■ Be careful not to burn the heat exchanger fin.</p>
2	<p>Heat the soldered portion of the discharge side, and disconnect the discharge pipe.</p> 	<p>Warning The refrigerator oil of the compressor may catch fire. Provide wet cloth for prompt extinction in emergency.</p> <p>Caution From the point of view of environmental protection, do not release the refrigerant gas to the atmosphere, but always collect it with use of a collecting device.</p>

Step	Procedure	Points
3	Heat the soldered portion of the suction side, and disconnect the suction pipe.	<p>Warning If the refrigerant gas leaks during work, ventilate the room. (In case the refrigerant gas is exposed to fire, it will cause toxic gas.)</p>
4	Remove the compressor by lifting it up.	<p>Cautions on Mounting</p> <ol style="list-style-type: none"> 1. Use anti-oxidation solder for connecting the pipe. If nitrogen gas can not be used, solder the pipe quickly. 2. It is necessary to prevent the gaskets from deterioration due to carbonization of oil in the four way valve or effect of heat. Therefore, wrap the four way valve body with wet cloth and add water occasionally so that it should not get dry and the valve should not be heated. (Keep the valve temperature below 120°C.) <p>■ When disconnecting the pipe, be careful not to crush it by pliers with undue force.</p> <p><u>If the pipe is hard to disconnect by means of a gas welding machine:</u></p> <ol style="list-style-type: none"> 1. Disconnect the pipe connection (soldered portion) which is easy to disconnect and reconnect. 2. Cut off the pipe of the valve body with use of a copper pipe cutter and disconnect it. <p>i NOTE: Never use a metal cutting saw for cutting off the pipe. It produces metallic sawdust that may enter the pipe.</p> <p>Caution Be careful not to get burned by the pipe heated by the gas welding machine.</p> <p>Caution From the point of view of environmental protection, do not release the refrigerant gas to the atmosphere in repairing the refrigerant circulating system, but always collect it with use of a collecting device.</p>



(R4510)



(R4511)

3.8 Removal of Four Way Valve




Procedure












Warning

Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
1. Remove the parts around the four way valve.		Preparation
1	To remove the coil of the four way valve, remove the screw.	<ul style="list-style-type: none"> Remove the compressor sound insulation pad and terminal cover according to the removal of compressor sound insulation pad.
2	Remove the coil of the four way valve.	<p>Caution Be careful not to get burned by the four way valve and the pipes heated by the gas welding machine.</p>
3	Remove putty.	<p>Warning If the refrigerant gas leaks during work, ventilate the room. (In case the refrigerant gas is exposed to fire, it will cause toxic gas.)</p> <p>Caution From the point of view of environmental protection, do not release the refrigerant gas to the atmosphere in repairing the refrigerant circulating system, but always collect it with use of a collecting device.</p>
		<ul style="list-style-type: none"> Before starting the work, make sure that the refrigerant gas has been completely removed out of the refrigerant circulating system. Protect the four way valve by sheet or iron plate for welding work so that the flame of gas welding machine should not affect it.



Step	Procedure	Points
2. Remove the four way valve.	 <p style="text-align: right;">(R4515)</p>	<ul style="list-style-type: none"> ■ When heating the soldered portion, be sure to conduct nitrogen replacement.
1 Heat the soldered portions of the four way valve and remove the valve.	 <p style="text-align: right;">(R4516)</p>  <p style="text-align: right;">(R4517)</p>	<p>Cautions on Mounting</p> <ol style="list-style-type: none"> 1. Use anti-oxidation solder for connecting the pipe. If nitrogen gas can not be used, solder the pipe quickly. 2. It is necessary to prevent the gaskets from deterioration due to carbonization of oil in the four way valve or effect of heat. Therefore, wrap the four way valve body with wet cloth and add water occasionally so that it should not get dry and the valve should not be heated. (Keep the valve temperature below 120°C.) <ul style="list-style-type: none"> ■ When disconnecting the pipe, use care not to crush it by pliers with undue force. <p><u>If the pipe is hard to disconnect by means of a gas welding machine:</u></p> <ol style="list-style-type: none"> 1. Disconnect the pipe connection (soldered portion) which is easy to disconnect and reconnect. 2. Cut off the pipe of the valve body with use of a copper pipe cutter and disconnect it.

Step	Procedure	Points
	<p> Warning If the refrigerant gas leaks during work, ventilate the room. (In case the refrigerant gas is exposed to fire, it will cause toxic gas.)</p> <p> Caution Be careful not to get burned by the four way valve and the pipes heated by the gas welding machine.</p> <p> Caution From the point of view of environmental protection, do not release the refrigerant gas to the atmosphere in repairing the refrigerant circulating system, but always collect it with use of a collecting device.</p> 	<p> NOTE: Never use a metal cutting saw for cutting off the pipe. It produces metallic sawdust that may enter the pipe.</p> <p> Caution From the point of view of environmental protection, be sure to use a vacuum pump for air purging.</p>




3.9 Removal of Electronic Expansion Valve

Procedure



Warning

Be sure to turn off all power supplies at least 10 min. before disassembling work.

Step	Procedure	Points
<p>1. Remove the parts around the electronic expansion valve.</p> <p>Using care not to burn the electronic expansion valve by the flame of gas welding machine, remove the following parts:</p> <ul style="list-style-type: none"> ■ Coil of four way valve ■ Putty 	 <p style="text-align: right;">(R4569)</p>  <p style="text-align: right;">(R4520)</p>	<p>Preparation</p> <ul style="list-style-type: none"> ■ Remove the compressor sound insulation pad according to the removal of compressor sound insulation pad. ■ When mounting the electronic expansion valve, be sure to fasten the hook of its coil as it was. <p>Warning If the refrigerant gas leaks during work, ventilate the room. (In case the refrigerant gas is exposed to fire, it will cause toxic gas.)</p> <p>Caution Be careful not to get burned by the pipes heated by the gas welding machine.</p> <p>Caution From the point of view of environmental protection, do not release the refrigerant gas to the atmosphere in repairing the refrigerant circulating system, but always collect it with use of a collecting device.</p>
<p>2. Remove the electronic expansion valve.</p>	 <p style="text-align: right;">(R4521)</p>	<ul style="list-style-type: none"> ■ Be careful not to burn the heat exchanger fin. ■ When mounting the electronic expansion valve, be sure to fasten the hooks of its coil as it was.
<ul style="list-style-type: none"> ■ Before starting the work, make sure that the refrigerant gas has been completely removed out of the refrigerant circulating system. 		
<p>1 Heat the 2 soldered portions and remove the electronic expansion valve (body).</p>		
<ul style="list-style-type: none"> ■ When heating the soldered portion, be sure to conduct nitrogen replacement. 		

Part 8 Others

1. Others	218
1.1 Test Run from the Remote Control	218
1.2 Jumper Settings	219

1. Others

1.1 Test Run from the Remote Control

For Heat pump

In cooling mode, select the lowest programmable temperature; in heating mode, select the highest programmable temperature.

- Trial operation may be disabled in either mode depending on the room temperature.
- After trial operation is complete, set the temperature to a normal level.
(26°C to 28°C in cooling mode, 20°C to 24°C in heating mode)
- For protection, the system disables restart operation for 3 minutes after it is turned off.

For Cooling Only

Select the lowest programmable temperature.


- Trial operation in cooling mode may be disabled depending on the room temperature.
Use the remote control for trial operation as described below.
- After trial operation is complete, set the temperature to a normal level (26°C to 28°C).
- For protection, the machine disables restart operation for 3 minutes after it is turned off.

Trial Operation and Testing

1. Measure the supply voltage and make sure that it falls in the specified range.
 2. Trial operation should be carried out in either cooling or heating mode.
 3. Carry out the test operation in accordance with the Operation Manual to ensure that all functions and parts, such as louver movement, are working properly.
- The air conditioner requires a small amount of power in its standby mode. If the system is not to be used for some time after installation, shut off the circuit breaker to eliminate unnecessary power consumption.
 - If the circuit breaker trips to shut off the power to the air conditioner, the system will restore the original operation mode when the circuit breaker is opened again.

Trial operation from Remote Control

- (1) Press ON/OFF button to turn on the system.
- (2) Simultaneously press center of TEMP button and MODE buttons.
- (3) Press MODE button twice.
("T" will appear on the display to indicate that Trial Operation mode is selected.)
- (4) Trial run mode terminates in approx. 30 minutes and switches into normal mode. To quit a trial operation, press ON/OFF button.



1.2 Jumper Settings

1.2.1 When Two Units are Installed in One Room

When two indoor units are installed in one room, the two infrared remote controls can be set for different addresses.


How to set the different addresses

■ Control PCB of the indoor unit


- (1) Remove the front panel.
- (2) Remove the sensor parts cover (2-screws), then remove the electric parts box (1-screw).
- (3) Slide the metallic cover to remove it. (4-claws on the electric parts box)
- (4) Cut the jumper JA on PCB.

■ Infrared remote control

- (1) Slide the front cover and take it off.
- (2) Cut the address jumper J4.



(R2871)



(R4562)

1.2.2 Jumper Setting

Jumper (On indoor control PCB)	Function	When connected (factory set)	When cut
JC	Power failure recovery function	Auto-restart	Unit does not resume operation after recovering from a power failure. Timer ON-OFF settings are cleared.
JB	Fan speed setting when compressor is OFF on thermostat.	Fan speed setting ; remote control setting	Fan rpm is set to "0" <Fan stop>

Part 9 Appendix


1. Piping Diagrams.....	222
1.1 Indoor Units.....	222
1.2 Outdoor Units.....	223
2. Wiring Diagrams.....	229
2.1 Indoor Units.....	229
2.2 Outdoor Units.....	230

1. Piping Diagrams

1.1 Indoor Units

1.1.1 Cooling Only


FTKS20CVMB(9), FTKS25/35CVMB(9)(8), ATKS20/25/35CVMB(9), ATKS20/25/35DVMB
FTN20/25/35CVMB9, ATKS20/25/35DAVMB



4D033698E

1.1.2 Heat Pump

FTXS20CVMB(9), FTXS25/35CVMB(9)(8), ATXS20/25/35CVMB(9), ATXS20/25/35DVMB
FTYN20/25/35CVMB9, ATXS20/25/35DAVMB




4D049319A

1.2 Outdoor Units


1.2.1 Cooling Only

ARKS20/25CVMB(9)




3D043690C

ARKS35CVMB(9)




3D043691D

RKH20/25CVMB7, ARKH20/25CVMB7, RN20/25CVMB7




3D048294

RKH35CVMB7, ARKH35CVMB7, RN35CVMB7




3D048297

ARKS20/25C2VMB



3D043690C


ARKS35C2VMB



3D043691D


1.2.2 Heat Pump

ARXS20/25CVMB(9)




3D043688C

ARXS35CVMB(9)




3D043689D

RXH20/25CVMB7, ARXH20/25CVMB7, RYN20/25CVMB7




3D048296

RXH35CVMB7, ARXH35CVMB7, RYN35CVMB7




3D048295

ARXS20/25C2VMB



3D043688C

ARXS35C2VMB




3D043689D

2. Wiring Diagrams


2.1 Indoor Units

FTK(X)S20/25/35CVMB(9)(8), ATK(X)S20/25/35CVMB(9), ATK(X)S20/25/35DVMB
ATK(X)S20/25/35DAVMB



3D033599G


FTN20/25/35CVMB9, FTYN20/25/35CVMB9




3D038710B

2.2 Outdoor Units


ARK(X)S20/25/35CVMB(9), ARK(X)S20/25/35C2VMB



RKH20/25/35CVMB7, ARKH20/25/35CVMB7, RN20/25/35CVMB7



RXH20/25/35CVMB7, ARXH20/25/35CVMB7, RYN20/25/35CVMB7



3D046990

Index

Numerics

00	101
3-minutes standby	47, 54

A

A1	102
A5	103
A6	105
address setting jumper	30
air filter	47, 140
air flow control	39
air flow direction	77
air purifying filter with photocatalytic deodorizing function	47
ARC433A	98
AUTO · DRY · COOL · HEAT · FAN operation	75
automatic operation	41
auto-restart	30, 219
auto-restart function	47
auto-swing	38

B

bell mouth	165, 185
------------	----------

C

C4	106
C9	106
care and cleaning	87
centralized control	30
check	
discharge pressure check	133
electronic expansion valve check	130
four way valve performance check	131
Hall IC check	137
installation condition check	133
inverter units refrigerant system check	135
outdoor unit fan system check	134
power supply waveforms check	135
power transistor check	136
thermistor resistance check	132
turning speed pulse input on the outdoor unit PCB check	136
compressor	177, 209
compressor lock	109
compressor overload	108
compressor protection function	54
connectors	30, 32, 34
connectors	
fan motor	163
four way valve	169
control PCB (indoor unit)	31, 153
control PCB (outdoor unit)	33, 34, 179
cover	
stop valve cover	162
terminal cover	175

D

DC fan lock	110
DC voltage / current sensor abnormality	118
defrost control	57
diagnosis mode	99
discharge pipe	59
discharge pipe control	54
discharge pipe temperature control	60, 114
discharge pipe thermistor	48, 49, 59, 120, 170, 204
discharge pressure check	133
display PCB	152
drain plug	157
drip proof plate	163, 186

E

E5	108
E6	109
E7	110
E8	111
EA	112
electrical box	169, 194
electrical box temperature rise	121
electronic expansion valve	215
electronic expansion valve check	130
electronic expansion valve control	58
error codes	
00	101
A1	102
A5	103
A6	105
C4	106
C9	106
E5	108
E6	109
E7	110
E8	111
EA	112
F3	114
F6	115
H6	117
H8	118
H9	119
J3	119
J6	119
L3	121
L4	123
L5	125
P4	119
U0	127
U2	129
U4	107
error codes and description	101
external panels	182

F	
F3	114
F6	115
facility setting jumper	32, 63
fan control	56
fan motor	158, 166, 197
fan motor fixing frame	166
fan motor or related abnormality	105
fan motor, connector	163
fan rotor	158
fan speed control	39
fan speed setting	30, 219
filter	
air filter	47
air purifying filter with photocatalytic deodorizing function	47
filter PCB	33
forced cooling operation	37
forced operation mode	62
forced operation ON/OFF switch	30
four way valve	175, 212
four way valve abnormality	112
four way valve operation compensation	53
four way valve performance check	131
four way valve switching	53
four way valve, connector	169
freeze-up protection control	55, 103
frequency control	36, 51
frequency principle	36
front grille	143
front panel	163
FU1	30, 32, 34
FU2	32
FU3	32, 34
fully closing with power on	59
functions, list	2
fuse	30, 32, 34
H	
H6	117
H8	118
H9	119
HA	30
Hall IC	39, 105
Hall IC check	137
HC3	32
HC4	32
heat exchanger	154
heating peak-cut control	56
high pressure control	103
high pressure control in cooling	115
HL3	32
HN3	32
HOME LEAVE operation	45, 81
horizontal blade	146
hot start function	47
I	
indoor heat exchanger thermistor	106, 148
indoor unit PCB abnormality	102
input current control	55
input over current detection	111
installation condition check	133
instruction	67
insufficient gas	127
insufficient gas control	61
INTELLIGENT EYE	43
INTELLIGENT EYE operation	83
INTELLIGENT EYE sensor PCB	31
inverter powerful operation	46
inverter principle	36
inverter units refrigerant system check	135
J	
J3	119
J4	219
J6	119
J8	32
JA	30
JB	30, 219
JC	30, 219
jumper settings	219
L	
L3	121
L4	123
L5	125
LED1	30
LED2	30
LED3	30
LED A	32, 34
liquid compression protection function 2	56
lower limit for cooling	63
M	
mode changing control	53
mode hierarchy	50
mold proof air filter	47
motor	
fan motor	166
N	
names of parts	69
night set mode	42
O	
OL activation	108
ON/OFF button on indoor unit	47
opening limit	59
operation lamp	96
outdoor air temperature thermistor	120
outdoor heat exchanger	
thermistor	48, 49, 120, 170, 204
outdoor unit fan system check	134
OUTDOOR UNIT SILENT operation	80
output over current detection	125
over current	61, 111, 125
overload	61, 108
overload protector	32
over-voltage detection	129

P	
P4	119
panel	
front panel	163
right side panel	167, 200
top panel	163
partition plate	171
PCB	151, 186
PI control	52
piping diagrams	222
plate	
drip proof plate	163
partition plate	171
shelter	162
position sensor abnormality	117
power failure recovery function	30, 219
power supply waveforms check	135
power transistor check	136
power-airflow dual flaps	38
POWERFUL operation	46, 79
POWERFUL operation mode	62
preheating operation	53
preparation before operation	72
pressure equalization control	59
printed circuit board (PCB)	
control PCB (indoor unit)	31, 153
control PCB (outdoor unit)	33, 34, 179
display PCB	152
filter PCB	33
INTELLIGENT EYE sensor PCB	31
signal receiver PCB	31
problem symptoms and measures	97
programme dry function	40
propeller fan	164, 197
R	
radiation fin temperature rise	123
radiation fin thermistor	120
reactor	171
reactor harnesses	169
remote control	98
right side panel	167, 200
room temperature thermistor	106
RTH1	30
S	
S1	30, 148
S10	32
S11	32
S20	32, 34, 189
S21	30
S26	30
S27	30
S30	32
S32	30
S35	30
S36	30
S40	32
S6	30, 148
S7	30, 148
S70	32, 34, 163, 188
S80	32, 34, 169, 188
S90	32, 34, 189
safety precautions	67
self-diagnosis digital display	47
sensor malfunction detection	61
service check function	98
service cover	143
shelter	151, 162
signal receiver PCB	31
signal receiving sign	47
signal transmission error	107
sound blanket	173
sound insulation pad	200
specifications	10
starting operation control	59
start-up	53
stop valve cover	162
SW7	30
swing motor	153
switch box	148
T	
terminal board	179
terminal cover	175
terminal strip	149
test run	218
thermistor	
discharge pipe	
thermistor	48, 49, 59, 120, 170, 204
indoor heat exchanger	
thermistor	48, 49, 106, 148
outdoor air temperature thermistor	120
outdoor heat exchanger	
thermistor	48, 49, 120, 170, 204
radiation fin thermistor	120
room temperature thermistor	106
thermistor or related abnormality (indoor unit)	106
thermistor or related abnormality (outdoor unit) ..	119
thermistor resistance check	132
TIMER operation	85
top panel	163, 182
troubleshooting	90, 101
troubleshooting with LED indication	96
turning speed pulse input on the outdoor unit PCB	
check	136
U	
U0	127
U2	129
U4	107
V	
V1	30, 32, 34
V2	32, 34
V3	32, 34
varistor	30, 32, 34
vertical blade	147
voltage detection function	62
W	
wide-angle louvres	38

wiring diagrams229

Drawings & Flow Charts

A			
ARC433A	98	inverter features	37
automatic air flow control	39	inverter POWERFUL operation	46
automatic operation	41	inverter units refrigerant system check	135
auto-swing	38		
C		J	
compressor lock	109	jumper settings	219
compressor protection function	54		
control PCB (indoor unit)	31	M	
control PCB (outdoor unit)	33, 34	mode hierarchy	50
D		N	
DC fan lock	110	night set mode	42
defrost control	57	O	
diagnosis mode	99	OL activation (compressor overload)	108
discharge pipe control	54	ON/OFF button on indoor unit	47
discharge pipe temperature control	114	operation lamp	96
discharge pressure check	133	outdoor unit fan system check	134
E		output over current detection	125
electrical box temperature rise	121	over-voltage detection	129
electronic expansion valve check	130		
electronic expansion valve control	58	P	
F		pipings diagrams	
facility setting jumper	63	ARKH20/25CVMB7	224
fan motor or related abnormality	105	ARKH35CVMB7	224
filter PCB	33	ARKS20/25C2VMB	225
four way valve abnormality	112	ARKS20/25CVMB(9)	223
four way valve performance check	131	ARKS35C2VMB	225
freeze-up protection control	55	ARKS35CVMB(9)	223
freeze-up protection control or		ARXH20/25CVMB7	227
high pressure control	103	ARXH35CVMB7	227
frequency control	51	ARXS20/25C2VMB	228
frequency principle	36	ARXS20/25CVMB(9)	226
function of thermistor		ARXS35C2VMB	228
cooling only model	49	ARXS35CVMB(9)	226
heat pump model	48	ATKS20/25/35CVMB(9)	222
H		ATKS20/25/35DAVMB	222
Hall IC check	137	ATKS20/25/35DVMB	222
heating peak-cut control	56	ATXS20/25/35CVMB(9)	222
high pressure control in cooling	115	ATXS20/25/35DAVMB	222
HOME LEAVE operation	45	ATXS20/25/35DVMB	222
I		FTKS20CVMB(9)	222
indoor unit PCB abnormality	102	FTKS25/35CVMB(9)(8)	222
input current control	55	FTN20/25/35CVMB9	222
input over current detection	111	FTXS20CVMB(9)	222
installation condition check	133	FTXS25/35CVMB(9)(8)	222
insufficient gas	127	FTYN20/25/35CVMB9	222
insufficient gas control	61	RKH20/25CVMB7	224
INTELLIGENT EYE	43	RKH35CVMB7	224
INTELLIGENT EYE sensor PCB	31	RN20/25CVMB7	224
		RN35CVMB7	224
		RXH20/25CVMB7	227
		RXH35CVMB7	227
		RYN20/25CVMB7	227
		RYN35CVMB7	227

position sensor abnormality	117
power supply waveforms check	135
POWERFUL operation	46
programme dry function	40

R

radiation fin temperature rise	123
remote control	98

S

service check function	98
signal receiver PCB	31
signal transmission error (between indoor and outdoor units)	107

T

target discharge pipe temperature control	60
thermistor or related abnormality (indoor unit)	106
thermistor or related abnormality (outdoor unit) ...	119
thermistor resistance check	132
trial operation from remote control	218
turning speed pulse input on the outdoor unit PCB check	136

W

wiring diagrams	
ARK(X)S20/25/35C2VMB	230
ARK(X)S20/25/35CVMB(9)	230
ARKH20/25/35CVMB7	230
ARXH20/25/35CVMB7	231
ATK(X)S20/25/35CVMB(9)	229
ATK(X)S20/25/35DVMB	229
FTK(X)S20/25/35CVMB(9)(8)	229
FTN20/25/35CVMB9	229
FTYN20/25/35CVMB9	229
RKH20/25/35CVMB7	230
RN20/25/35CVMB7	230
RXH20/25/35CVMB7	231
RYN20/25/35CVMB7	231

In all of us,
a green heart



Daikin's unique position as a manufacturer of air conditioning equipment, compressors and refrigerants has led to its close involvement in environmental issues. For several years Daikin has had the intension to become a leader in the provision of products that have limited impact on the environment. This challenge demands the eco design and development of a wide range of products and an energy management system, resulting in energy conservation and a reduction of waste.



Daikin Europe N.V. is approved by LRQA for its Quality Management System in accordance with the ISO9001 standard. ISO9001 pertains to quality assurance regarding design, development, manufacturing as well as to services related to the product.



ISO14001 assures an effective environmental management system in order to help protect human health and the environment from the potential impact of our activities, products and services and to assist in maintaining and improving the quality of the environment.




Daikin units comply with the European regulations that guarantee the safety of the product.



Daikin Europe N.V. participates in the Eurovent Certification Programme for Air Conditioners (AC), Liquid Chilling Packages (LCP) and Fan Coil Units (FC); the certified data of certified models are listed in the Eurovent Directory.

"The present publication is drawn up by way of information only and does not constitute an offer binding upon Daikin Europe N.V.. Daikin Europe N.V. has compiled the content of this publication to the best of its knowledge. No express or implied warranty is given for the completeness, accuracy, reliability or fitness for particular purpose of its content and the products and services presented therein. Specifications are subject to change without prior notice. Daikin Europe N.V. explicitly rejects any liability for any direct or indirect damage, in the broadest sense, arising from or related to the use and/or interpretation of this publication. All content is copyrighted by Daikin Europe N.V.."



DAIKIN EUROPE N.V.
Naamloze Vennootschap
Zandvoordestraat 300
B-8400 Oostende - Belgium
www.daikin.eu
BTW: BE 0412 120 336
RPR Oostende



SIENBE04-512A