



Nr	Part name	Description
1	Liquid pipe connection port	\varnothing 6.4 Flare connection
2	Gas pipe connection port	\varnothing 12.7 Flare connection
3	Drain pipe connection port	VP20 (O.D. \varnothing 26 / I.D. \varnothing 20)
4	Drain hose (Accessory)	I.D. \varnothing 25 (Outlet)
5	Control box	
6	Transmission wiring connection	
7	Power supply connection	
8	Suspension bracket	
9	Inspection door	
10	Socket for drain	
11	Air filter (Accessory)	

NOTES

- In case of back-suction, mount chamber cover to bottom side of the unit.
 In case of bottom-suction, mount chamber cover to back side of the unit.
- Location of unit's name plate: control box cover.
- Mount the air filter at the suction side.
 (Select its color (gravity method) 50% or more).
 It can not be equipped with air filter (accessory) when connecting duct to suction side.